

# MFG 4550 plus

brother.




# Shipment of the Multi-Function Center (MFC)

If for any reason you must ship your MFC, carefully package the MFC to avoid any damage during transit. It is recommended that you save and use the original packaging. The MFC should be adequately insured with the carrier.

# Warning

When shipping the MFC, the DRUM UNIT assembly including the TONER CARTRIDGE must be removed from the MFC and placed in the plastic bag. Failure to remove it and place it in the plastic bag during shipping, will cause severe damage to the MFC and will VOID THE WARRANTY.



© 1994, 1995, 1996, 1997 Brother Industries Ltd.

# Introduction to the Operations Manual (for Fax, Printer, Copier Operations)

- Have you set up your MFC and prepared your computer for the printer mode by following the instructions in the Setup Manual? The Setup Manual will help you prepare your MFC to use it as a <u>fax, printer and copier.</u>
- ► Your MFC 4550 plus has five performance modes. It is a Fax, Printer, Copier, Scanner and PC Fax.
- After you complete setting up the MFC, see this Operations
  Manual for Fax, Printer, Copier operations and for more
  information about your MFC, such as functions of the machine
  and the control panel. Information about maintenance,
  troubleshooting and technical specifications are also available
  in this manual.
- ► Please keep this manual beside your MPC so you can access important information whenever necessary.
- ► See the Multi-Function Link Pro Online Documentation for information on how to set up your MFC and Personal Computer and how to use the Scanner and PC Fax.





# • ····· For Your Information

1.	THE CONTROL PANEL KEYS	1
	TELEPHONE AREA	2
	ONE TOUCH, PRINTER AND COPY AREA	3
	LCD & USER SETUP AREA	5
2.	HOW TO USE ON-SCREEN PROGRAMMING (O AND HELP KEY	
	User-friendly Programming	
	Using the Function Mode to Access On-screen Programming (OSP)	
	Shortcut	
	Alternating Displays for On-screen Programming (OSP)	
	Function Selection Table	
	Using the Help Key	14
	How to Enter Text in Function Mode	15
	How to Enter Special Characters, Symbols and Punctuation Marks in Function Mode	
	How to Set the Sleep Time	17
3.	FUNCTION SETTINGS	19
	Setting the Dialing Mode (Tone/Pulse)	
	Setting the Date and Time	
	Setting the Station ID	21
	Setting the Beeper Volume Level	
	Storing the One Touch Dial Numbers	
	• When You Wish to Change the Stored One Touch and	25
	Speed Dial Numbers	97
	Memory Storage/Temporary Battery Back Up	27
	Setting Up Groups for Broadcasting	
	Types of Numbers	
	-1 F	
	Chain Dialing	29
4.	<b>*</b> -	
4.	Chain Dialing  USING THE MFC AS A TELEPHONE  Manual Dialing	<b>31</b> 31
4.	Chain Dialing  USING THE MFC AS A TELEPHONE	31 31

	Using Hold, Pause, # with the Telephone	
	On Hook Dialing	. 32
	Searching the Telephone Index	. 32
<b>5.</b>	SENDING FAXES	.33
	A) DOCUMENT BASICS	. 33
	The Size of Your Documents	. 33
	How to Insert the Document	. 33
	The Auto Document Feeder (ADF)	. 34
	Getting Ready to Send a Fax	. 35
	Setting the Resolution (Temporary Setting)	
	Setting the Contrast (Temporary Setting)	. 36
	B) BASIC FAX TRANSMISSIONS	. 37
	Sending a Fax	. 37
	Talking to the Other Party When Sending a Fax	. 37
	Sending a Fax Automatically	. 38
	Sending a Fax Manually	. 38
	Automatic and Manual Redialing	
	Optional Settings When You Send a Fax Manually	. 39
	Printing Page Headers	. 39
	C) ADVANCED FAX TRANSMISSIONS	. 40
	Sending a Fax by Using Super Quick-Scan	
	(Memory Transmission)	. 40
	<ul> <li>If You Get a MEMORY FULL Message When Trying to</li> </ul>	
	Send a Fax by Using Super Quick-Scan	. 40
	Setting the Daily Timer (for Delayed Transmissions)	
	Delayed Transmission (Temporary Setting)	
	Broadcasting	. 43
	Getting Familiar with the Broadcasting Function	
	Sending by Multiple Transmissions	
	Interrupting the Timer and Polled Job	
	Canceling a Job	. 47
	D) FAX TRANSMISSION OPTIONS	. 48
	Setting the Overseas Mode (Temporary Setting)	
	Setting Your MFC for Multiple Resolution	
	Transmission (Temporary Setting)	. 49
	Sending a Fax with an Electronic Cover Page Message	
	Selecting a Comment for the Cover Page	
	Customizing Your Cover Page Comment	


	Printing a Sample Cover Page	52
	To Always Send a Cover Page	53
	Sending an Automatic Cover Page	54
	Sending a Fax When the Cover Page Is ON	54
	Sending a Cover Page (Temporary Setting)	54
	Sending a Fax with Call Reservation (Temporary Setting)	
	(Talking to the receiving party after fax transmission)	56
	Using the Call Reservation Function	56
	Printing the Call Back Message	58
	ECM (Error Correction Mode)	58
	Error Retransmission	59
	Next-FAX Reservation	59
6.	RECEIVING FAXES AND OTHER CALLS	<b>51</b>
	A) BASIC SETUP TO RECEIVE FAXES	61
	Selecting an Answer Mode	61
	Manual Reception (Manual Mode)	
	Automatic Fax Only Reception (Fax Mode)	62
	Setting the Ring Delay	62
	The F/T Switch (Fax/Telephone Mode)	63
	Setting the F/T Ring Time	
	Smoothing	
	Setting the Size of the Paper	
	Printing a Reduced Size Copy of the Incoming Document	
	Auto Reduction	67
	Using Fixed Reduction Ratios	
	Selecting the Ratios of Fixed Reduction	
	Reception into Memory (Out of Paper Reception)	
	Setting the Print Density	
	Toner Save Function	
	Speaker Volume	
	Ring Volume	72
	B) REMOTE ACTIVATION	
	What is Remote Activation?	
	• Connecting an External or Extension Telephone	
	Using Remote Codes	
	Using the Activation Code	14
	Using the Deactivation Code	
	WAKING THE REMOTE LODGE PASIET TO USE	10

	Troubleshooting	75
	Changing and Registering Remote Codes	75
	C) CONNECTING A TELEPHONE ANSWERING	
	DEVICE (TAD)	76
	How to Use an External TAD with the MFC	76
	Connecting an External TAD to the MFC	77
	Flowchart of External TAD Reception	78
	TAD Hookup	78
	Recording the TAD's Outgoing Message (OGM)	79
	D) DISTINCTIVE RINGING	
	Distinctive Ringing	79
	What Is Distinctive Ringing?	79
	What Is the Advantage of Using the Distinctive Ringing	
	Function?	79
	Can My MFC Use Distinctive Ringing?	79
	Can I Change the Setting Later?	80
	How Will the MFC Treat All Other Numbers?	80
	External Telephone Answering Device (TAD) Answers	
	Other Number(s) on the Line:	80
	How Does the Distinctive Ringing Function Work?	81
	Flowchart of an Incoming Call	
	Which Phone Number Should I Register?	82
	What Must I Do to Set Up Distinctive Ringing?	82
	Setting the Distinctive Ringing Function	82
	How to Turn the Distinctive Ringing Function ON or OFF	
	E) CALLER ID	84
	What is Caller ID?	84
	Advantages of Caller ID	
	How Does Caller ID Work?	85
	The Caller ID Appears on the Display When Your	
	Telephone Rings	85
	The Caller ID is Stored in Your MFC's Memory	85
	Scanning through the Caller IDs Stored in the Memory	
	Clearing a Caller ID Stored in Memory	
	Printing the Caller ID List	87
_	DOLLENG (WELLDOD A DAY OF WELLDON	^^
<u>7.</u>	POLLING (TEMPORARY SETTINGS)	89
	What Is Polling?	89
	How Does It Work?	QQ


	When to Use Polling	89
	Polling Another Fax Machine (Calling)	90
	Setting Up Polled Waiting (Being Called)	
	Delayed Polling	92
	Setting Up Polled Waiting with Super Quick-Scan	
	Sequential Polling	
8.	REMOTE FAX OPTIONS	95
	Setting the Fax Storage	95
	Paging/Fax Forwarding	
	Setting Up Paging (Registering the Paging Number)	
	Setting Up Fax Forwarding (Registering the Fax Forwar	
	Number)	100
	What Is Remote Control Access?	100
	Changing the Remote Access Code	101
	How to Use Remote Access and Control Codes	102
	Remote Fax Retrieval	
	When to Enter the Remote Access Code	102
	Remote Control Commands	103
	Retrieving the Memory Status List and Fax Messages	
	Remotely	104
	Changing the Fax Forwarding Number Remotely	
	Printing a Fax Message	105
9.	USING THE MFC AS A PRINTER	107
	Acceptable Paper	107
	Control Panel Keys	110
	Simultaneous Operation	110
	On/OffLine Key	110
	FF/Cont Key	110
	Test/Reset Key	111
	Print Priority Key	111
	Windows® Printing	112
	Remote Printer Console Program for DOS	112
	Popular Printer Emulation Support	
	Bi-Directional Parallel Interface	
	Enhanced Memory Management	
	Multi-purpose Sheet Feeder	113

Manual Feed Slot	115
Printing the Internal Font List	117
Printing the Print Configuration List	118
10. PRINTING REPORTS AND LISTS	121
How to Print Reports and Lists	122
11. HOW TO USE THE COPY FUNCTION	129
Making a Single Copy	129
	130
, 0	
while Making Copies	130
Copying a Photograph	132
12. REPLACING TONER CARTRIDGE AND	
	133
Toner Empty Indicator	_ 133
Manual Feed Slot       115         When you load one sheet of paper manually       115         When you load more than one sheet of paper manually:       115         • Paper Tray       116         Printing the Internal Font List       117         Printing the Print Configuration List       118         Restoring to the Factory Default Settings       119         Printing PC Data in Hexadecimal       120         10. PRINTING REPORTS AND LISTS       121         How to Print Reports and Lists       122         Activity Report Interval       123         Printing the All Dial List       125         Transmission Verification (Xmit) Report       126         Memory Status List       127         11. HOW TO USE THE COPY FUNCTION       129         Making a Single Copy       122         Stacking Multiple Copies       130         • What to Do When You Get a MEMORY FULL Message       while Making Copies       130         Reducing and Enlarging Copies       131         Copying a Photograph       132         12. REPLACING TONER CARTRIDGE AND       132         DRUM UNIT       133         Replacing the Toner Cartridge       133         Replacing the Drum Unit       133	
Regular Maintenance	141
Cleaning the Drum Unit	142
Fixing a Document Jam	
Fixing a Paper Jam	146

14.	OPTIONAL ACCESSORIES	149
	Connecting the Serial Interface Board (RS100M)	149
	Setting the Serial Interface Parameters	<b>1</b> 51
	Memory Board	154
	Optional Memory for the Printer & Fax Operations	154
	Installing the Optional Memory Board	
<b>15.</b>	TROUBLESHOOTING PROCEDURES	157
	Fax-Back System	
	Brother on the World Wide Web	157
	Brother Bulletin Board	
	Error Messages	
	If You are Having Difficulty with Your MFC	
	Troubleshooting Tips	
16.	SPECIFICATIONS	175
	Parallel Interface Specifications	
	Resident Fonts	
	Symbol Sets/Character Sets	178
17.	IMPORTANT INFORMATION	181
	Standard Telephone and FCC Notices (Applies only to	
	120V model)	181
	Important Safety Instructions	
IN	DEX	187
	OR CUSTOMER SERVICE	



# **4** TELEPHONE AREA



#### 1. Dial Pad

These twelve keys are used to dial phone and fax numbers (see page 31), and also can be used as an alphanumeric keyboard for entering information into the MFC. (See pages 15–17.)

#### 2. Hook


This key lets you dial telephone and fax numbers without lifting the handset.

#### 3. Hold

You can use this key to put a call on hold. (See page 31.)

#### 4. Redial/Pause

This key redials the last number called. (See page 39.) This key is also used to insert a pause in auto dial numbers. (See pages 25, 31.)




# 5. Speed Dial

This key lets you dial previously stored Speed Dial phone numbers by entering a two-digit number. (See pages 25–27, 31.)

#### 6. Tel-index

This key allows you to look up numbers stored in the dialing memory alphabetically. (See page 32.)

# **6** ONE TOUCH, PRINTER AND COPY AREA




# 7. Shift

This key is used to access the "13" through "24" One Touch keys. (See page 24.) In the printer mode when **Shift** is pressed together with **Test/Reset**, it resets and restores the MFC to the factory default settings. (See page 111.)

## 8. One Touch Dial Keys

These 12 keys give you instant access to previously stored phone numbers.

(See pages 24 25, 31.)



#### 9. Reduce

This **Reduce** key will reduce copies depending on the ratio you select: 100%, 93%, 87%, 75%, and 50%. You can also use the Auto Reduction function to have the MFC automatically calculate the reduction ratio that fits the size of your paper. (See page 131.)

## 10. Copy

Press this key to make a copy. (See pages 129–132.)


# 11. Enlarge

This **Enlarge** key will enlarge copies depending on the ratio you select: 200%, 150%, 125%, 120% and 100%. You can also use the Auto Reduction function to have the machine automatically calculate the reduction ratio that fits the size of your paper. (See page 131.)

#### 12. Photo

This key is used to copy photographs. (See page 132.)

# **3** ONE TOUCH, PRINTER AND COPY AREA



### 13. On/OffLine

This key is used to turn the printer online (ready to receive PC data) and offline (not ready to receive PC data) alternately. When the printer is online, the LCD displays ONLINE. (See page 110.)

#### 16. FF/Cont

When the LCD shows REMAINED DATA, you can turn the MFC OFFLINE and then press this key to print the data that is in the memory. Also, it clears some operation and

machine errors.
(See pages


110–111.)

#### 14. Stop

This key stops a fax, cancels an operation, or exits from function mode. (See page 8.)

#### 15. Start

Use this key to start an operation, such as sending a fax. (See page 37.)




# 17. Test/Reset

This key is used to print a test page. When it is pressed together with **Shift**, it clears data from the printer memory, cancels an error status, and then resets and restores to the factory default settings. (See page 111.)

#### 18. Print Priority

When this key is pressed all faxes will be received into memory without first printing and can be printed later. This key also increases the memory available for printing. (See page 111.)

#### **©** LCD & USER SETUP AREA



#### 19. (Left Arrow)

This key moves the LCD cursor to the left. It also allows you to back up one step when you are in function mode (see page 7) or Telephone Index (see page 32).

# 21. Liquid Crystal Display


The LCD displays messages (On-Screen Programming) that will help you set up and operate your MFC. The upper row shows fax and copy status and the lower row shows printer and scanner status. (See page 7.)

#### 20. $\blacktriangleright$ (Right Arrow)

This key moves the LCD cursor to the right, and it also lets you advance one step when you are in function mode (see page 7) or Telephone Index (see page 32).

#### 22. Clear

This key deletes entered data or backs up one step in function mode. (See page 8.)




#### 23. Set

This key is used for storing a function setting into the MFC. (See page 8.)

#### 24. Function

This key accesses the function and programming mode (OSP), so you can alter various settings. (See page 7.)

### **©** LCD & USER SETUP AREA



#### 25. Mode


This key is used to specify how the MFC should handle incoming calls. (See page 61.)

#### 27. Resolution

This key is used to set the resolution requirements when sending a fax. (See page 35.)

## 26. Super Q.Scan

This key enables you to seen in your originals at twice the normal speed, by storing them in the memory before actual transmission. (See page 40.) When it is pressed, Broadcasting is available. (See pages 43–44.) When **Super Q.Scan** is pressed together with **Shift**, Multi-Transmission is available. (See pages 44–45.)



#### 28. Coverpage

This key is used to send a Cover Page as the first page of a fax transmission. (See pages 54-55.)

#### 29. Help

Press this key whenever you want a quick reference Help List printed. This Help List will give you information on how to perform settings for a function, how to register information, or how to get basic information. (See pages 7, 14.)

# 2. HOW TO USE ON-SCREEN PROGRAMMING (OSP) AND HELP KEY




#### User-friendly Programming

We have designed your MFC with on-screen programming and a Help key, userfriendly programming that helps you take full advantage of all the functions your MFC has to offer.

We created step-by-step on-screen prompt messages on the LCD to help you program your MFC. All you have to do is follow the prompt instructions as they guide you through the function menu selections and programming options and settings.

#### Using the Function Mode to Access On-screen Programming (OSP)

You can access the Function mode by pressing Function and waiting for two seconds. Then select FAX or PRINTER by pressing 1 or 2.



When you enter Function mode, your MFC will display a list of Level One Functions to choose from (see pages 10 through 14 for these Level One Functions), as seen on the previous page.

These function options will appear one after the other on the display. You can then choose one of these options by pressing **Set** when the option you want appears on the LCD.

You can also move through the function menu options at a faster rate by pressing right arrow). (See page 5 to locate this key on your Control Panel.) When you find the option you want, press Set.

After you press the Level One Function number, then press the Level Two Function number associated with each option (refer to pages 10 through 14).

To exit function mode, press **Stop**. If you selected the wrong menu and want to return to the previous step, press **Clear**.


#### Shortcut

The functions in this manual list each step in detail, showing the LCD display prompts after you press each key. Function, 1 (FAX)—OR—2 (PRINTER), Level One number, and Level Two number. Then you are in the function where you must either use the < or > to select an option or enter the information using the dial pad.

To bypass LCD displays and go directly into the function without waiting, do not pause between the above four key strokes. For example, the shortcut to access the DATE/TIME function is: Press **Function**, 1, 7, 1.

Once you are comfortable with skipping these LCD displays, you can program most functions directly from the Function Selection Table (see pages 10–14).

# Alternating Displays for On-screen Programming (OSP)



When you see alternating displays, the LCD will usually alternate between the currently selected option, and a help message giving brief instructions on how to proceed. The example shows the current speaker volume is high and prompts you to use — (left arrow) and — (right arrow) to change the setting, and then to press Set to store it.

#### Function Selection Table

If you have a basic understanding of how to program your MFC, you can perform most of the programming settings without this Operations Manual. To help you understand the function selections, options, and settings that are found in your MFC programs, we have the following Function Selection Table.

Read through this table to gain a basic understanding of what your new Multi-Function Center can do, and then the next section will begin instructing you how to use On-Screen Programming.

#### <1. FAX MENU FUNCTIONS>

Level one function	Level two function	Explanation of Options	Factory setting	Page
	1. TIMER	Use TIMER to send your documents at a later time.		42–43
	2. POLLING	Polling is the process of retrieving faxes from another machine. ON/OFF	OFF	89–94
1. TEMP.	3. CALL RESERVE	You can send a fax and then talk to the recipient using the CALL RESERVE function. ON/OFF.	OFF	56–57
(TEMPORARY) SETTINGS	4. CONTRAST	There are three types of contrast settings. Usually the AUTO setting is acceptable. But if you want to send or copy an especially light or dark document, you should change this setting. AUTO: Default is AUTO. Contrast setting always reverts to AUTO after one transmission. S. LIGHT:To send very light documents. S. DARK: To send very dark documents.	AUTO	36

Level one function	Level two function	Explanation of Options	Factory setting	Page
1. TEMP. (TEMPORARY) SETTINGS	5. RESOLUTION	If you need to send a set of originals at various resolutions, this function will allow you to set the required resolution page by page. (If all documents are the same resolution, use the Resolution key. See page 1-6 #27.) STANDARD/FINE/S. FINE/PHOTO	STAN- DARD	49–50
	6. OVERSEAS MODE	If you have trouble when sending overseas, you may want to set OVERSEAS MODE to ON. ON/OFF	OFF	48
2. CANCEL JOB		If you wish to cancel a job that has been set with the timer, a polled job etc., use this function.		47
3. PRINT REPORTS	See page 121 for a list of reports.	You can print several different lists and reports, which are available under function item 3. PRINT REPORTS.		121–127
	1. ONE-TOUCH DIAL	If you register names and numbers on One Touch dial keys, you can dial a number automatically just by pressing a One Touch key. (Max. of 24 locations)		24–25
4. SET AUTO DIAL	2. SPEED-DIAL	If you register names and numbers as Speed Dial numbers, you can dial a number automatically just by pressing Speed Dial key and a two-digit number using the dial pad. (Max. of 36 locations)		25–26
	3. SETUP GROUPS	This is used for setting up a group number used for broadcasting.		27–29
5. USER OPTIONS	1. SMOOTHING	Smoothing enhances the appearance of incoming faxes. If you set SMOOTHING to ON, you will receive messages with the smoothing enhancement. ON/OFF	ON	.65
	2. BEEPER	You can adjust the volume of the beeper with this function. OFF/LOW/HIGH	LOW	23

The second services of the second second services of the second secon

Level one function	Level two function	Explanation of Options	Factory setting	Page
	3. COVERPG ON/OFF	If you set COVERPAGE to ON, you can send your documents with a Cover Page generated by your MFC. When the COVERPAGE setting is ON, you can select a Cover Page comment. ON/OFF	OFF	53–54
	4. ERROR RE-TX	If you set ERROR RE-TRANSMISSION to ON, the MFC automatically resends the page once an error occurs. ON/OFF	OFF	59
5. USER	5. REDUCTION	You can avoid having your incoming data separated by printing a reduced copy of the incoming document. The reduction methods are AUTO or Fixed ratio: AUTO/100%/93%/87%/75%	AUTO	67 68
OPTIONS	6. RCD PAPER	You can select one of three sizes of paper. The MFC automatically will adjust the size of the incoming fax document or original document so that it fits the paper size you have selected.  LETTER/LEGAL/A4	LETTER	66
	7. TONER SAVE	You can extend the life of the toner by conserving its use. ON/OFF	OFF	70
	8. SLEEP MODE	This mode reduces the power consumption when the MFC is idle. The time period before the MFC drops into the mode is user selectable.	00MIN	17
	9. PRINT DENSITY	You can adjust Print Density with this function.		69
6. TEL OPTIONS	1. TONE/PULSE	There are two different dial types and you must select the type of signal suitable for your telephone line. TONE/PULSE	TONE	19
	2. RING DELAY	This is the number of rings before the MFC answers the call when in F/T or Fax Mode.  0/1/2/3/4 rings	2	62–63
	3. SPEAKER VOLUME	You can adjust the speaker volume with this function. OFF/LOW/HIGH	LOW	71

Level one function	Level two function	Explanation of Options	Factory setting	Page
	4. F/T RING TIME	F/T RING TIME sets the time for the "double-ring" in F/T mode. 10/20/30/60 seconds	20	63–64
	5. RING VOLUME	The settings are OFF/LOW/HIGH.	HIGH	72
6. TEL OPTIONS	6. DISTINCTIVE	If you have distinctive ringing service from your phone company, you can use this function to register the ringing pattern of your fax number. And if you set it to ON, you can use the registered number as a fax number only.  OFF/ON/SET	OFF	82–84
	7. CALLER ID	You can display the last 30 Caller IDs that are stored in the memory.		85–86
	1. DATE/TIME	If you enter the date and time in 24-hour format, the LCD will display the date and time and they will be printed on outgoing faxes.	01/01/1999 00:00	20
	2. DAILY TIMER	If you frequently have delayed jobs, all for execution at same time each day, you can program that time. Once you register it, you do not have to enter that time, just set Timer Transmission in temporary settings.	00:00	41
7. SETUP	3. INTERVAL	You can select the time interval at which the activity report is printed. 6/12/24 hours, 2/4/7 days, OFF	OFF	123–124
SYSTEM	4. STATION ID	You can enter your name or company name, fax number and telephone number in STATION ID.  It is printed at the top of each page of every outgoing fax, It is also printed on the automatic Cover Page.		21
	5. REMOTE CODE	If you enter a REMOTE CODE, you can activate or deactivate the MFC from a remote telephone. ON/OFF	ON *51(ACT.) #51(DEACT.)	75–76
	6. SET COVERPAGE	You can register your own two custom comments on the Cover Page.	-	51–52

Level one function	Level two function	Explanation of Options	Factory setting	Page	
7. SETUP SYSTEM	/. MF LINK	When you use the application software included into the MFC, you can select if your PC connected to your MFC will receive voice and fax messages.  ON/OFF	ON	See the Multi- Function Link Pro Online Documentation	
8. REMOTE FAX OPT	1. FAX STORAGE	You can store the incoming fax messages in the memory. Then you can use the convenient remote control functions. ON/OFF	OFF	95–96	
	2. FAX FWD/ PAGING	You can choose either PAGING, FAX FORWARDING or OFF. PAGING ON will cause the MFC to page you when it receives a fax message. FAX FORWARDING ON will cause the MFC to send any stored faxes that are received to another predetermined fax number. OFF/FAX FORWARD/PAGING	OFF	98–100	
	3. REMOTE ACCESS	You can register the REMOTE ACCESS CODE (three digits) allowing you remotely operate the MFC. (Example: Retrieving an incoming fax message)	159*	101	
	4. PRINT FAX	You can print incoming faxes that were stored in memory.		105	
O. INTERRUPT		You can send a fax without canceling the Timer or Polled Waiting, even if there are documents in the feeder, by "interrupting" it.	<u>.</u>	46	

# <2. PRINTER MENU FUNCTIONS>

Level one function	Level two function	Explanation of Options	Factory setting	Page	
1. PRINT OPTIONS	1. INTERNAL FONT	You can print resident fonts to check and confirm font types.		117	
	2. CONFIGURATION	Printer settings and status are listed here.		118	
2. RESET PRINTER	1. FACTORY SET	You can restore factory default settings and temporary settings for the printer back to factory default settings.		119	
	2. HEX DUMP MODE	If you set HEX DUMP MODE, all the PC data is printed in hexadecimal.		120	

#### Using the Help Key

Press this key to print a quick reference Help List. The Help List will tell you how to perform settings for a function, how to register information or, how to get basic information for sending or receiving faxes, copying and printing. When you don't have this Operations manual with you or when you want some information quickly, you can press **Help** to get a list of basic operating procedures.

You can request a printout whenever the MFC meets the following conditions:

- While the LCD displays the date and time.
- While the MFC is timer waiting.
- While the MFC is polled/polling waiting.
- While the MFC is at level one or two of the function menu.
- While you are using the phone.

NOTE: You cannot print the Help List while the MFC is printing data from the PC.

# How to Enter Text in Function Mode

Dial pad keys have three or four letters printed above them. The keys "0", "1", "#" and "\*" have no printed letters.



By pressing the appropriate dial pad key the correct number of times, you can access the character you want. When you are setting certain functions, such as the Station ID, you will have to enter text into your MFC.

Key	once	twice	three times	four times	five times
2	A	В	C	2	A
3	D	E	F	3	D
4	G	H	I	4	G
5	J	K	L	5	J
,6	M	N	0	6	M
7	P	Q	R	S	7
8	Т	U	v	8	Т
9	W	X	Y	$\mathbf{Z}$	. 9

Let's say that you want to enter the initials "BR". Follow the example on the next page.

#### KEYS TO PRESS

## THE DISPLAY WILL SHOW:

NAME:

ENTER & SET

NAME:B

NAME: BR

- 1. Press 2 twice to enter the letter B.
- 2. Press 7 three times to enter the letter R.
- 3. Press Set.

### FOR YOUR INFORMATION

- 1. If you want to enter a blank space, press (right arrow) twice.
- 2. If you entered a letter incorrectly and want to change it, you can use (left arrow) to move the cursor back. When you reach the letter, you can enter a new one in it's place. You can only overwrite letters, not insert them, so you may have to go back and overwrite a lot of letters if you forget to enter a letter.
- 3. If you have to enter a character that is assigned to the same dial pad key as the previous character, press (right arrow) to move the cursor to the right.

# How to Enter Special Characters, Symbols and Punctuation Marks in Function Mode

0 key ------ ÄËÖÜÀÇÈÉ0 \* key ----- (space) !"#\$%&'()\*+,-/ # key ----- ;;<=>?@[]^\_

The "0" key contains all the accented characters. The "\*" and the "#" key are used for punctuation marks and symbols. Let's say that you want to enter the Symbol "&". Follow the example on the next page.

#### KEYS TO PRESS

- 1. Press \* to show a list of characters.
- 2. Press \*, \*, \*, \*, \*, \* (six times).
- 3. Press ► (right arrow).

## THE DISPLAY WILL SHOW:

NAME: JAMES \_

MARK-\_!"#\$%&'()\*

MARK- !"#\$%&'()\*

NAME: JAMES &\_

#### How to Set the Sleep Time

The sleep mode reduces the power consumption when the MFC is idle. The time period before the machine drops into sleep mode is user selectable.

Using the dial pad, you can select the time period before the MFC drops into sleep mode (from 00 to 99 minutes).

The sleep timer is automatically reset when a fax is received, the MFC starts to copy, or the MFC is receiving PC data. The factory setting is 0 minute.

Use the following sequence to set the sleep time.

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 5.
- 5. Press 8.

### THE DISPLAY WILL SHOW:

01/01/1999 00:00 ONLINE

ENTER NO. & SET

1. FAX

2.PRINTER

1.FAX

5.USER OPTIONS

8.SLEEP MODE

SLEEP TIME: OOMIN

6. Enter sleep time (00 to 99) using dial pad. Example: 05.

SLEEP TIME: 05MIN

7. Press Set.

8.SLEEP MODE

8. Press Stop to exit.

#### NOTICE

- Sleep Mode is activated when the heater stops. However, the cooling fan will continue to run until the MFC has cooled down. The actual time before the fan stops will vary depending upon operating conditions.
- It will take approximately 12 to 30 seconds for the MFC to warm up from the sleep mode before you can start printing or copying. The LCD will show WARMING UP during this time. When it is ready it will automatically start the last job you have entered.

NOTE: The cooling fan will continue to run until the temperature of the MFC reaches a certain level. Even after the heater stops, the MFC will have to warm up before copying and printing.

#### 3. FUNCTION SETTINGS

This chapter is included in both the Setup Manual and this Operations Manual. If you read the Setup Manual first, you may have completed these function settings already. There are some settings, such as the date and time, you should set on your MFC before you begin using it. Once entered, these settings will remain in the MFC until you change them. You can begin customizing the settings by pressing **Function** on the control panel. This activates the function mode and On-Screen Programming prompts. You can complete a variety of settings in this mode.

### Setting the Dialing Mode (Tone/Pulse)

Your MFC supports both tone (multi-frequency) and pulse (rotary) dialing. It is initially set to TONE, so you do not have to change the setting if you use that kind of line. If you are using a pulse dial line, you can change the setting to PULSE by following the steps below:

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 6.
- Press 1.
   After two seconds you will be prompted to select pulse or tone.
- 7. Press Set.
- 8. Press **Stop** to return to the date and time.

#### THE DISPLAY WILL SHOW:

01/01/1999 00:00 ONLINE

ENTER NO. & SET

1. FAX

2.PRINTER

1.FAX

6.TEL OPTIONS

1.TONE/PULSE

DIALING: TONE

SELECT ← → & SET

DIALING: PULSE

1.TONE/PULSE

#### Setting the Date and Time

Your MFC shows the date and time on the display and prints it on every fax page you send. You can set the date and time in function mode.

## KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 7.
- 5. Press 1.
- 6. Enter the last two digits of the year. Example: **98**.
- 7. Enter two digits for the month. (JAN = 01, OCT = 10, etc.)
  Example: 09.
- 8. Enter two digits for the day. Example: 12.
- 9. Enter the time in 24-hour format. Example: 15:25 (3:25 P.M.).
- 10. Wait for two seconds.
- 11. Press **Stop** to exit and to view the new date and time.

# THE DISPLAY WILL SHOW:

01/01/1999 00:00 ONLINE

ENTER NO. & SET

I.FAX
2.PRINTER

1.FAX

7.SETUP SYSTEM

1.DATE/TIME

ENTER YEAR: XX

ENTER YEAR:98

ENTER MONTH: XX

ENTER MONTH:09

ENTER DAY: XX

ENTER DAY:12

ENTER TIME: XX:XX

ENTER TIME:15:25

1.DATE/TIME

09/12/1998 15:25 ONLINE

#### Setting the Station ID

The Station ID is for identification purposes. Here you can store your name, fax number, and telephone number. Your MFC prints this information on the electronic Cover Page and every fax page you send.

- The telephone number that you stored above is used only for the Call Back Message and the Cover Page features.
- If you do not enter a fax number, no additional information can be entered.
- If Station ID has been programmed, then after Step 5 the name will be displayed with the prompt "1" to change "2" to exit. Press "1" to change information. Press "2" to exit from the function.

#### KEYS TO PRESS THE DISPLAY WILL SHOW: 09/12/1998 15:25 ONLINE 1. Press Function. ENTER NO. & SET 2. Wait for two seconds. 1. FAX 2.PRINTER 1.FAX 3. Press 1. 4. Press 7. 7. SETUP SYSTEM 5. Press 4. 4.STATION ID You will be prompted to enter your fax number. FAX: **ENTER & SET** 6. Enter your fax number (up to 20 digits). FAX:4155554444\_ Example: 4155554444. 7. Press Set. TEL: You will be prompted to enter your telephone number. **ENTER & SET**

8. Enter your telephone number (up to 20 digits).

If your telephone number and fax number share the same line, enter the same number again.

Example: 4155554445.

9. Press Set.

You will be prompted to enter your name or company's name.

10. Enter your name using the dial pad (up to 20 characters).

Example: BROTHER.

By pressing the appropriate dial pad key the correct number of times, you can access the character you want. For example, press 2 twice to enter B.

Refer to the section "How to Enter Text in Function Mode" on pages 15–17.

- 11. Press Set to confirm the entry.
- 12. Press Stop to return to the date and time.

TEL:4155554445\_

NAME:

**ENTER & SET** 

NAME: BROTHER

4.STATION ID

#### NOTICE

The Telephone Consumer Protection Act. of 1991 makes it unlawful for any person to use a computer or electronic device to send any message via a telephone fax machine unless such messages clearly contain in a margin at the top or bottom of each transmitted page or on the first page of the transmission, the date and time it is sent and an identification of the business or other entity, or other individual sending the message and the telephone number of the sending machines or such business, other entity, or individual.

To program this information into your MFC, complete the steps on the previous page.

# Setting the Beeper Volume Level

If the beeper setting is LOW or HIGH, it will "beep" every time you press a key, make an error, or at the end of sending or receiving a fax.

The initial setting on your MFC for the beeper is LOW. If you do not want the beeper on, select OFF, and if you want it loud, select HIGH.

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 5.
- 5. Press 2.
- 7. Press Set.
- 8. Press Stop to return to the date and time.

#### THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

- I. FAX
- 2.PRINTER
- 1.FAX
- 5.USER OPTIONS
- 2.BEEPER

BEEPER: LOW

SELECT ← → & SET

BEEPER: OFF

2.BEEPER

# Storing the One Touch Dial Numbers

You can dial numbers automatically by storing telephone or fax numbers as One Touch dial numbers. You can also store names with the numbers so when you call, you can verify the destination by the name on the display. You can store a maximum of 24 numbers. To access numbers 13 to 24, hold down the **Shift** key. For example, One Touch location "13" is accessed by pressing **Shift** and the "01" One Touch key simultaneously. Here is how to store a telephone number as a One Touch dial number:

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 4.
- 5. Press 1.
- 6. Press the **One Touch** key where you want to store a number.

Example: One - Touch 05.

**NOTE:** The One Touch keys are <u>not</u> the keys on the dial pad.

- 7. Enter a number (up to 20 digits). Example: **14155551212**.
- 8. Press Set.

You then will be prompted to enter the name or company associated with this number.

9. Enter the name using the dial pad (up to 15 characters).
Example: NJ OFFICE.
(See pages 15–17.)

#### THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1. FAX

2.PRINTER

1.FAX

4.SET AUTO DIAL

1.ONE-TOUCH DIAL

SELECT ONE-TOUCH

\*05:

**ENTER & SET** 

\*05:14155551212\_


NAME:

**ENTER & SET** 

NAME: NJ OFFICE



- 12. Press Set.
- Return to Step 6 to enter another number, or press Stop to return to the date and time.



#### **Helpful Hints**

If you must wait for a dial tone to access an outside line, or at one or more points during a long credit card dialing sequence, you can insert a pause by pressing the **Redial/Pause** key. When you press **Redial/Pause**, a dash "-" will appear on the display. By storing the numbers with a pause, you can create a delay of 3.5 seconds.

# Storing the Speed Dial Numbers

When you store a phone or fax number as a Speed Dial number, you must enter a two-digit number, from 01 to 36 using the dial pad keys. For example, you can not enter "5". You must enter "05". You can store as many as 36 Speed Dial numbers.

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 4.
- 5. Press 2.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1. FAX
2. PRINTER

1.FAX

4.SET AUTO DIAL

2.SPEED-DIAL

SPEED-DIAL? #\_

6. Use the dial pad to enter a two-digit number.

Example: 05.

7. Enter the number (up to 20 digits). Example: **5555151**.

8. Press Set.

You will be prompted to enter the name or company associated with this number.

9. Use the dial pad to enter a name (up to 15 characters).

Example: MANCHESTER.

(See pages 15-17 for entering text.)

10. Press Set.

Example: TEL. (See page 29.)

- 12. Press Set.
- 13. You are ready to enter another Speed Dial number. Or press Stop to return to the date and time.

SPEED-DIAL? #05


#05:

ENTER & SET

#05:5555151\_

NAME:

ENTER & SET



SPEED-DIAL? #\_

**Helpful Hints** 


- Print the All Dial List to make sure you have stored the correct numbers. (See page 125.) This list will contain the type of number: FAX, TEL, F/T, or CHAIN.
- Even if there is a loss of electrical power to your MFC, the telephone and fax numbers you have stored will not be lost.
- If your MFC is connected to a PBX and you must first access an
  outside line, you must insert an additional number followed by a
  pause before the fax or telephone number to access an outside line.

# FOR YOUR INFORMATION

# When You Wish to Change the Stored One Touch and Speed Dial Numbers

When you try to set up a One Touch key or Speed Dial number that is already in use, you will be asked if you wish to change it or to exit so you can select a different One Touch or Speed Dial number. This display does not appear if the One Touch key or Speed Dial number you chose is not assigned.

 Press 1 to assign a new number to the One Touch key or Speed Dial number, or press 2 to choose a different One Touch key or Speed Dial number.



2. If you are replacing an existing number with a new one, the old number and name will appear in the display. Press Clear to erase the old number and name. Then, enter the new number and name and press Set to store the entry.

#### Memory Storage/Temporary Battery Back Up

Your MFC is equipped with an internal battery that will keep the date and time information for up to two hours after power has been cut off. After that time, the date and time will be lost and you will have to reenter the information. All other settings in the SET AUTO DIAL, USER OPTIONS and SETUP SYSTEM functions (see pages 10–13) are stored permanently until you change them and will be retained even in the event of a power failure. However, the faxes stored in the memory during Out-of-Paper Reception and Memory Transmission will be lost when the power is disconnected.

#### Setting Up Groups for Broadcasting

Groups allow you to send the same fax message to many fax numbers by pressing only one One Touch key. (This is called Broadcasting.) You must store each fax number first as a One Touch or Speed Dial number. Then you can combine the stored numbers into a Group.

You can have up to six smaller Groups (each group uses up a One Touch key) or you can assign up to 59 numbers if you want one large Group. You can use the same stored number in several groups. Groups can have a name up to 15 characters long.

#### **KEYS TO PRESS**

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 4.
- 5. Press 3.
- 6. Press the One Touch key where you wish to store the number.
  Example: select One Touch "01" as a group.
- After two seconds, enter a number for the group, using the dial pad. Example: 1.
- 8. Enter the One Touch or Speed Dial numbers in this group.
  Example: #03, #05, \*02.

NOTE: Press the Speed Dial key and dial pad keys for Speed Dial numbers, and the One Touch keys for One Touch numbers.

- 9. Press Set.
- 10. Enter the group's name. Example: **BROTHER**.

#### THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

I. FAX

2.PRINTER

1.FAX

4.SET AUTO DIAL

3.SETUP GROUPS

SELECT ONE-TOUCH

SETUP GROUP:GO

ENTER & SET

SETUP GROUP:G01

G01:

ENTER & SET

G01:#03#05\*02\_

NAME:

ENTER & SET

NAME: BROTHER

11. Press Set.

3.SETUP GROUPS

12. Press **Stop** to return to the date and time.

\*:One-Touch #:Speed Dial

**Helpful Hints** 

See pages 43–44 for Broadcasting procedure. You can print a list of all One Touch numbers and Speed Dial numbers. Group numbers will be listed under One Touch numbers. (See page 125.)

#### FOR YOUR INFORMATION

# Types of Numbers

When you store a number as a One Touch or as a Speed Dial number, you have a choice of choosing the type of number. There are four options:

- 1. FAX (A fax number)
- 2. TEL (A telephone number)
- 3. F/T (Both a fax number and a telephone number)
- 4. CHAIN (A number, usually an access code, for chain dialing).

#### Chain Dialing

Chain dialing is used to store a very long dialing sequence. You can spread the number over two or more keys if you register the first key(s) in the sequence as type "Chain." Chain tells the system that the dialing sequence is not completed and that there is more to follow. The last key in the sequence must be any other dial type (either FAX, TEL or F/T). You can use any combination of One Touch, Speed Dial and manually dialed numbers in a chain.

If you must wait for another dial tone at any point in the dialing sequence, store a pause at that point in the number by pressing the Pause/Redial key. (If you need a pause that is longer than 3.5 seconds, call Brother Customer Service Center at 1-800-284-4329 (USA), 1-800-853-6660 (from within Canada) for assistance.)

When you are ready to dial the chain number, simply press the keys one after the other in sequence and then press the **Start** key.

Chain dialing makes using access codes easy. Sometimes you may want to choose from among several long-distance carriers when you make a call; rates may vary depending upon the time and destination. To take advantage of low rates, you can store the access code of a long-distance carrier as you would a regular number and register it as a "chain" number. Then to dial, press this (access code) number followed by the regular number and Start key.

You can set up chain dialing for phone/credit card numbers, the same way. However, when using chain dialing, do <u>NOT</u> send a cover page because your credit card number will be on it.

# 4. USING THE MFC AS A TELEPHONE

Your MFC can be used to make regular telephone calls. You can dial numbers manually, by pressing the dial pad keys, or by using One Touch or Speed Dialing.

#### Manual Dialing

- 1. Pick up the handset, or press Hook.
- 2. When you hear a dial tone, you can begin dialing by pressing the dial pad keys.
- 3. If you used **Hook** to dial, pick up the handset when the call is answered.

### One Touch Dialing

- 1. Pick up the handset, or press Hook.
- 2. When you hear a dial tone, press the One Touch key.
- 3. If you used Hook, pick up the handset when the call is answered.

If you try to use a One Touch number that has not been stored on the key you pressed, you will hear a warning sound and the display will say, NOT REGISTERED. The display will return to normal after two seconds.

# Speed Dialing

- 1. Pick up the handset or press Hook.
- 2. When you hear a dial tone, press **Speed Dial** and then press the two-digit Speed Dial number.
- 3. If you used **Hook**, pick up the handset when the call is answered.

#### FOR YOUR INFORMATION

#### Using Hold, Pause, # with the Telephone

- Press Redial/Pause to insert a 3.5 second pause between numbers.
- Press Hold to put a call on hold. You can replace the handset without disconnecting the call. You must pick up the MFC's handset to release the call from Hold.
- Press # to switch the dialing type from "pulse" to "tone" temporarily. This key also is used for push-button services, such as those offered by banks, credit card companies, or paging services.

#### FOR YOUR INFORMATION

#### On Hook Dialing

When you make a call using **Hook**, you can listen to the other end through the one-way speaker of the MFC, but the other party can not hear you unless you pick up the handset. Also, if you press **Hook** again before you pick up the handset, the call will be disconnected.

# Searching the Telephone Index

Once you have stored a name and number as a One Touch number or as a Speed Dial number, you can search for that name alphabetically using the Telephone Index. You can dial a number directly from the Telephone Index.

#### KEYS TO PRESS

- 1. Press Tel-Index.
- 3. Pick up the handset, or press Hook.
- 4. Press Start to begin dialing.
  - Return the handset to its cradle or press
     Hook to cancel the call.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

TEL.INDEX ONLINE


NJ OFFICE ONLINE

NJ OFFICE ONLINE

# 5. SENDING FAXES

#### A) DOCUMENT BASICS

# The Size of Your Documents



The size of the documents you want to send by fax should not be larger (or smaller) than your MFC can accommodate. The documents should each be between 5.8 and 8.5 inches (148 and 216 mm) wide and between 3.9 and 35.4 inches (100 and 900 mm) long.


The maximum width of the scanned area, that can be printed on the recording paper of the recipient's fax, is 8.2 inches (208 mm).

# How to Insert the Document

To send a fax, first insert the document you wish to send, face down, in the document feeder. The top edge of the document should go in first, or the fax will be received upside down.

To prevent the document from skewing as it is fed, adjust the paper guides to fit the width of the document.





#### The Auto Document Feeder (ADF)

The Auto Document Feeder (ADF) automatically feeds documents (**up to 30 pages**) into the MFC, one at a time. The thickness and weight of the documents should fall into the following categories:

Thickness: For one sheet:  $2.8 \times 10^3$  to  $4.7 \times 10^3$  inches (0.07 to 0.12 mm). For multiple sheets:  $2.8 \times 10^3$  to  $3.9 \times 10^3$  inches (0.07 to 0.10 mm).

Weight: For one sheet:  $0.07 \times 10^3$  to  $0.121 \times 10^3$  lbs/inch<sup>2</sup> (52 to 85 g/m<sup>2</sup>). For multiple sheets:  $0.07 \times 10^3$  to  $0.114 \times 10^3$  lbs/inch<sup>2</sup> (52 to 80 g/m<sup>2</sup>).

As a reference, please note that the paper used for this manual has the following thickness and weight:

Thickness:  $3.1 \times 10^{-3}$  inches (0.08 mm) Weight:  $0.091 \times 10^{-3}$  lbs/inch<sup>2</sup> (64 g/m<sup>2</sup>)

Before inserting documents into the document feeder, fan the sheets of paper to make sure the documents are not stuck together. Then tap the leading edge on a flat surface so all the pages are even when placed in the feeder. Make sure you always place the documents in face down.

# Getting Ready to Send a Fax

Setting the Resolution (Temporary Setting)

You can choose a setting (STANDARD, FINE, SUPERFINE, or PHOTO) for the resolution any time before you press **Start** or **Copy**. You can choose a setting by pressing the **Resolution** key. (o means light off. W means light on.)

STANDARD	O Fine Photo O S.Fine	The STANDARD resolution can be used for most typewritten text. When the STANDARD setting is on, both lights are off. Transmission speed is normal.
FINE	Fine Photo S.Fine	The FINE resolution is an ideal setting to use if you want to send documents that have small print. When the FINE setting is on, the FINE light will be lit. Transmission speed is slower than STANDARD.
SUPERFINE	O Fine Photo S.Fine	The SUPERFINE resolution is a good setting to use for documents with very small print or artwork. When the SUPERFINE setting is on, the S. FINE light will be lit. Transmission speed is slower than FINE.
РНОТО	Fine Photo S.Fine	The PHOTO resolution is ideal for sending documents that have varying shades of gray, such as photographs. The PHOTO setting is on when both lights are lit. Transmission speed is slower than FINE.

To set different resolutions for each page of a multipage document, refer to "Multiple Resolution Transmission" on pages 49–50.

#### Setting the Contrast (Temporary Setting)

The MFC has automatic contrast control, but if you are sending or copying a document that is very light or very dark, you may want to set the contrast yourself.

Use SUPER LIGHT to send a very light document. Use SUPER DARK to send a very dark document.

# KEYS TO PRESS

- 1. Insert the documents face down into the feeder.
- 2. Press Function.
- 3. Wait for two seconds.
- 4. Press 1.
- 5. Press 1.
- 6. Press 4.
  The display will alternate messages.
- 7. Use (left arrow) or (right arrow) to select one of the settings, AUTO, S.LIGHT, or S. DARK. Example: S.LIGHT.
- 8. Press Set.
- 9. Press Stop to exit.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

FAX: NO. & START SCAN READY

COPY: PRESS COPY SCAN READY

ENTER NO. & SET

1. FAX
2.PRINTER

1.FAX

1.TEMP.SETTINGS

4.CONTRAST

CONTRAST: AUTO

SELECT ← → & SET

CONTRAST: S. LIGHT

4.CONTRAST

FAX: NO. & START ONLINE

COPY: PRESS COPY ONLINE

Then start the fax sending operation (see page 37) or copy (see page 129).

#### B) BASIC FAX TRANSMISSIONS

#### FOR YOUR INFORMATION

#### Sending a Fax

There are three basic ways to send a fax:

#### 1) Manual transmission:

You can talk or listen to the other party before you send a fax by picking up the handset and dialing the number. After the other party has finished talking and has pressed the **Start** button, you will be able to send your fax by pressing your **Start** key and placing the handset in its cradle. (If you call and all you hear is the chirping sound of a fax machine, you can go ahead and press your **Start** key, and then replace the handset.)

#### 2) Automatic transmission:

You can send a fax without picking up the handset or without pressing **Hook** by dialing the fax number and then pressing **Start**.

- a. One Touch Dialing
  - Press one of the One Touch keys. (The numbers must be stored beforehand. See pages 24–25.) Then press **Start**.
- b. Speed Dialing
  - Press **Speed Dial**, then use the dial pad to enter a two-digit number. For example, press **05** for five. (The numbers must be stored beforehand. See pages 25–26.) Then press **Start**.
- c. Telephone Index

You can use Tel-Index to make telephone or fax calls. (See page 32.)

# 3) Delayed transmission:

It is possible to send documents at a later time by using the TIMER function. (See pages 42–43.)

#### Talking to the Other Party When Sending a Fax

When you are sending a fax manually and you hear the recipient's voice instead of fax tones, you can use the handset to have a conversation. If you want to then send a fax, ask the other party to press **Start** and when you hear fax tones you can press **Start** to begin sending your fax.

# Sending a Fax Automatically

#### KEYS TO PRESS

- 1. Insert the documents face down into the feeder.
- 2. Enter a fax number. Example: One Touch dialing.
- 3. Press Start.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

FAX: NO. & START SCAN READY

COPY: PRESS COPY SCAN READY

NJ OFFICE ONLINE

DIALING ONLINE

SENDING P.01 ONLINE

# Sending a Fax Manually

#### KEYS TO PRESS

- 1. Insert the documents face down into the feeder.
- 2. Pick up the handset or press **Hook** and listen for the dial tone.
- 3. Enter the fax number. You can use manual dialing, One Touch dialing, Speed Dialing, or Tel-Index.
- When you hear a fax tone, press Start.
   Your MFC will begin sending the documents.
- Return the handset to its cradle, if you did not use **Hook**.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

FAX: NO. & START SCAN READY

COPY: PRESS COPY SCAN READY

ENTER FAX NO. ONLINE

PRESS START KEY ONLINE

NJ OFFICE ONLINE

SENDING ONLINE

# Automatic and Manual Redialing

If a number you have dialed is busy or your call did not go through for some other reason, you can redial that number. There are two ways to redial: "automatic" and "manual." Automatic redialing can be used only for faxes that were sent using automatic transmission—not for telephone calls. The MFC automatically will redial the number 3 times at 5 minute intervals before giving up. It will redial the last dialed number when you press **Redial/Pause** (manual redialing).


#### FOR YOUR INFORMATION

#### Optional Settings When You Send a Fax Manually

- Resolution (See pages 35, 49-50.)
- Contrast (See page 36.)
- Cover Page (See pages 50-55.)
- Overseas Mode (See page 48.)
- Call Reservation (See pages 56-57.)

#### **Printing Page Headers**

Your MFC can print a page header on the top of every fax you send. It is printed on the receiving party's fax paper. It contains the date and time of transmission, your fax number and name (Station ID), and page number. Of course you must register your Station ID beforehand for that information to be available. (See pages 21–22.)



#### C) ADVANCED FAX TRANSMISSIONS

# Sending a Fax by Using Super Quick-Scan (Memory Transmission)

If you are faxing a set of documents that are confidential in nature or you just need your original documents back right away, you do not have to stand at the MFC and wait for the transmission of each page to be completed. You can use **Super Q.Scan** in order to get your original documents back before transmission.

#### KEYS TO PRESS

- 1. Insert the documents into the feeder.
- Press Super Q.Scan.
   The display will indicate how much memory is available.
- 3. Enter the fax number.
- Press Start to begin scanning the documents into memory. Once completed, the MFC will dial the destination.

# THE DISPLAY WILL SHOW:

	09/12/1998 15: ONLINE	25
اے	FAX: NO. & STA SCAN READY	RT
•	COPY: PRESS CO SCAN READY	PY
	MEMORY 10 ONLINE	0%
•	ENTER FAX NO. ONLINE	
	NJ OFFICE ONLINE	
	MEMORY 10 ONLINE	0%

#### FOR YOUR INFORMATION

If You Get a MEMORY FULL Message When Trying to Send a Fax by Using Super Quick-Scan

If the memory becomes full when scanning page 1 and the display shows PRESS STOP KEY, then press **Stop** to abort the job.

If the memory becomes full on page 2 or more of a multipage document, you will be prompted to press **Start** to send the portion already scanned, or to press **Stop** to abort the job.

# Setting the Daily Timer (for Delayed Transmissions)

The Daily Timer function lets you send a fax at a preset time every day. This is handy for sending delayed jobs that must go out at the same time daily. Once you enter the time, you don't have to enter it again. The setting will stay the same until you change it. So you can use it every day, or only on days when you need it.

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 7.
- 5. Press 2.
- Enter the time in 24-hour format using the dial pad.
   Example: 19:45 (7:45 P.M.).
- 7. Wait for two seconds, press Stop to exit.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1. FAX
2.PRINTER

1.FAX

7.SETUP SYSTEM

2.DAILY TIMER

ENTER TIME: 00:00

ENTER TIME:19:45

2.DAILY TIMER

# Delayed Transmission (Temporary Setting)

You can use the timer to send documents at a later time (up to 24 hours later). When the preset time is displayed, accept it or enter a new time if needed. Your MFC also will produce a report, the "Delayed Sending Report," after the fax is sent. You can set up to three different documents for delayed transmission.

#### KEYS TO PRESS THE DISPLAY WILL SHOW: 09/12/1998 15:25 ONLINE 1. Insert the documents into the feeder. FAX: NO. & START SCAN READY COPY: PRESS COPY SCAN READY 2. Press Super Q.Scan if you use memory MEMORY 100% transmission, or you can send your fax ONLINE normally. ENTER FAX NO. ONLINE 3. Press Function. ENTER NO. & SET 4. Wait for two seconds. I.FAX 2.PRINTER 5. Press 1. 1.FAX 6. Press 1. 1.TEMP.SETTINGS 7. Press 1. 1.TIMER SET TIME=<u>0</u>0:00 8. Accept the displayed time or enter the time SET TIME=19:45 in 24-hour format using the dial pad. Example: 19:45 (7:45 P.M.). 9. Wait for two seconds. 1.TIMER ENTER FAX NO. 10. Press Stop. ONLINE MEMORY 100% ONLINE 11. Enter the fax number. NJ OFFICE ONLINE

12. Press Start.

The MFC will wait until the specified time to call.

09/12/1998 15:25 ONLINE

# Broadcasting

By using the numbers you have stored for One Touch dialing, Speed Dialing, or Group dialing, you can send faxes automatically to a maximum of 60 numbers at once. Remember, each Group you created uses up one of the One Touch keys. You cannot broadcast to a number that has not been stored into memory. Use the Telephone Index to help you choose the numbers to which you wish to broadcast. (See page 32.) After transmission is completed, a Broadcast Report will be printed automatically to let you know the results.

#### FOR YOUR INFORMATION

#### Getting Familiar with the Broadcasting Function

- \* To stop the broadcast in progress, press **Stop**.
- \* Enter the chain dialing numbers as you normally would, but keep in mind that each key counts as one location, so the number of locations you can call becomes limited. (You have up to 59 locations you can call with One Touch, Speed Dialing, and group numbers.)
- \* If the line is busy or for some other reason a connection could not be made while broadcasting, the MFC will redial the number automatically. (See page 39.)
- \* If the memory is full, press **Stop** to abort the job or press **Start** to send the portion that is in the memory (if more than one page has been scanned.) (See page 40.)

#### KEYS TO PRESS

1. Insert the documents into the feeder.

# THE DISPLAY WILL SHOW:

09/12/1998 15.25 ONLINE

FAX: NO. & START SCAN READY

COPY: PRESS COPY SCAN READY

- 2. Press Super Q.Scan.
- Enter the One Touch key(s) and/or Speed Dial number(s), one after the other, or a Group number.
   Example: Group number.
- Press Start and the MFC will read the documents into memory, and then start sending faxes to all the numbers you entered.

(	MEMORY	100%	)
_ (	ONLINE		J_
-	ENTER FAX ONLINE	NO.	) /
	BROTHER ONLINE		

MEMORY ONLINE	100%
DIALING ONLINE	
SENDING ONLINE	P.01

#### Sending by Multiple Transmissions

Use this function to send several different faxes to several destinations at once. For example, you can automatically fax "Document A" to one destination and "Document B" to another destination.

This is not to be confused with Broadcasting, which is sending the same document(s) to many destinations.

If you wish, you can combine this function with broadcasting so you can fax different documents to different lists of people at the same time. To do this, store various sets of documents in memory. Then automatically your MFC will fax "Document A" to one list of people and "Document B" to another list of people. You can preset three different documents (including timer transmission) in memory; if you set one timer transmission, multiple transmissions are available for two other destinations.

If you press only **Super Q.Scan** instead of **Shift + Super Q.Scan** for the last document, your MFC will start dialing without waiting for 30 seconds.

#### KEYS TO PRESS

1. Insert "Document A" into the feeder.

#### THE DISPLAY WILL SHOW:

09/12/1998 15:25
ONLINE

FAX: NO. & START
SCAN READY

COPY: PRESS COPY
SCAN READY

- Press Shift + Super Q.Scan together to send by multiple transmission.
   The display shows remaining memory.
- 3. Enter the fax number. (Or enter a series of numbers if you are broadcasting.)
- 4. Press Start to start scanning documents.
- 5. Insert "Document B" within 30 seconds after "Document A" has been scanned. (If you wait more than 30 seconds to scan another document, the MFC will begin to send document "A.") Repeat Step 2, 3, 4 for document "B".
- 6. Repeat Step 1, 2, 3, 4 for document "C".
- 7. After 30 seconds, your MFC will start sending the documents.

MULTI TX 100% ONLINE	\
ENTER FAX NO. ONLINE	)
NJ OFFICE ONLINE	
MULTI TX 100% ONLINE	
09/12/1998 15:27 ONLINE	
ENTER FAX NO. ONLINE	١
PRESS START KEY ONLINE	,

MULTI TX	70%
ONLINE	
DIALING	
ONLINE	

# Interrupting the Timer and Polled Job

You can send a fax without canceling the timer (see pages 42–43) or Polled Waiting with documents in the feeder (see pages 91–92) by "interrupting" it. When you interrupt the Timer to send a "new" set of documents, the MFC will not redial the number automatically if it was busy. Also, you can not use the function mode if you have interrupted the Timer or Polled Waiting: For example, TIMER WAITING with a document in the feeder.

KEYS TO PRESS	THE DISPLAY WILL SHOW:
	(TIMER WAITING ONLINE
1. Press Function.	ENTER NO. & SEI
2. Wait for two seconds.	1. FAX 2. PRINTER
3. Press 1.	1.FAX
4. Press <b>0</b> .	0.INTERRUPT
5. Wait for two seconds.	REMOVE DOCUMENT ONLINE
6. Remove documents from the MFC.	INSERT DOCUMENT ONLINE
7. Place the "new" documents into the feeder.	FAX OR COPY ONLINE
	FUNC 10 TO RESET ONLINE
8. Enter the new fax number for the documents you are sending now, then	DIALING ONLINE
press <b>Start</b> .	SENDING P.01 ONLINE
9. After the transmission is finished, place the "old" documents back into the feeder.	INSERT DOCUMENT ONLINE
	FAX OR COPY ONLINE
	FUNC 10 TO RESET ONI THE
10. Press Function and 1 and 0 to restore the timer.	0.INTERRUPT
	TIMER WAITING ONLINE

Use the Cancel Job function to permanently remove scheduled tasks such as Polling or Polled Waiting (see pages 91–92) and Timer (Delayed Transmission) (see pages 42–43) from your MFC.

Example: TIMER WAITING with documents in the feeder.

### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 2.

Any waiting jobs that have been set up will appear in the display.

If no jobs are waiting to be processed, a NO JOB WAITING message will appear in the display.

- 5. Use (left arrow) or (right arrow) to select the job you wish to cancel.
- 6. Press Set.
- Press 1 to cancel the selected job, or 2 to exit without canceling.
   If 1 is selected, the job will be canceled and the next job in the queue will appear
- 8. To cancel the next job, press 1 again. To exit, simply press 2.
- 9. Press Stop to exit.


in the display.

# THE DISPLAY WILL SHOW:

TIMER WAITING
ONLINE

ENTER NO. & SET

The second of the s



2.CANCEL JOB

#### D) FAX TRANSMISSION OPTIONS

# Setting the Overseas Mode (Temporary Setting)

If you experience difficulty with sending faxes overseas, you may want to use the Overseas mode. Using the Overseas mode is an effective way to send faxes overseas.

#### KEYS TO PRESS

- 1. Insert the documents into the feeder.
- 2. Press Function.
- 3. Wait for two seconds.
- 4. Press 1.
- 5. Press 1.
- 6. Press 6.
- 7. Press (left arrow) or (right arrow) to switch to ON.
- 8. Press Set.
- 9. Press Stop to exit.
- 10. Then start the fax sending operation. (See page 38.)

After sending your fax, the overseas mode will switch itself OFF.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

FAX: NO. & START SCAN READY

COPY: PRESS COPY SCAN READY

ENTER NO. & SET

1. FAX

2.PRINTER

1.FAX

1.TEMP.SETTINGS

6. OVERSEAS MODE

OVERSEAS: OFF

SELECT ← → & SET

OVERSEAS: ON

6.OVERSEAS MODE

ENTER FAX NO. ONLINE

PRESS START KEY ONLINE

This is a temporary setting for the current transmission job only. You can set the resolution of the documents you send by pressing **Resolution**. Once you set the resolution, all the pages will be sent at the same resolution. However, there may be times when you want to send some pages at one resolution, such as STANDARD, and other pages in another resolution, such as PHOTO. If you send all pages in Photo resolution, for instance, it would take a great deal of time. It is better to specify the resolution for each page to minimize transmission time. This is made possible by using the 1.TEMP. SETTINGS function.

#### KEYS TO PRESS

- 1. Insert the documents into the feeder.
- 2. Press Function.
- 3. Wait for two seconds.
- 4. Press 1.
- 5. Press 1.
- 6. Press 5.
- 7. Press (left arrow) or (right arrow) to find the resolution you want for the first page of your documents.

  Example: FINE.
- Press Set.
   Return to Step 6 to set the resolution for page 2 and the following pages.

### THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

FAX: NO. & START SCAN READY

COPY: PRESS COPY SCAN READY

ENTER NO. & SET

1. FAX

2.PRINTER

1.FAX

1.TEMP.SETTINGS

5.RESOLUTION

PAGE 01:STANDARD


SELECT ← → & SET

PAGE 01:FINE

PAGE 02:FINE

Sending PAX

9. When you finish setting the resolution for all your pages, press **Stop**.




- 10. Enter the fax number.
- 11. Press Start.

The resolution will revert to STANDARD after the documents have been sent.

#### Sending a Fax with an Electronic Cover Page Message

An automatic Cover Page will allow you to send details of who the fax is going to, who it is from and when it was sent. This is what the Cover Page looks like:



- (1) The "TO" information comes from the One Touch or the Speed Dial memory. If you are dialing manually, the name of the destination will be left blank.
- (2) The "FROM" information comes from the Station ID.
- (3) The number of pages you are sending. When Cover Page is sent each time by using the automatic settings (see pages 53–54), the number of pages will be left blank. If you have used the temporary Cover Page setting (see pages 54–55), the number of pages you entered will be listed.
- (4) Your comments. You may customize the comments (see pages 51-52).

# Sending FAX

#### FOR YOUR INFORMATION

#### Selecting a Comment for the Cover Page

You can choose one comment from among six options. The first option is to send no comment at all. The next three are built-in comments, and the last two are ones you can enter yourself. (For more information see below, "Customizing Your Cover Page Comment").

- 1. COMMENT OFF
- 2. PLEASE CALL
- 3. URGENT
- 4. CONFIDENTIAL
- 5. (Your own customized comment up to 27 characters.)
- 6. (Your own customized comment up to 27 characters.)

# Customizing Your Cover Page Comment

You can customize the comment on your Cover Page as follows:

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 7.
- 5. Press 6.
- Press (left arrow) or (right arrow) to select 5 or 6 where you wish to store a comment. Example: 5.

### THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

I.FAX 2.PRINTER

1.FAX

7.SETUP SYSTEM

6.SET COVERPAGE

5

SELECT ← → & SET

5.

#### DEINLAING FAXED: FAX TRANSMISSION OPTIONS

- 7. Press Set.
- 8. Enter your customized comment using the dial pad (up to 27 characters). (See pages 15–17 for more details.) Example: TOP SECRET.

9. Press Set.

10. Press **Stop** to exit.

5.\_

5.TOP SECRET

6.SET COVERPAGE

# Printing a Sample Cover Page

You can print a sample Cover Page to check the format.

# KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 3.
- 5. Press 4.
- 6. Press Start.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1.FAX 2.PRINTER

1.FAX

3. PRINT REPORTS

4.COVERPAGE

PRESS START KEY

PRINTING

### To Always Send a Cover Page

If you often send an automatic Cover Page, you can set it to ON to avoid having to set up the details of the Cover Page each time. Here is how you can switch the setting for the automatic Cover Page to ON (or OFF):

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 5.
- 5. Press 3.
- 7. Press Set.
- 9. Press Set.
- 10. Press Stop to exit.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

[].FAX 2.PRINTER

1.FAX

5.USER OPTIONS

3.COVERPG ON/OFF

COVERPAGE: OFF

SELECT ← → & SET

COVERPAGE: ON

1.COMMENT OFF

SELECT ← → & SET

2.PLEASE CALL

3.COVERPG ON/OFF

Sending BAX

# FOR YOUR INFORMATION

#### Sending an Automatic Cover Page

If you have the Cover Page ON/OFF setting to ON, the total number of pages will not be printed on the Cover Page. Also, the comment you selected when you set it to ON will be printed on all the Cover Pages you send.

# Sending a Fax When the Cover Page Is ON

#### KEYS TO PRESS

- Insert the documents into the feeder.
   The display will say COVERPAGE ON for one second.
- 2. Enter the fax number.
- Press Start.
   Your MFC will begin transmitting the Cover Page and original document.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

COVERPAGE ON SCAN READY

FAX: NO. & START SCAN READY

COPY: PRESS COPY SCAN READY

NJ OFFICE ONLINE

SEND COVERPAGE ONLINE

SENDING P.01 ONLINE

# Sending a Cover Page (Temporary Setting)

# KEYS TO PRESS

- 1. Insert the documents into the feeder.
- 2. Press Coverpage.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

FAX: NO. & START SCAN READY

COPY: PRESS COPY SCAN READY

1.COMMENT OFF ONLINE

SELECT ← → & SET ONLINE 2.PLEASE CALL ONLINE

4. Press Set.

TOTAL PAGES? :00
ONLINE

Enter the number of pages you are sending. (Enter 00 to leave the number of pages blank.) TOTAL PAGES? :02 ONLINE

6. Wait for two seconds.

ENTER FAX NO. ONLINE

7. Enter the fax number.

PRESS START KEY ONLINE

NJ OFFICE ONLINE

8. Press Start.

SEND COVERPAGE ONLINE

SENDING P.01 ONLINE

# **Helpful Hints**

- Even if the Cover Page ON/OFF setting is ON, you can avoid sending an automatic Cover Page by pressing **Coverpage** once to turn off the Cover Page for that transmission.
- If you want the total number of pages sent to be printed on the cover page, press **Coverpage** once to set the COVERPAGE ON/OFF option to OFF. Then press **Coverpage** once again and enter the number of pages. (See pages 53-54.)

# Sending a Fax with Call Reservation (Temporary Setting) (Talking to the receiving party after fax transmission)

You can send a fax and then talk to the recipient using the Call Reservation feature. After your fax has been printed on the receiving end, the receiving fax machine will ring as if it were receiving a telephone call. If the recipient picks up the handset, your MFC will ring. Then you can pick up your handset and start a conversation. If you have both Call Reservation and Call Back Message set to ON and the recipient does not pick up the handset when it rings, your MFC will leave a fax message asking the recipient to call you.

#### FOR YOUR INFORMATION ...

#### Using the Call Reservation Function

- There are some fax machines that will not respond to this function.
- When you use auto redialing, you cannot use the Call Reservation function, but if Call Back Message is ON, your MFC will leave a Call Back Message asking the other party call you.
- You cannot use Call Reservation with the Delayed Transmission or with the Polling function.
- You must register your Station ID number to turn Call Back Message: ON. (See pages 21-22.)

#### KEYS TO PRESS

- 1. Insert the documents into the feeder.
- 2. Press Function.
- 3. Wait for two seconds.
- 4. Press 1.
- 5. Press 1.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

FAX: NO. & START SCAN READY


COPY: PRESS COPY SCAN READY


ENTER NO. & SET

I.FAX 2.PRINTER

1.FAX

1.TEMP.SETTINGS






13. Press Start.

11. Press Stop.

14. Pick up your handset if it rings.

FROM:



ENTER FAX NO.

PRESS START KEY

ONLINE

ONLINE

NJ OFFICE ONLINE

PLEASE CALL AT [TEL] 4155554445

**BROTHER** 

## Printing the Call Back Message

You can print a sample Call Back Message to check the format.

# KEYS TO PRESS THE DISPLAY WILL SHOW: 09/12/1998 15:25 ONLINE 1. Press Function. ENTER NO. & SET 2. Wait for two seconds. 1. FAX 2.PRINTER 3. Press 1. 1.FAX 4. Press 3. 3.PRINT REPORTS 5. Press 5. 5.CALL BACK MSG PRESS START KEY 6. Press Start. PRINTING

#### ECM (Error Correction Mode)

The Error Correction Mode (ECM) is a way for the MFC to check the integrity of a fax transmission while it is in progress. ECM transmissions are possible only between machines that both have the ECM feature. If they do, you may send and receive fax messages that are continuously checked for their integrity.

Sufficient memory must be available in your MFC for this feature to work.

#### Error Retransmission

Error Retransmission is helpful when the receiving machine does not have ECM. Even though your MFC cannot check the integrity of the message, it will send the affected page(s) again after occurrences of accidental noise have caused an error.

This feature is available only for memory transmission using Super Q.Scan (see pages 40, 42~45).

# KEYS TO PRESS THE DISPLAY WILL SHOW: 09/12/1998 15:25 ONLINE 1. Press Function. ENTER NO. & SET 2. Wait for two seconds. 1. FAX 2.PRINTER 3. Press 1. 1.FAX Sending FAX 4. Press 5. 5.USER OPTIONS 5. Press 4. 4.ERROR RE-TX ERROR RE-TX:OFF SFLECT ← → & SFT ERROR RE-TX:ON to choose either ON (or OFF). Example: ON. 4.ERROR RE-TX 7. Press Set.

#### Next-FAX Reservation

8. Press Stop to exit.

You can use Next-FAX Reservation for sending a fax when the MFC is busy receiving or transmitting from memory. This function saves you from having to wait until the incoming fax has printed or the fax stored in memory has finished transmission. To use the Next-FAX Reservation feature, insert the documents as you normally would and follow a few other simple steps.

#### FOR YOUR INFORMATION

- Next-FAX Reservation cannot be used when there are documents in the document feeder awaiting Delayed Transmission or Polled Waiting or when the Interrupt function is in use.
- When you are making a call using Next-FAX Reservation, you can dial manually, or use One Touch, Speed Dial, Redial, or Chain dialing. However, when you use One Touch dialing, the screen will display only the number of the One Touch number you are using, such as "\*01" and not the name of the person you are calling. Similarly, if you use Speed Dialing, the screen will show you only the Speed Dial number, such as "#02".
- You can set the resolution for Next-FAX Reservation by pressing Resolution, but you cannot change any settings using the Function key. (For example, you cannot change a setting for multiple resolution transmission by using function mode.)
- To cancel a Next-FAX Reservation, remove the documents and press Stop.

# **KEYS TO PRESS**

- 1. Insert the documents into the feeder.
- 2. Enter a fax number.
- 3. Press Start.
- 4. Press Set.

#### THE DISPLAY WILL SHOW:

RECEIVING P.01 ONLINE

ENTER No & START SCAN READY

14155551234 ONLINE

PRESS SET ONLINE

NEXT-FAX RESERVD ONLINE

09/12/1998 15:25 ONLINE

DIALING ONLINE

- If a One Touch or Speed Dial number is selected that is not stored, a warning beep will sound.

# 6. RECEIVING FAXES AND OTHER CALLS

#### A) BASIC SETUP TO RECEIVE FAXES

#### Selecting an Answer Mode

There are four different answer modes for your MFC. You may choose the mode that best suits your needs by pressing the Mode button repeatedly until you have changed the Fax and F/T lights to the setting you want to use. For more detailed information about a particular mode, please refer to the page number in the right column.

NOTE: The lighted indicators mean o = not selected  $\leq$  = is selected and lit

Mode	Light	How it works	When to use it	Page #
1. Manual (manual receive)	O FAX	You control the phone line and must answer every call yourself.	Use this mode when you are using a computer modem on the same line or if you receive very few fax messages. You can also use this mode with Distinctive Ringing.	62
2. Fax (automatic receive)	Fax TAD O F/T	The MFC automatically answers every call as a fax.	For dedicated fax lines. You cannot receive a voice call but you can call out.	62
3. F/T (Fax/Telephone)	O Fax - TAD F/T	The MFC controls the line and automatically answers every call. If the call is a fax it will receive the fax. If the call is not a fax it will ring (double ring) for you to pick up the call.	This mode is for when you are not using an answering machine. You cannot have an answering machine on the same line, even if it is on a separate jack on the same line. You cannot use the telephone company's Voice Mail in this mode.	63
4. TAD (External Telephone Answering Device or machine)	Fax TAD F/T	The answering machine controls the phone line and answers every call. As soon as the TAD answers, the MFC listens for fax tones. If it hears then it will take over the call and receive the fax message.	You must have an external answering machine plugged into the MFC for this mode to work properly. It will not work with the telephone company's Voice Mail services. The TAD mode can be set so you have time to answer calls before the TAD picks up. You do not have to change modes when you are in or out.	76

\*NOTE: • In TAD mode the Ring Delay and F/T Ring Time settings on the MFC do not apply! The number of rings is set on the external answering machine, which overrides the settings on the MFC.

In F/T mode you must cet the Ring Delay and F/T Ring Time. If you have extension phones on the line, set the Ring Delay to four rings.

# Manual Reception (Manual Mode)

When you set the Answer Mode to manual, you must answer each incoming call yourself. Here is what you should do when using Manual Mode:

If You Get a	Then You Should	
1. Regular phone call	Talk as you normally would.	
2. Phone call and request to send a fax	Press <b>Start</b> when finished talking, and replace the handset. <b>NOTE:</b> Sender must also press <b>Start</b> .	
3. Fax tone	Press Start, and replace the handset.	

#### Automatic Fax Only Reception (Fax Mode)

You can automatically receive all your faxes in Automatic Fax Reception mode (Fax light is on). Select this mode by pressing **Mode**.

#### Setting the Ring Delay

You can set the number of rings before the MFC will answer the line. You can set 00 to receive incoming faxes without rings,

# KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 6.
- 5. Press 2.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

- 1.FAX
- 2.PRINTER
- 1.FAX
- 6. TEL OPTIONS
- 2.RING DELAY

RING DELAY:02

SELECT ← → & SET

RING DELAY:00


7. Press Set.

2.RING DELAY

8. Press Stop to exit.

# The F/T Switch (Fax/Telephone Mode)

When you share one line for your telephone and fax application, in the F/T switch mode, the MFC can determine whether an incoming call is a fax or a telephone call. (See Chart below.)



NOTE: The caller may hang up, but the F/T ringing will continue for 10-60 seconds.

# Setting the F/T Ring Time

You can specify the maximum time you want the MFC to ring (double ring) to notify you after it has answered a telephone call. There are four predefined settings: 10, 20, 30, or 60 seconds. During this time, only the MFC will ring. No other phones on the same line will ring.

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 6.
- 5. Press 4.
- 7. Press Set.
- 8. Press Stop to exit.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

FAX
 PRINTER

1.FAX

6.TEL OPTIONS

4.F/T RING TIME

RING TIME: 20 SEC

SELECT ← → & SET

RING TIME: 10 SEC

4.F/T RING TIME

The smoothing feature enhances the appearance of incoming faxes by making the lines smooth and takes no additional time. This function does not apply to outgoing faxes, or to lists or reports you print. The initial setting is ON.

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 5.
- 5. Press 1.
- 7. Press Set.
- 8. Press Stop to exit.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1.FAX
2.PRINTER

1.FAX

5.USER OPTIONS

1.SMOOTHING

SMOOTHING: ON

SELECT ← → & SET

SMOOTHING: OFF

1.SMOOTHING

Receive PAX

#### Setting the Size of the Paper

There are three different settings for the size of the printing paper. The MFC automatically will reduce and print the incoming data according to this setting of the size of the paper in the cassette.

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 5.
- 5. Press 6.
- 7. Press Set.
- 8. Press 1 to go to the REDUCTION setting in Function, 1, 5, 5. (See pages 67–68.)
- 10.Press Set.
- 11. Press Stop to exit.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1.FAX
2.PRINTER

1.FAX

5.USER OPTIONS

6.RCD PAPER

RCD PAPER: LETTER

SELECT ← → & SET

RCD PAPER: LEGAL

CHANGE REDUCT ?

1.YES 2.NO

REDUCTION: AUTO

SELECT ← → & SET

REDUCTION: AUTO

6.RCD PAPER

#### NOTICE

Regardless of the actual size of the paper, the MFC will calculate the reduction ratio by this setting. So when you change the size of the paper in the cassette, you must also change this setting to get the correct reduction. Your MFC can be set to receive incoming fax documents on only letter, legal or A4 paper.

#### Printing a Reduced Size Copy of the Incoming Document

You can avoid separating data even if the document is longer than the paper by using this function to print a reduction of the document. There are two types of reduction: Auto Reduction and Fixed Reduction.

#### **Auto Reduction**

Regardless of the original size of the incoming document, it will be reduced so that it fits on one page of paper in your cassette. The MFC will automatically calculate the reduction ratio by taking into account the size of the incoming document and the size of the paper you selected in **Function**, 1, 5, 6. (See page 66.)

#### **Using Fixed Reduction Ratios**

You can choose to have incoming documents reduced at a fixed reduction ratio, regardless of the size of the paper. The reduction ratio can be selected from among four choices: 100%, 93%, 87%, or 75%.

# **KEYS TO PRESS**

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 5.
- 5. Press 5.

#### THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

①.FAX 2.PRINTER

1.FAX

5.USER OPTIONS

5.REDUCTION

REDUCTION: AUTO

SELECT ← → & SET

6. Press (leftarrow) or (rightarrow) to select the reduction ratio you want:

- If you want Auto Reduction, choose "AUTO".
- Choose 93%, 87%, or 75% if you want Fixed Reduction.

Example: 93%

- Choose 100% if you want to record the same size.
- 7. Press Set.

5.REDUCTION

REDUCTION: 93%

8. Press Stop to exit.

#### NOTICE

- You can use Auto Reduction to reduce incoming documents to fit on one
  page of paper, only as long as the original document is not longer than
  legal size. If the original is longer than legal size, the data will not be
  reduced (see "For Your Information," below) and will carry over to print
  on a second page.
- When you use Auto Reduction and you receive an incoming document that is smaller than your paper, no reduction will take place.
- When selecting Fixed Reduction, you must consider the size of the paper as registered in **Function**, **1**, **5**, **6**. (See page 66.) If you selected letter size, you can choose a reduction of 93%, 87%, or 75%. If you selected A4 size, you can choose a reduction of only 93% or 87%. And if you selected legal size, you can choose only 93%.

# FOR YOUR INFORMATION

#### Selecting the Ratios of Fixed Reduction

Other party sends you a document the size of	Your paper size is:	Recommended Reduction Ratio is:
Letter document (8.5"x11")	Letter	93%
(mostly domestic communications)	A4, Legal	100%
A 4 4 4 6 10 10 10 10 10 10 10 10 10 10 10 10 10	Letter	87%
A4 document (8.2"x11.6") (mostly international communications)	A4	93%
(mostly linemational communications)	Legal	100%
Legal documents (8.5"x14")	Letter	75%
Legal documents (6.5 x14 )	Legal	93%

# Reception into Memory (Out of Paper Reception)

If the multi-purpose sheet feeder is empty, the LCD will display the message CHECK PAPER. Add more paper.

Your MFC automatically will store incoming faxes in its memory if it runs out of paper. The contents of the memory will be printed automatically when you replace the paper. The memory will not be lost as long as you do not turn off the MFC or disconnect the power.

# Setting the Print Density

You can set print conditions with the following steps. Press — (left arrow) to make the print lighter and — (right arrow) to make the print darker. If the print is still too light or too dark, you can adjust it further by turning the Print Density Dial located in the right corner under the top cover. (Remove the drum unit to find the dial. See page 162 for more information.)

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 5.
- Press 9.
   The display will alternate messages.
- 6. Use **→** (left arrow) or **→** (right arrow) to change the settings.
- 7. Press Set.
- 8. Press Stop to exit.

# 09/12/1998 15:25 ONLINE ENTER NO. & SET 1. FAX 2. PRINTER 1. FAX 5. USER OPTIONS 9. PRINT DENSITY -■■■■□□□□□□+ SELECT ← → & SET

9. PRINT DENSITY

THE DISPLAY WILL SHOW:

Receive FAX

#### **Toner Save Function**

This function lets you extend the life of the toner by conserving its use. When the Toner Save is set to ON, the print appears somewhat lighter. This feature is also available when copying. The default setting is OFF.

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 5.
- 5. Press 7.
- 7. Press Set.
- 8. Press Stop to exit.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1.FAX
2.PRINTER

1.FAX

5.USER OPTIONS

7.TONER SAVE

TONER SAVE: OFF

SELECT ← → & SET

TONER SAVE: ON

7.TONER SAVE

There are three settings available for the Speaker Volume, OFF, LOW, or HIGH. This setting controls the loudness of the MFC's one-way speaker, which is connected to the phone line. The initial setting is LOW.

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 6.
- 5. Press 3.
- 7. Press Set.
- 8. Press Stop to exit.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1.FAX
2.PRINTER

1.FAX

6.TEL OPTIONS

3.SPEAKER VOLUME

SPEAKER: LOW

SELECT ← → & SET

SPEAKER: HIGH

3.SPEAKER VOLUME

Receive FAX

# Ring Volume

You can set the ring volume to either OFF, LOW or HIGH. The initial setting is HIGH. Even if you select OFF, the ring volume will be LOW for F/T ringing, Call Reservation ringing and when the Distinctive Ringing mode is SET.

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 6.
- 5. Press 5.
- 7. Press Set.
- 8. Press Stop to exit.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1. FAX

2.PRINTER

1.FAX

6.TEL OPTIONS

5.RING VOLUME

RING VOLUME: HIGH

SELECT ← → & SET

RING VOLUME: LOW

5.RING VOLUME

#### **B) REMOTE ACTIVATION**

#### What is Remote Activation?


If you answer a call that is a fax message, you can use the Remote Activation Code (\*51) to make your MFC take over the call. If your MFC answers a telephone call that is for you, you can use the Remote Deactivation Code (#51) to pick up the call at an extension phone. (You do not need a code to take over a call at the MFC.) You must use a touch tone phone.

#### FOR YOUR INFORMATION

#### Connecting an External or Extension Telephone

You may connect an external telephone to your MFC, as shown below. Use the "EXT." jack on your MFC.

Alternatively, you may wish to use this **EXT**. jack to connect a telephone answering device (TAD). An extension phone is a telephone that is plugged into a separate wall jack on the same line.



If the external telephone is in use, the warning message EXT. TEL IN USE will be displayed on the fax LCD. When the handset on the MFC is picked up, an alarm will sound. You can disconnect the external phone and switch to the MFC's handset by pressing **Hook**.

#### Using Remote Codes

The Remote Activation Code (\*51) is used in F/T and TAD modes. The Deactivation Code (#51) is used only in F/T mode.

#### Using the Activation Code

When you are at the MFC, you will probably answer incoming calls before your MFC or answering machine is programmed to pick up. If you answer a call and no one seems to be on the line, assume it is a fax message. Do not hang up. You must activate your MFC to take over the call first. (If you are holding the MFC's handset, just press the Start key and hang up.) If you are on an extension/external phone, press \*51 and wait for your MFC to respond before you hang up. After 3 seconds, you will hear receiving tones (chirps) through the handset of the extension phone. Then hang up. You can repeat the code as many times as needed. Your MFC will take over the call and print the fax message. If your caller wants to talk before sending the fax, you can have a conversation first and then activate your MFC with the code.

The Remote Activation Code can also be used by your callers. When you are using a TAD, your outgoing message (OGM) should end with the statement "to send a fax, press \*51". (See the section on Connecting a Telephone Answering Device for more information.)

#### Using the Deactivation Code

When your MFC is in F/T mode, sometimes it will answer a call that is not fax calling tones (a telephone call or manual fax). It will respond with a **double ring** (short, short) to alert you to take over. Because it has already answered the call, only the MFC will ring, extension phones are no longer connected to the call. Pick up any phone on the line, except an external phone connected to the MFC.

#### To take over the call at the MFC:

Pick up the handset of the MFC and talk to the caller as usual. If no one is there or someone is trying to send you a manual fax, press the **Start** key and replace the handset. Your MFC will display RECEIVING and print the incoming fax message.

#### To take over the call at an extension phone:

Pick up the handset on another telephone and **press #51 quickly during the silence between the double ring pattern.** When the MFC hears the code it will stop ringing and let you speak with the caller. If no one is on the line or someone is trying to send you a manual fax, send the call back to the MFC by pressing the Remote Activation Code (\*51).

You can change the codes at any time. It may be easier for you and your callers to press the same key three times (Example: \*\*\* and ###). Although you can change the codes to any numbers you want, try to avoid using digits for the Activation Code. The Remote Activation Code cannot match any number you dial. If you try to dial a phone number that includes the Activation Code, your MFC will go into receiving mode.

#### **Troubleshooting**

Sometimes other equipment on your phone line reserves a key that is in the Activation or Deactivation code. (Some answering machines reserve the "\*" key.) If the code you use to retrieve messages from your answering machine causes the line to be disconnected, try changing the Remote Codes. Change \*51 to ### and #51 to 999. The Remote Activation and Deactivation Codes may not work with some telephone systems or telephone sets.

NOTE: If you accidentally pick up an extension phone when a fax message is being received, you may disrupt the transmission or render some portions unreadable.

# Changing and Registering Remote Codes

The default setting is ON, so the remote codes were turned on for you.

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds,
- 3. Press 1.
- 4. Press 7.
- 5. Press 5.

#### THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1.FAX 2.PRINTER

1.FAX

7.SETUP SYSTEM

5.REMOTE CODE

REMOTE ACT.: ON

SELECT ← → & SET

Receive IVX

#### KELETVING FAACO AND UTTER LALLO REMOTE ACTIVATION

6. Press → (left arrow) or ▶ (right arrow) to choose ON or OFF. Example: ON.

REMOTE ACT.: ON

- 7. Press Set.
- Enter new remote code to activate. (Factory setting is \*51.) Then press Set.

ACT.CODE: \*51

9. Enter new remote code to deactivate. (Factory setting is #51.)

DEACT.CODE:#51

10. Press Set.

5:REMOTE CODE

11. Press Stop to exit.

#### C) CONNECTING A TELEPHONE ANSWERING DEVICE (TAD)

#### How to Use an External TAD with the MFC

When you have a Telephone Answering Device on the fax phone line, the TAD will answer all the incoming calls. Your Brother MFC will listen in on the line for fax CNG tones. If it hears them, it will take over the call and receive the fax message. If it does not hear fax tones, it will let the TAD continue playing the outgoing message so the caller can leave a voice message.

The TAD must answer within four rings. The MFC cannot hear the CNG calling tones until the TAD answers the call. When the Ring Delay is set for four rings, only 8–10 seconds of CNG calling tones are left for the "handshake." So you must strictly follow the instructions for recording the OGM.


You must erase the incoming messages frequently on your TAD. When the TAD's memory is full it will not answer any incoming calls (fax or voice).

Set the MFC's answer mode to TAD mode (Fax and F/T lights lit). (See page 61.)

# FOR YOUR INFORMATION ....


# Connecting an External TAD to the MFC

You may connect an external TAD to your MFC, as shown below. Use the  ${\bf EXT.}$  jack on your MFC.



- Do not connect a TAD elsewhere on the same phone line. This will cause problems because your MFC and TAD will both try to control the line.

#### Flowchart of External TAD Reception



#### TAD Hookup

There is only one way you can hook up a Telephone Answering Device (TAD) on the fax phone line. The TAD must be plugged into the back of the MFC in the jack labeled EXT. Your MFC cannot work properly if you plug the TAD into a wall jack. Follow these steps:

- Plug the telephone line cord from the wall jack into the back of the MFC in the jack labeled LINE.
- 2. Plug the telephone line cord from your TAD into the back of the MFC in the jack labeled EXT. (Double check that the telephone line cord comes from the jack in the TAD for telephone line and not for telephone set.)
- 3. Put your MFC in TAD mode by turning both the Fax and F/T lights on.
- 4. Sct your TAD to four rings or loss. (The MFC's Ring Delay setting does not apply).
- 5. Turn the TAD's Answer mode to ON.
- 6. Record the OGM (outgoing message) on your TAD as explained on the next page.

The TAD's outgoing message is important because it must be set up to handle two kinds of fax receptions; automatic and manual. Timing is important.

- 1. Record five seconds of silence as the beginning of your message. (Your MFC will be able to hear the fax calling tones, of automatic fax transmissions, before they stop.)
- 2. Limit your speaking to 20 seconds.
- 3. End your 20 second message by giving your Remote Activation Code for people sending manual faxes:
  - "After the beep, leave a message or send a fax by pressing \*51."

**NOTE:** Do not assume that most callers send faxes automatically. Many people do not realize they are not sending fax tones when they lift the handset or press the Hook key. Also, some machines may not send fax tones.

#### D) DISTINCTIVE RINGING

#### Distinctive Ringing

# What Is Distinctive Ringing?

Distinctive ringing is a service offered by the telephone carriers that allows you to have several different numbers on one phone line, so you can have a separate number for your MFC. Each number has its own distinctive ringing pattern. This way, when you get an incoming call, you can identify the number being called by its ring. Your local telephone company can provide more information about this service. The service is usually offered as a monthly charge to your normal telephone bill.

#### What Is the Advantage of Using the Distinctive Ringing Function?

Using Distinctive Ringing is the most efficient way to receive both fax and telephone calls on the same line. It is much easier for your callers who dial manually. The MFC will answer with receiving tones so they will not have to press an activation code or wait 30 seconds to hear fax tones (F/T mode). And the people who call to talk on your main number, will not have to talk to your MFC. Basically, it gives you two independent numbers without the higher cost of a second line.

#### Can My MFC Use Distinctive Ringing?

Yes, it has a distinctive ringing function that allows you to register the distinctive ringing pattern of an additional phone number on the line. The number you register must be the number you want to use as your dedicated fax number. Once you register the ringing pattern, the MFC will be able to identify its own incoming calls and automatically receive faxes at that number. You can register only one ringing pattern. There are some ringing patterns that can not be registered.



#### Can I Change the Setting Later?

Yes, you can change or cancel the distinctive ringing setting at any time. You can switch it OFF temporarily and then turn it back ON. When you move or get a new fax number, change the distinctive ringing mode to SET so you can register the new number.

#### How Will the MFC Treat All Other Numbers?

If you have registered the distinctive ringing number, the MFC will answer the registered number (with fax receiving tones) and receive faxes automatically. When a call comes in to your main number or to additional distinctive ringing numbers, all the phones will ring. You can set an external answering device (TAD) to answer calls on the other number(s). (See the chart on page 81.)

If you change the answer mode on the MFC to Fax or F/T, that setting will override the Distinctive Ringing setup. In Fax or F/T modes, your MFC will answer all the phone numbers (including its own ring pattern).


# External Telephone Answering Device (TAD) Answers Other Number(s) on the Line:

An external telephone answering device (TAD) can be set up to work with the Distinctive Ringing function. The external TAD must be set to its maximum number of rings (at least 4 ring patterns). Otherwise, it will answer the registered fax number before the MFC has time to recognize the ringing pattern. The external TAD's OGM (outgoing message) will answer your main number(s) if you do either #1 or #2 as follows:

- Plug the external TAD into the EXT jack of the MFC (you will not hear the first two rings on the MFC). Put your machine in Manual mode (Fax and F/T lights off).
- Plug the external TAD into another phone jack and put the MFC in Manual mode (Fax and F/T lights turned off).

Your telephone number will have the standard ring pattern of long long, while the new number could have a ring pattern of short short, long short, etc. When Distinctive Ringing is ON, you will not hear the first two rings of all incoming calls on the MFC. Extension phones will ring as usual. If the MFC recognizes the ring pattern, all ringing will stop and the MFC will answer and automatically receive the fax message. Otherwise, you will hear the extension phones and the MFC continue to ring. The MFC always listens to at least two ring patterns before it answers, so do not pick up the phone during that time. You will quickly learn to recognize the ring pattern for faxes, so you will not be tempted to answer that number. Either you or a telephone answering device can answer the main number(s).

#### Flowchart of an Incoming Call



**NOTE:** The MFC always listens to at least two ring patterns before it answers, so do not pick up the phone during that time.

Receive MX

#### Which Phone Number Should I Register?

It is a good idea to keep your old number for its original purpose and to register the new number as your fax number. Remember to give the new fax number to your customers and colleagues.

#### What Must I Do to Set Up Distinctive Ringing?

To use the Distinctive Ringing feature you must:

- 1. Get the distinctive ringing service from your telephone carrier.
- 2. When your distinctive ringing number is available, register it in the function called "Setting the Distinctive Ringing Function."
- 3. Keep the MFC in Manual answer mode (both Fax and F/T lights turned off).

#### Setting the Distinctive Ringing Function


This function is a one-time procedure to register a distinctive ringing number with your MFC. Your MFC will answer the registered number automatically, simulating Fax mode on a dedicated fax line. You can register only <u>one</u> number. <u>Do not try to set up this function if you do not have the distinctive ringing service. It may cause your MFC to malfunction.</u>

This procedure is in two parts: First, you must put the MFC in SET mode; D/R SET MODE will be on the display screen. Second, you must wait for a friend to call the distinctive ringing number so you can register the ringing pattern. When a call comes in, do not pick up the handset until the MFC's display says PICK UP TO SET. Then pick up the handset. If the caller dialed your distinctive ringing number, press the Start key and check that the display says REGISTERED before you hang up. If the caller dialed the other number, press the Stop key and hang up to try again.

#### Before you begin this function:

- 1. If your MFC is connected to a telephone answering device or to the telephone company's Voice Mail system, disconnect it before you begin this function.
- 2. Have a friend ready to call your distinctive ringing number.

# | KEYS TO PRESS | THE DISPLAY WILL SHOW: | 09/12/1998 15:25 | 0NLINE | ENTER NO. & SET |



# **Troubleshooting Tip**

If your MFC display shows **D/R SET MODE** and you are not in the process of setting up a distinctive ringing number, press the **Stop** key to exit this function. The Settings will remain unchanged.

 When the phone rings, listen carefully to check that the ringing pattern is the one you want to register. If it is, <u>wait</u> until the display says **PICK UP TO SET**. Then pick up the MFC handset.

D/R SET MODE.

ringing fax number.

Also, the answer mode lights will flash. You must now wait for someone to call the distinctive

- Press Start to set. Check that the display says REGISTERED.
   (If the other number was called, press Stop to cancel.)
- 11. Press **Start** again to receive the incoming fax, or if the call is a voice call, talk into the handset.

START TO SET

STOP TO CANCEL

REGISTERED

TELEPHONE/FAX
ONLINE

#### After you complete this one-time setup:

- 1. The Distinctive Ringing function automatically will be changed from SET to ON. Set the answer mode based upon your needs.
- 2 Be sure to have a friend call you on <u>hoth</u> numbers to test that everything is set up correctly.
- 3. If you do not complete this function by pressing **Start** to register a number, your MFC will stay in D/R SET MODE. So, if you decide <u>not</u> to register a number, you must repeat Steps 1–8 and in Step 6 change the mode to OFF.

#### How to Turn the Distinctive Ringing Function ON or OFF

The distinctive ringing function is designed to accommodate the distinctive ringing service (a telephone service that provides you with multiple numbers, each with a distinctive ring pattern, on one line). You can change the distinctive ringing function setting to ON or OFF as needed <u>after</u> you have registered the distinctive ringing number in the function called Settingthe Distinctive Ringing Function. To change the setting, repeat Steps 1–8 above; Step 6 is where you can select either ON or OFF.

#### E) CALLER ID

#### What is Caller ID?

Caller ID is a telephone service that allows the subscriber to see a display of the caller's phone number (or name in certain states) as the telephone rings. It is a fast way to screen your calls. You can respond quickly to calls you missed, because Caller IDs are received and stored in your MFC's memory.

#### NOTICE

To get the Caller ID Service: apply for the Caller ID service at your local telephone company.

The type of service varies from state to state and is determined by your telephone company. Your particular service may display only the caller's phone number or the caller's number and/or name.

#### Advantages of Caller ID

#### For Business

All businesses profit from a quicker response to customer calls. Businesses that provide mail order services, money-lending services or provide confidential information, can protect themselves from false orders or acceptance of false identification.

#### At Home

Residential customers can protect themselves from unwanted calls.

# The Caller ID Appears on the Display When Your Telephone Rings

As your telephone rings, the Display shows you the caller's phone number (or caller's name in certain states). You will know who is calling before you pick up the handset or before your MFC automatically receives the call. Once you pick up the handset, the caller's ID disappears. If both the caller's phone number and name are received, only the name will appear on the Display. You will see the first 16 characters of the number or name.

#### **Helpful Hints**

- If OUT OF AREA appears on the Display, it means that the call came from outside your caller ID service area.
- If PRIVATE CALL appears on the Display, it means the caller intentionally blocked the transmission of his/her ID.
- If no caller ID was transmitted to your MFC, CALL PICKUP will remain on the display.

NOTE: Please set the number of rings to more than 02 to use Caller ID. If you set the number of rings to 01, you can not receive the Caller ID.

#### The Caller ID is Stored in Your MFC's Memory

The MFC can store a maximum of the last 30 incoming caller IDs in the memory, along with the time and date of reception. The 31st call will cause the oldest ID to be erased.

You can scroll through the Caller ID information stored in the memory.

You can also print the Caller ID list and review calls you received by checking the Caller IDs in memory. This report lists the Date, Time, Phone Number (Caller ID), Name (in certain states), and type of call (Comment). (See pages 87–88.)

#### Scanning through the Caller IDs Stored in the Memory

You can display the caller IDs that are stored in the memory as follows. (You can skip to Step 6 below by pressing the **Shift** and **Tel-index** keys simultaneously.)

#### KEYS TO PRESS

#### THE DISPLAY WILL SHOW:

1. Press Function.

09/12/1998 15:25 UNLINE

2. Wait for two seconds.

ENTER NO. & SET

1. FAX

2.PRINTER

Receive FAX

- 3. Press 1.
- 4. Press 6.
- 5. Press 7.
- 6. Press Set.

The Caller ID of the last call will appear on the display.

- If no ID is stored, the beeper will sound and NO CALLER ID will appear on the display.
- Press (leftarrow) or (rightarrow) key to scroll through the Caller IDs in the memory.

In this example, press the  $\blacktriangleleft$  key five times.

- Pressing the key will cycle backward through the stored caller IDs from the latest to the oldest. If you press the key when the oldest ID appears, the latest one will appear. The key cycles forward.
- After two seconds, the date and time the caller ID was received will appear.
- 8. Press Stop to exit.

1.FAX

6.TEL OPTIONS

7.CALLER ID

30)1455551212

25)5555151

# FOR YOUR INFORMATION

#### Clearing a Caller ID Stored in Memory

For effective use of the memory, it is recommended that you clear the Caller IDs stored in memory by pressing **Clear** when the display shows the number or name.

You can print a listing of the Caller IDs for the last 30 calls received. Both telephone and fax calls will be listed.

# KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 3.
- 5. Press 9.
- 6. Press **Set** or wait two seconds until you see the prompt at the right.
- 7. Press Start.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

FNTFR NO. & SFT

FAX
 PRINTER

1.FAX

3.PRINT REPORTS

9.CALLER ID

PRESS START KEY

PRINTING

# **▼** Sample of Caller ID List

CALLER ID LIST

TIME: 09/04/1998 14:05

NAME : BROTHER FAX : 908-469-4547 TEL : 908-356-8880

	DATE	TIME	CALLER ID	NAME	COMMENT
01	09/04	13:45	5551212	KOUJI TAKEYAMA	TEL RX
02	09/04	13:45	5551212	KOUJI TAKEYAMA	TEL
03	09/04	13:45	5551111		TEL RX
04	09/04	13:45	5551010		RX
U5	U9/04	13:45	5552222		
06	09/04	13:45	5552323		
07	09/04	13:45	5550000	SMITH SHARON	TEL RX
08	09/04	13:45	5551212	KOUJI TAKEYAMA	TEL TX
09	09/04	13:45	5551234		RX
10	09/04	13:45	5551010	SMITH SHARON	TX
11	09/04	13:45	5550101	JONES JENNIFER	TEL RX

NOTE: "TX" means Transmit, "RX" means Receive.

#### CONTENTS OF THE LIST:

- DATE & TIME
- CALLER ID
- NAME (ONLY WHEN AVAILABLE)
- COMMENT

#### COMMENTS WILL INCLUDE:

- TX means your MFC sent a fax message when it was polled or called.
- RX means your MFC received a fax message (except Polling or Call Reservation).
- TEL means you answered a telephone call at your MFC, external TAD or external phone.
- BLANK means the call was not answered or you answered on an extension phone.

# 7. POLLING (TEMPORARY SETTINGS)


#### FOR YOUR INFORMATION

#### What Is Polling?

Polling is the process of **retrieving** faxes from another fax machine. You may use your MFC to "poll" other machines, or you may ask someone to poll your MFC. The party who polls pays for the cost of the call.

#### How Does It Work?

First all parties set up their fax machines so that they can accommodate polling. Then one party leaves documents in the fax machine so that the other party can call and have the documents sent to them.



# When to Use Polling

Use polling to control the cost of who pays for sending a fax.

- 1. If **you** want to pay for the cost of the call: Send faxes to other parties as you normally would, and if another party has documents to send you, ask if you can poll for them.
- 2. If you want **others** to pay for the cost of the call: Ask them to poll your MFC for documents they want, and have them fax any documents that you want.
- \* There are some fax machines that will not respond to the polling function.

# Helpful Hints Using Polling Effectively (Examples)

**Problem No. 1:** You want another party to send you a long fax, but they do not want to pay for the call.

Solution: Ask them to leave the document in their fax machine

so you can poll for it.

Problem No. 2: Sales representatives have difficulty sending faxes

to the head office's fax machine because it is busy

much of the time.

Solution: Head office can poll the sales representatives' fax

machines.

Problem No. 3: Because of the time or location, it is cheaper for

someone to call you than it is for you to make the call.

Ask the other party to poll for the documents and

offer to pay for the call at their lower rate.

# Polling Another Fax Machine (Calling)

Solution:

Once you have set up polling, as described below, and the other party has set their fax machine to POLLED WAITING, you can receive their documents automatically.

#### KEYS TO PRESS

Make sure there are no documents in your feeder.

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 1.
- 5. Press 2.
- 6. Wait for two seconds.
- 7. Press (leftarrow) or (rightarrow) to select Polling ON.
- 8. Press Set.

#### THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1. FAX

2.PRINTER

1.FAX

1.TEMP.SETTINGS

2.POLLING

POLLING: OFF

SELECT ← → & SET

POLLING: ON

2.POLLING

11. Press Start.

	ENTER FAX NO.
(	ONLINE
•	PRESS START KEY
-	ONLINE
	NJ OFFICE
	ONLINE
	DIALING
	ONLINE
	RECEIVING P.01
	ONLINE

# Setting Up Polled Waiting (Being Called)

Polled Waiting is when you place a document in your MFC and set it to allow another fax machine to retrieve that document. Your MFC will print a Polled Report after the transmission.

# THE DISPLAY WILL SHOW: KEYS TO PRESS 09/12/1998 15:25 ONLINE FAX: NO. & START 1. Insert the documents into the feeder. SCAN READY COPY: PRESS COPY SCAN READY ENTER NO. & SET 2. Press Function. 3. Wait for two seconds. I. FAX 2.PRINTER 4. Press 1. 1.FAX 1.TEMP.SETTINGS 5. Press 1. 2.POLLING 6. Press 2. POLLING: OFF 7. Wait for two seconds. SELECT ← → & SET 8. Press <a>(left arrow) or <a> (right arrow) to</a> POLLING: ON select Polling ON.

9. Press Set.

10. Press Stop.

11. Press **Start** and wait for the polling call to come in.

2.POLLING

PRESS START KEY ONLINE

POLLED WAITING ONLINE

# **Delayed Polling**

You can set the time when you want polling to take place. After you select POLLING:ON, press  $\mathbf{Set}$ , then press  $\mathbf{1}$  and use the dial pad to enter the time when you want polling to take place.

#### KEYS TO PRESS

Make sure no documents are in the feeder.

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 1.
- 5. Press 2.
- 6. Wait for two seconds.
- 8. Press Set.
- 9. Press 1.
- 10. Enter the time. Example: **19:45** (7:45P.M.).

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

FAX
 PRINTER

1.FAX

1.TEMP.SETTINGS

2.POLLING

POLLING:OFF

SELECT ← → & SET

POLLING: ON

2.POLLING

1.TIMER

SET TIME=00:00

SET TIME=19:45

12. Press Stop.

13. Enter the fax number. Example: One Touch dialing.

14. Press **Start**.

The MFC waits until the specified time to call



#### Setting Up Polled Waiting with Super Quick-Scan

Before pressing **Start**, press **Super Q.Scan** so that you can store your Polled Waiting document in the memory. If you use **Super Q.Scan** to place the Polled Waiting documents into the memory, they will not be erased automatically after they are polled. To erase them you must use the Cancel Job function. (See page 47.)

#### Sequential Polling

This function is the reverse of Broadcasting, in which your MFC sends a document to several destinations. In a sequential polling operation, your MFC will request documents from several fax units in a single operation.

After all the polling operations are finished, a Sequential Polling Report will be printed automatically.

#### KEVS TO PDESS

- 1. Make sure there are no documents in the feeder.
- 2. Press Function.
- 3. Wait for two seconds.
- 4. Press 1.
- 5. Press 1.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

FAX
 PRINTER

1.FAX

1.TEMP.SETTINGS

 $FAX\ Options$ 

6. Press 2.

- 8. Press Set.
- 9. Press Stop.
- Specify the destination of fax machines, that you wish to poll by using One Touch, Speed Dial, or Group keys.
   Example: Group key.
- 11. Press **Start**. Your MFC polls each number or group member in turn for a document.

2.POLLING

POLLING:OFF

SELECT ← → & SET

POLLING:ON

2.POLLING

ENTER FAX NO.
ONLINE

PRESS START KEY
ONLINE

BROTHER

DIALING ONLINE

ONLINE

Since the MFC can store incoming data in memory as well as print it, you can use the convenient FAX Forwarding, Paging and Remote Retrieval functions.

# Setting the Fax Storage

Set this function to ON if you want the incoming data to be stored in the memory as well as printed. When the data is stored in the memory, you can use the Fax Forwarding, Paging, and Remote Retrieval functions. It is a good idea to turn the Fax Storage function ON when you go out. The initial setting is OFF.

# KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 8.
- 5. Press 1.
- 7. Press Set.
- 8. Press Stop to exit.

# THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

I. FAX

2.PRINTER

1.FAX

8.REMOTE FAX OPT

1.FAX STORAGE

FAX STORAGE:OFF

SELECT ← → & SET

FAX STORAGE: ON

1.FAX STORAGE

FAX Options

#### FOR YOUR INFORMATION

 When you have FAX STORAGE:ON, your incoming faxes will be stored in the memory and the LCD will show the number of incoming calls:

> FAX IN MEMORY:01 ONLINE


 When you want to change the Fax Storage setting from ON to OFF and fax data is still in the memory, you will get the following message after you select OFF:

ERASE ALL FAX?

1.YES 2.NO

If you select 1, you will erase all the fax data from the memory and the function will be set to OFF. If you press 2, the data will not be erased, and the setting will remain ON.

Whenever your MFC prints a document for "Back-Up Printing," it will be printed in standard resolution regardless of the resolution in which it was received.



#### NOTICE

- 1. You can activate either paging or fax forwarding; they are very similar features and cannot be used simultaneously.
- 2. If paging is ON, you will be paged every time a fax message is received into the memory.

#### Setting Up Paging (Registering the Paging Number)

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 8.
- 5. Press 2.
- 6. Press  **(**leftarrow) and  **(**rightarrow) to select PAGING.
- 7. Press Set.
- 8. Enter a paging number up to 20 digits (this is the telephone number of your pager), followed by two # signs. Do not include the area code if it is the same for your MFC and pager.

  Example: 18002844329##.
- 9. Press Set.
- Enter a PIN (Personal Identification Number), #, press Redial/Pause, your MFC telephone number, and ##. Example: 12345#-19085551234##.
  - If you do <u>not</u> use a PIN, you <u>must</u> enter the telephone number of your MFC. Press Redial/Pause before entering your MFC's telephone number and add ##. Example: -19085551234##.

## THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1. FAX

2.PRINTER

1.FAX

8. REMOTE FAX OPT

2.FAX FWD/PAGING

OFF

SELECT ← → & SET

PAGING

PAG#:

ENTER & SET

#:18002844329##\_

PIN#:

ENTER & SET

5#-19085551234##

- 12. Press Stop to exit.
- Paging number and PIN number cannot be changed remotely.
- Redial/Pause appears as a hyphen on the display.

#### FOR YOUR INFORMATION

The PIN (Personal Identification Number) you enter depends upon the type of paging company you use. There are generally two types of paging companies:

1) Satellite Pagers: In this case we recommend you enter your actual satellite PIN # plus your return MFC telephone/fax number/or special alpha message.

For Example: 12345#19085551234## or 12345#329329329## FAXFAXFAX

2) Radio Pagers: Most\* radio pagers do not require a PIN #, and in this case you should use the PIN # in the MFC only for the return number or special alpha message.

For Example: 19085551234## or 329329329##

FAXFAXFAX

\* If your radio pager utilizes a PIN # then use satellite sequence

The "##" symbols at the end of the special message (or return #) are used to signify the end the PIN #/Message.

## Setting Up Fax Forwarding (Registering the Fax Forwarding Number)

## THE DISPLAY WILL SHOW: **KEYS TO PRESS** 09/12/1998 15:25 ONLINE ENTER NO. & SET 1. Press Function. I. FAX 2. Wait for two seconds. 2.PRINTER 3. Press 1. 1.FAX 4. Press 8. 8.REMOTE FAX OPT 5. Press 2. 2.FAX FWD/PAGING OFF SELECT ← → & SET 6. Press **(left arrow)** and **(right arrow)** FAX FORWARD to select FAX FORWARD. 7. Press Set. FWD#: ENTER & SET WD#:18005551234\_ 8. Enter a fax forwarding number up to 20 digits. Example: 18005551234. 2.FAX FWD/PAGING 9. Press Set.

#### What Is Remote Control Access?

10. Press **Stop** to exit.

When you leave your home or office, you will turn on your FAX STORAGE to receive fax messages. (See pages 95–96.) But if you would like to activate or deactivate this FAX STORAGE feature, you can control and program your fax by remote control. You can call your MFC from any touch tone phone, enter your remote access code, followed by programming commands.

The initial setting for the remote access code on your MFC is "159\*". You can change this code if you wish or if it conflicts with other equipment codes.

Change the Remote Access Code frequently and use it as a "secret password" to limit access to your REMOTE FAX OPTIONS.

When you use the Remote Access Code, you must press all four keys (three-digit number plus \*).

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 8.
- 5. Press 3.
- Enter a three digit number 000 to 999.
   The last digit, an asterisk, cannot be changed.

Example: 160\*.

The three digit number must not be the same as the remote activation and deactivation codes. (See pages 73–76.) Example: When the remote access code is 160\*, don't use 160 or 60\* for the activation and deactivation code.

- 7. Wait for two seconds.
- 8. Press Stop to exit.

#### THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1.FAX 2.PRINTER

1.FAX

8.REMOTE FAX OPT

3.REMOTE ACCESS

ACCESS CODE: 159\*

ACCESS CODE:160\*

3.REMOTE ACCESS

FAX Options

#### How to Use Remote Access and Control Codes

- 1. Pick up the handset of a remote touch tone phone or fax machine.
- 2. Dial your MFC's number.
- 3. When your MFC answers with a beep, immediately press your Remote Access Code (159\*). (See page 101.)
- 4. If you hear a long beep, it means your MFC has received fax message(s).

  If you do not hear a long beep, it means your MFC did not receive any message(s).
- 5. As soon as you hear two short beeps, press a Control Command.
  Each time your MFC completes an instruction, it gives two short beeps telling you to enter the next command; if you wait longer than 30 seconds to enter the command, your MFC will disconnect the line. If you perform a wrong operation, you will hear three short beeps.
- 6. When you are ready to exit remote control mode, press 90 to reset your MFC.

#### Remote Fax Retrieval

If you have set your FAX STORAGE: ON to store incoming fax messages, you have the ability to retrieve these fax messages from any remote Group 3 facsimile machine. Remote fax retrieval is accomplished via remote control access commands, which are described in the remainder of this chapter.

#### FOR YOUR INFORMATION

#### When to Enter the Remote Access Code

Just after the line is connected, you should enter the remote access code from any touch tone phone. Make sure that you enter the remote access code while you do <u>NOT</u> hear the chirping sound of the MFC. If the MFC is set to MANUAL mode, it will answer the call after about 20 rings (about 100 seconds). You will have 30 seconds to press the remote access code or the line will be disconnected.

## Remote Control Commands

You can control your MFC with the following remote control commands.

Re	mote control command	Detail Operation				
95	Changing Fax Forwarding /Paging setting					
	1 OFF	If you hear one long beep, the change is accepted. If you hear				
	2 Fax Forwarding	three short beeps, you can not change it because the conditions (ex. registering fax forwarding or paging number) have not been				
	3 Paging	completed. You can register your fax forwarding number by using 4. FAX FWD No. (see page 104). Once you have registered the number, the machine automatically will turn to "FAX"				
	4 FAX FWD No.	FWD:ON" mode. To receive a Memory Status List, enter 961 (see page 104). Check the List to make sure the Fax Forwardin number you registered is correct. Then enter the confirmation command 955. Now the MFC will start Fax Forwarding.				
	5 FWD No. Confirm					
	6 Fax Storage ON	You can set FAX STORAGE ON or OFF.				
	7 Fax Storage OFF					
96	Retrieve FAX	-				
	1 Memory Status List	You must call from a remote fax machine to receive the Memo				
	2 00 Retrieve all FAXES	Status List or stored fax message(s). (See page 104.)				
	2 "MSG No." 00 Retrieve by MSG number	*. *				
	3 Erase FAX in the memory	If you hear one long beep, you can erase fax message(s) from the memory.				
97	Check the receiving status	You can check whether your MFC has received any fax message				
	1 FAX	If yes, you will hear one long beep. If no, you will hear three she beeps.				
98	Change Answer Mode	If you hear one long beep, you can change the Answer Mode. If you hear three short beeps, you can not change it.				
	1 TAD	you near three short beeps, you can not change it.				
	2 F/T					
-	3 Fax					
90	Exit	The MFC is reset. After a long beep, you can hang up.				

#### Retrieving the Memory Status List and Fax Messages Remotely

From a remote fax machine, you can retrieve your Memory Status List to see if you have any stored fax messages in the memory. Then you can retrieve all or only specified fax messages that are on the list.

- 1. Pick up the handset of a remote touch tone fax machine.
- 2. Dial your MFC's number.
- 3. When your MFC answers with a beep, immediately press your Remote Access Code (159\*).
- 4. As soon as you hear two short beeps, press 961.
- 5. When you hear your MFC through the handset responding with a fax tone, press **Start** and <u>hold</u> the handset if you want to retrieve fax messages also. (If you wish to retrieve only the Memory Status List, <u>replace</u> the handset.)
- 6. Your remote fax machine will print the Memory Status List. (See page 127.)
- Look at the Memory Status List to see if there are any fax messages you want to retrieve.
- 8. Press 96 2 as soon as you hear two short beeps.
  - After 96 2, enter the two-digit message numbers from the Memory Status List (Example: 01) and end by pressing 00.

Example:) To receive NO.1 and NO.2 messages, press 96 2 01 02 00.

If you want to retrieve all messages, simply press 00.

Example:) To retrieve all fax messages, press 96 2 00.

- 9. When you hear your MFC through the handset responding with a fax tone, press **Start**.
- 10. Replace the handset.
- 11. Your remote fax machine will print the fax messages.

#### Changing the Fax Forwarding Number Remotely

- 1. Pick up the handset of a remote fax machine.
- 2. Dial your MFC's number.
- 3. When your MFC answers with a beep, immediately press your Remote Access Code (159\*).
- 4. As soon as you hear two short beeps, press 954.
- Enter your new Fax Forwarding number using the dial pad (up to 20 digits). You
  cannot register \* and # as dial numbers. Use \* to create a pause between the dial
  numbers.
- 6. Press # after entering the new number.
- 7. As soon as you hear the next two short beeps, press **961**.
- 8. When you hear your MFC through the handset responding with a fax tone, press **Start** and <u>hold</u> the handset.
- 9. Your remote fax machine will print the Memory Status List. Look at the list to make sure the new Fax Forwarding number you registered is correct.
- 10. If the new number is correct, wait for the next two short beeps, and press 955. (If the new number is incorrect, press 954 and reenter the number beginning at Step 5.)
- 11. Replace the handset. Your new Fax Forwarding number is activated.

## Printing a Fax Message

You can print a fax message that is stored in the memory.

## KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 1.
- 4. Press 8.
- 5. Press 4.
- 6. Press Set.
- 7. Press Start.
- 8. Press Stop to exit.

## THE DISPLAY WILL SHOW:

FAX IN MEMORY:01 ONLINE

ENTER NO. & SET

1.FAX

2.PRINTER

1.FAX

8.REMOTE FAX OPT

4.PRINT FAX

PRESS START KEY

PRINTING

4.PRINT FAX

## 9. USING THE MFC AS A PRINTER

#### Acceptable Paper

Your MFC can handle paper that has the following specifications. But please note that you can receive <u>fax messages</u> on only Letter, Legal and A4 paper. And if you use Legal or A4 sheet, you have to change the Paper Size setting, which is **Function**, **1**, **5**, **6**. (See page 66.)

Paper Type	Paper Size			
Cut sheet	A4, Letter, Legal, B5, A5, Executive, Custom size 2.75-8.5 x 5-14 inches (70-216 x 127-356 mm)			
Envelopes	DL, C5, COM-10, Monarch, 9" x 12"			
Post Card	2.75-8.5 x 5-11 inches (70-216 x 127-356 mm)			
Organizer	Day-Timer® J, K, L, M 2.75-8.5 x 5-11 inches (70-216 x 127-356 mm)			
Labels and Transparencies	2.75-8.5 x 5-14 inches (70-216 x 127-356 mm)			

#### Paper Capacity in Feeder:

Multi-purpose

Sheet Feeder: Up to 22 mm (0.87 inch) in height (up to the mark) Approx. 200

sheets of 75 g/m<sup>2</sup> (20 lb.) or 50 sheets of 158 g/m<sup>2</sup> (42 lb.) A4/Letter

paper, or 10 envelopes

	Cut Sheet	Envelope	
Basis Weight	16 to 42 lb. (60 to 158 g/m²)	20 to 24 lb. (75 to 90 g/m²) single thickness	
Caliper	0.08 to 0.2 mm (±0.03 to ±0.08 in.)	0.084 to 0.14 mm (0.0033 to 0.0058 in.) single thickness	
Moisture Content	4% to 6% by weight	4% to 6% by weight	
Smoothness	100 to 250 (Sheffield)	100 to 250 (Sheffield)	

## Recommended paper types:

Cut sheet: Xerox 4200

Label: Avery laser label or equivalent

Transparency: 3M CG3300 for laser printers or equivalent

#### **Helpful Hints**

It is recommended that you test paper, especially special sizes and types of paper, on the MFC before purchasing large quantities.

Avoid feeding labels with carrier sheets exposed, or your MFC will be damaged.

Avoid using coated paper, such as vinyl coated paper.

Avoid using preprinted or highly textured paper.

For optimum printing, use a recommended type of paper, especially plain paper and transparencies. For more information on paper specifications, consult with your nearest authorized sales representative or the place where you purchased your MFC.

Use label or transparencies that are designed for use in laser printers.

We recommend you use long-grained paper for the best print quality.


If you are using special paper, and the paper has problems feeding from the multi-purpose sheet feeder, try again using the manual feed slot.

You can use recycled paper in this MFC.

#### FOR YOUR INFORMATION

Before using paper with holes such as organizer sheets, you must fan the stack well to avoid paper jams and misfeeds.

Before using any paper, make sure that it is not curled. If it is, straighten the paper as much as possible. Using curled paper will cause paper jams and misfeeds.




The following types of envelopes should not be used:

- Damaged, curled, wrinkled, or irregularly shaped envelopes
- Extremely shiny or highly textured envelopes
- Envelopes with clasps
- Envelopes with self-adhesive closures
- Envelopes of baggy construction
- Envelopes that are not sharply creased
- Embossed envelopes
- Envelopes already printed with a laser printer
- Envelopes preprinted on the inside
- Envelopes that can not be arranged uniformly when placed in a pile




The printable area of your MFC begins at approximately 4mm (0.16 inch) from the edge of the paper.



#### Control Panel Keys

#### **Printer Status**



#### Simultaneous Operation

Your MFC can print data from the PC simultaneously while either sending or receiving a fax message or scanning into the PC. When your MFC is copying or receiving a fax on paper, it pauses the PC printing operation until it has finished.

#### On/OffLine Key

This key is used to turn the printer on-line (ready to receive PC data) and off-line (not ready to receive PC data). If you press this key during printing, the MFC immediately stops printing even if it has already started to print. It ejects the page, and then enters the offline status. Press **On/OffLine** again and the printer will print the complete page again.

When the printer is in the online status and the LCD shows ONLINE, you cannot use **FF/Cont** and **Test/Reset** keys.

#### FF/Cont Key

The upper switch on the control panel can work as the Form Feed (FF), Continue (CONT) key.

#### Form Feed

When the LCD shows **REMAINED DATA**, press **On/OffLine** to turn the printer offline, then press **FF/Cont**. The MFC prints any data remaining in the printer memory.

NOTE: The MFC periodically will print any data remaining in the memory.

#### **Clearing Errors**

If an error occurs, the MFC usually will automatically recover the recoverable errors, such as a memory full condition. If the error does not clear automatically, press **FF/Cont** to clear the error and continue the operation.

#### Test/Reset Key

#### **Test Sample Page**

This key is used to print a test sample page. If data remains in the printer memory, press **On/OffLine** to turn the printer offline and press **Test/Reset**. The MFC will print the remaining data first and then will print a test sample page. To print the printer status lists, see page 118. If the printer is online, the MFC cannot print a test sample page.

#### Resetting the Printer

When **Test/Reset** is pressed together with **Shift**, it clears data from the memory. The printer is also reset and restored to the factory default settings. The **Test/Reset** switch may be able to clear an error status and the Hex Dump mode. (See page 120.) Remember that the **Test/Reset** switch clears data from the printer memory.

#### **Print Priority Key**

When this key is first pressed, it puts the MFC exclusively in printer mode. All fax data will be stored in the memory instead of printing on paper. When this key is pressed again, and PC data is not being sent or the MFC has completed printing, it will exit automatically from the print priority status. When the **Print Priority** key is pressed, it increases the memory available for printing.

#### FOR YOUR INFORMATION

#### Windows® Printing

The dedicated printer driver and True Type™ compatible fonts for Microsoft® 3.11, 3.1 Windows® 95 and Windows NT® Workstation Version 4.0 are available on the Brother CD-ROM supplied with your MFC. You can easily install them into your Windows® system using our installer program. The driver supports our unique compression mode to enhance printing speed in Windows® applications, and allows you to set various printer settings including economy printing mode and custom paper size.

#### Remote Printer Console Program for DOS

The utility program, Remote Printer Console (RPC), is available on the CD-ROM supplied with your MFC. When you operate your computer in the DOS (Disk Operating System) environment, this program allows you to easily change the default settings of the printer such as fonts, page setup, emulations and so on.

The RPC program also provides a status monitor program, which is a Terminate-and-Stay Resident (TSR) program. It can monitor the printer status while running in the background and will report the current status or errors on your computer screen.

#### Popular Printer Emulation Support

This MFC supports the printer emulation mode, HP LaserJet IIP. When you use DOS application software or Windows® version 3.0 or earlier, you can use the emulation mode of HP LaserJet IIP to operate the printer. To set the printer emulation, use the Remote Printer Console Program.

#### Bi-Directional Parallel Interface

The parallel interface of this MFC allows bi-directional communication with a computer. This interface allows the printer (MFC) to communicate back to the computer useful information such as the amount of memory installed, and other printer setup conditions. As the supplied Remote Printer Console, Windows® 95 or 3.1 driver both support the bi-directional mode, they can both report the printer status.

#### **Enhanced Memory Management**

The MFC has its own Data Compression Technology, which automatically compress graphic data and download font data efficiently into the printer's (MFC's) memory. You can avoid memory errors and print most full page 600 dpi graphic and text data, including larger fonts, with the printer's standard memory.

The MFC has a multi-purpose sheet feeder that can feed plain paper, envelopes and organizer paper.

When the MFC receives data, it begins the print process by loading paper from the multi-purpose sheet feeder.

#### KEYS TO PRESS

- Select and set the PC command and status.
- Your PC will send a print command and data to the MFC.If the MFC is in sleep mode, it will wake
- 3. When the PC has sent the first page data, the MFC will start printing.

up. (See pages 17-18.)

- The MFC will start to print the next page automatically.
   Example: Two pages of data.
- When the MFC finishes printing all the data, it will return to online status.

If data is still remaining in memory, press **On/OffLine** and then press **FF/Cont**.

#### THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

09/12/1998 15:25 RECEIVING DATA

09/12/1998 15:25 REMAINED DATA

09/12/1998 15:25 REMAINED DATA

09/12/1998 15:25 ONLINE

09/12/1998 15:25 REMAINED DATA

#### **Helpful Hints**


You may select the proper paper source, paper size, and orientation in your application software.

If your application software does not support your custom paper size, select the next larger paper size. Then adjust the print area by changing the right and left margins in your application software.

#### NOTICE

When you use labels or transparencies for overhead projectors, be sure to use the manual feed slot. See the next section "Manual Feed Slot" for more information.


Printer



#### Two-Sided Printing (Manual Duplexing)

The supplied printer driver for Windows® 95, 3.1, 3.11 or for Windows NT® Workstation Version 4.0 enables manual duplex printing. For more information about settings, see the Help screen text for the printer driver. The MFC will print all the even numbered pages on one side of the paper first, and then will print all the odd pages numbered on the reverse side of the paper. When you have finished printing on one side of the paper, the Windows® driver instructs you with a pop-up message on the computer to reinsert the paper. Follow the instructions on how to reinsert the paper.

Before reinserting the paper, straighten it well, or you may get the paper jam. The use of very thin or very thick paper is not recommended. If you get a double feeding error, hold the paper except the front sheet while the paper is feeding.



#### NOTICE


When you use the Manual Duplex function, it is possible that a paper jam may occur or the print quality might not be satisfactory.

#### Manual Feed Slot

The multi-purpose sheet feeder also has a manual feed slot. You can manually load paper, sheet by sheet into this slot. You do not have to remove paper from the multipurpose sheet feeder. When you use labels or transparencies, be sure to use this slot. For information on paper specifications, see "Acceptable Paper" on page 107.

#### When you load one sheet of paper manually:

You do not have to choose manual feed in the Setup dialog box of your printer driver. Insert the sheet of paper in the direction for Portrait or Landscape, placing the side of the paper you wish to print on face down in the manual feed slot. Align the paper at the center of the manual feed slot, and be sure to insert it all the way. (①) Adjust the paper guide of the manual feed slot to the paper width you are using. (②)



#### When you load more than one sheet of paper manually:

Open the Setup dialog box of the Windows® printer driver and select Manual Feed in the Paper Source section. Follow the above instructions to load the first page. The MFC will start printing automatically. After the first page is printed, the dialog box will appear and prompt you to load the next page. Load a sheet and select OK to resume printing. Repeat these steps until you have finished printing all the pages.

#### **Helpful Hints**

- You may select manual paper feed, paper size, and orientation in your application software. If your application software does not allow these settings, you should set them using the RPC program supplied with your MFC.
- If you do not select manual paper feed and insert a page in the manual feed slot, the MFC will load the first page from the manual feed slot and subsequent pages from the multi-purpose sheet feeder.
- If your application software does not support your custom paper size, select the next paper size. Then adjust the print area by changing the right and left margins in your application software.
- 4. When you want to stop or clear the manual feed, press **Shift** and **Test/Reset**, or you can also stop it with a PC command.
- 5. When you use manual feed slot, it is best to first press **Print Priority**. This allows you to print PC data without interruption from incoming faxes. Incoming faxes will be stored in the MFC's memory. To continue printing PC data, press **FF/Cont** after each page has printed.
- 6. If bi-directional communication is not operational between the MFC and the computer, such as when the MFC is shared on a network, the dialog box for loading the next page will not appear. When your MFC is attached to a network, we do not recommend manual feeding.

#### FOR YOUR INFORMATION

#### Paper Tray

The MFC ejects paper with printed surfaces face down into the paper tray at the front of the MFC.

When you use transparencies, remove each sheet immediately after printing, to prevent a paper jam or curled sheets.

## Printing the Internal Font List

The MFC prints a list of its internal or resident fonts. Use this font list to see how each font looks before you select it.

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 2.
- 4. Press 1.
- 5. Press 1.
- 6. Press **Start**.
  The MFC will start printing.
- 7. The MFC has finished printing the list.
- 8. Press Stop to exit.

## THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1. FAX 2. PRINTER

2.PRINTER

1.PRINT OPTIONS

1.INTERNAL FONT

PRESS START KEY

PRINTING

1.INTERNAL FONT

## Printing the Print Configuration List

The MFC prints a list of the current settings that configure or set up the printer.

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 2.
- 4. Press 1.
- 5. Press 2.
- 6. Press **Start**.

  The MFC will start printing.
- 7. The MFC has finished printing the list.
- 8. Press Stop to exit.

## THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1.FAX 2.PRINTER

2.PRINTER

1.PRINT OPTIONS

2.CONFIGURATION

PRESS START KEY

PRINTING

2.CONFIGURATION

#### Restoring to the Factory Default Settings

You can restore the MFC's printer to the factory default settings. The permanent fonts will be restored, but macros will be cleared. You can change the user settings with the Remote Printer Console program. (See the Setup Manual page 34~35.)

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 2.
- 4. Press 2.
- 5. Press 1.
- 6. Press 1.
- 7. Press Stop to exit.

#### THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1. FAX 2. PRINTER

2.PRINTER

2. RESET PRINTER

1.FACTORY SET

1.RESET 2.EXIT

FACTORY SETTINGS

1.FACTORY SET

#### Printing PC Data in Hexadecimal

The MFC can print data as hexadecimal values, so that you can check data errors and problems. If you set HEX DUMP MODE, all the PC data will be printed in hexadecimal and you reset it by pressing **Shift** and **Test/Reset**.

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seconds.
- 3. Press 2.
- 4. Press 2.
- 5. Press 2.
- 6. Press 1.
- 7. Press Stop to exit.

## THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1.FAX 2.PRINTER

2.PRINTER

2.RESET PRINTER

2.HEX DUMP MODE

1.SET 2.EXIT

2.HEX DUMP MODE

09/12/1998 15:25 HEX DUMP MODE

## 10. PRINTING REPORTS AND LISTS

You can print the following lists and reports under function item 3. PRINT REPORTS.

Level one function	Level two function	Content	Page
	1. ACT. REPORT	The Activity Report lets you know whether transmissions and incoming faxes were received. TX means Transmit; RX means Receive.	122–124
	2. ALL DIAL	This is a list of the names and numbers that are stored in One Touch and Speed Dial memory, printed in One Touch and Speed Dial number order.	125
	3. TEL. INDEX	This is the same report as the All Dial list printed in alphabetical order.	
	4. COVERPAGE	This sample coverpage allows you to see the Cover Page format.	52
<fax area=""> 3.PRINT REPORTS</fax>	5. CALL BACK MSG	This sample Call Back message allows you to see the format.	58
REPURIS	6. USER OPTIONS	The settings for FUNCTION MENU 5 to 8 (User Options, Tel Options, Setup System and Remote Fax OPT) are listed.	
	7. XMIT REPORT	You can choose whether the Transmission Verification Report will be printed after all faxes you send. ON/OFF	126–127
	8. MEMORY STATUS	Summary information and the amount of occupied memory for items stored in the memory will be listed.	127
	9. CALLER ID	You can review calls you received by checking this list.	87–88

NOTE: If the MFC's engine has entered the sleep mode (see pages 17–18) and the engine has started to cool down (the cooling fan may still be running), the MFC will have to warm up before printing the above lists and reports. The LCD will show WARMING UP.

#### **Other Reports**

The following reports are printed automatically, for your information:

Help List (By pressing **Help** on the control panel.) (See page 14.) Polled Report

Delayed Sending Report

Broadcast Report

Sequential Polling Report

Transmission Verification Report

#### How to Print Reports and Lists

All the reports and lists may be printed as follows:

#### KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seceonds.
- 3. Press 1.
- 4. Press 3.
- 5. Press the number of the level two function you wish to print.
  Example: 1.ACT.REPORT.
- 6. Press Start.

## THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

ENTER NO. & SET

1. FAX 2. PRINTER

1.FAX

3.PRINT REPORTS

1.ACT.REPORT

PRESS START KEY

PRINTING

An Activity Report can be printed at certain intervals that you specify. You can set the journal period to "OFF", "6 hours", "12 hours", "24 hours", "2 days", "4 days" or "7 days". The Activity Report will list all outgoing and incoming faxes (only the last 50) during that period. The factory default setting is OFF.

After the Activity Report has printed at the preset interval, the information will be deleted and cannot be recovered. However, at any time between these scheduled reports, you can manually print the Activity Report and the information will remain.

NOTE: If your Activity Report is not listing all your transactions, select a shorter interval period.

## KEYS TO PRESS THE DISPLAY WILL SHOW: 09/12/1998 15:25 ONLINE 1. Press Function. ENTER NO. & SET 1. FAX 2. Wait for two seconds. 2.PRINTER 3. Press 1. 1.FAX 4. Press 7. 7.SETUP SYSTEM 5. Press 3. 3. INTERVAL ACT.RPT.:OFF SELECT ← → & SET **EVERY 12 HOURS** to choose the setting. Example: 12 HOURS. If you select seven days, you will be

prompted to choose the base day of the week.

- 7. Press Set.
- 8. Enter the time to print in 24-hour format using the key pad keys. Example: 19:45 (7:45P.M.).

START AT: 00:00

START AT:19:45

9. Wait for two seconds.

3.INTERVAL

10. Press **Stop** to exit.

#### ACTIVITY REPORT

TIME : 09/12/1998 19:45

NAME : BROTHER FAX : 4155554444 TEL : 4155554445

DATE	TIME	FAX NO./NAME	DURATION	PAGE(S)	RESULT	COMMENT
09/12	10:00	BROTHER BOSTON	04:23	20 CV CA	0K	TX
09/12	10:10	NJ OFFICE	00	00	NG	TX
09/12	14:53	BROTHER BOSTON	48	01 CV CA	ок	l tx l

BUSY: BUSY/NO RESPONSE


NG : POOR LINE CONDITION
CV : COVERPAGE

CV : COVERPAGE
CA : CALL BACK MSG
POL : POLLING
RET : RETRIEVAL

NOTE: "TX" means Transmit, "RX" means Receive.

#### Printing the All Dial List

You can print a list of all stored One Touch numbers and Speed Dial numbers.



#### Transmission Verification (Xmit) Report

The Transmission Verification Report can be used as proof that you sent a fax. It lists the name or fax number of the receiving party, the time and date of transmission, and whether the transmission was successful. The factory default setting is OFF.

OFF: The report will be printed automatically only if an error occurs during transmission. If the report says "Result: NG" then send all the pages again. If the report says "Result: Check readability of transmitted page(s) 02, 05" then send only pages 2 and 5 again.

ON: A report will be printed automatically. It is important to read the result of each report to check that the transmission was successful.

## KEYS TO PRESS

- 1. Press Function.
- 2. Wait for two seceonds.
- 3. Press 1.
- 4. Press 3.
- 5. Press 7.
- 7. Press Set.
- 8. Press Stop to exit.

# THE DISPLAY WILL SHOW: 09/12/1998 15:25 ONLINE

ENTER NO. & SET

1. FAX 2. PRINTER

1.TEMP.SETTINGS

3. PRINT REPORTS

7.XMIT REPORT

XMIT REPORT:OFF

SELECT ← → & SET


XMIT REPORT: ON

7.XMIT REPORT

TRANSMI	SSION VERIFICATION REPORT
	TIME : 09/12/1998 15:25 NAME : BROTHER FAX : 4155554444 TEL : 4155554445
DATE, TIME	09/12 15:24
FAX NO./NAME	NJ OFFICE
DURATION	00:00:45
PAGE(S)	01
	COVERPAGE
RESULT	OK
MODE	STANDARD

#### Memory Status List

The MEMORY STATUS LIST will show you summary information and the amount of occupied memory for items stored in the memory such as Delayed Transmissions and Polled Waiting. You will see the combined total of stored fax messages for retrieval. The available memory is expressed as percentage of remaining memory.



You received two FAX messages :

- (A) When the fax came in
- (B) Sending party's number

This shows that you have three items in the MFC's memory for timer, polling and redial transmissions.

This shows the Fax Forwarding number.

 This shows the amount of available memory.

#### 11. HOW TO USE THE COPY FUNCTION

Use the **Copy** key to make a single copy or multiple copies. When making copies, check that the text or image on the original document is not too close to the edge. Your MFC cannot read anything closer than 4 mm (1/8 inch) from the edge. Original documents should be straight and not wrinkled or they may jam. Also, do not pull on the paper while copying is in progress or you may distort the image and damage your MFC.

Make sure there is enough paper in the MFC. And when making multiple copies, do not let the paper tray become overstacked. Remove copies from the paper tray.


Set the resolution to either PHOTO, FINE or S.FINE. If you select STANDARD, the resolution will change automatically to S.FINE. However, when you make a single copy and select S.FINE, the resolution may change automatically to FINE in case memory is used for memory transmission.

#### Making a Single Copy

#### KEYS TO PRESS

- Insert the documents face down into the feeder.
- 2. Press Copy.
- 3. Press Copy or just wait for five seconds.

## THE DISPLAY WILL SHOW:



#### Stacking Multiple Copies

#### KEYS TO PRESS

- Insert the documents face down into the feeder.
- 2. Press Copy.
- 3. Enter two digits for the number of copies you want using the key pad (max. 99 copies).

  Example: 05.
- 4. Press Copy or just wait five seconds.
- 5. The MFC will begin copying.

## THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

FAX: NO. & START SCAN READY

COPY: PRESS COPY SCAN READY

NO.OF COPIES:01 ONLINE

ENTER & COPY KEY

NO.OF COPIES:<u>0</u>5 ONLINE

COPY STACK ONLINE

COPY STACK P.01 ONLINE

#### FOR YOUR INFORMATION

What to Do When You Get a MEMORY FULL Message while Making Copies

When you are making copies, if the memory becomes full and the display shows PRESS STOP KEY, then press **Stop** to abort the job.

In this case, you can make only a single copy that is not reduced or enlarged.

NOTE: If you purchase the optional 1 or 2 MB of memory for your MFC 4550 plus, the copy function will include an additional step that allow you to sort multiple copies.

Use this function to make reduced or enlarged copies of a document. Select Auto Reduction (AUTO) if you want to reduce the size of the original, regardless of its size, to the size of the paper. To enlarge or reduce a document, select one of the enlargement/reduction ratios: 200%, 150%, 125%, 120%, 93%, 87%, 75% or 50%. If you want to reproduce the same size, select 100%.

When enlarging, any portion that extends outside the edge of the printing paper will be cut off.

#### KEYS TO PRESS


- Insert the documents face down into the feeder.
- Press Reduce or Enlarge. Example: Reduce
- - If you want Auto Reduction, select AUTO, or the reduction or enlargement ratio.


Example: 93%

- 4. Press Copy.
- Enter two digits for the number of copies you want, using the key pad keys (max. 99 copies).

Example: 05

- 6. Press Copy or just wait for five seconds.
- 7. The MFC will begin copying.





COPY STACK ONLINE	
COPY STACK ONLINE	P.01

#### Copying a Photograph

You can copy a photograph by pressing  $\boldsymbol{Photo},$  without pressing  $\boldsymbol{Resolution}.$ 

#### KEYS TO PRESS

- 1. Insert the documents.
- 2. Press Photo.
- Enter two digits for the number of copies you want, using the key pad (max. 99 copies).
   Example: 05.
- 4. Press Copy or just wait five seconds.
- 5. The MFC will begin copying.

#### THE DISPLAY WILL SHOW:

09/12/1998 15:25 ONLINE

FAX: NO. & START SCAN READY

COPY: PRESS COPY SCAN READY

NO.OF COPIES:01 ONLINE

ENTER & COPY KEY ONLINE

NO.OF COPIES:05 ONLINE


COPY STACK ONLINE

COPY STACK P.01 ONLINE

# 12. REPLACING TONER CARTRIDGE AND DRUM UNIT

#### Toner Empty Indicator

When the toner cartridge is running low, the display will show CHANGE TONER and the Toner Empty LED on the control panel will flash on and off to indicate the toner is low.



The Toner Empty LED will light and the display will show CHANGE TONER and TONER EMPTY alternately to indicate that the toner is empty. Once this indication appears, your MFC will not resume printing until you have installed a new toner cartridge.

#### Replacing the Toner Cartridge


The MFC can print approximately 2,200 pages with one toner cartridge. When the toner cartridge is running low, the display shows CHANGE TONER. The MFC is supplied with a starter toner cartridge that must be replaced after 1,000 pages.

- NOTE: Actual page count will vary depending on your average document type. (i.e., standard letter, detailed graphics, etc.)
  - It is recommended that you always keep a new toner cartridge ready for use for when you see the toner low warning.
  - Discard the used toner cartridge according to local regulations. If you are
    not sure of them, consult with Brother Customer Service. Be sure to seal
    the toner cartridge tightly so toner powder does not spill out of the
    cartridge. When discarding used toner cartridges, keep them separate
    from domestic garbage.
  - It is recommended that you clean the MFC when you replace the toner cartridge.

Follow these steps to replace the toner cartridge:



1) Turn off the power switch and unplug the power cord.




 Open the top cover. To remove the drum unit, hold each side of the drum by its handles and gently lift the drum forward toward you.

NOTE: • Make sure the top cover is completely open, by lifting it until the latch clicks into place.


 We recommend that you place the drum unit on a drop cloth or large piece of disposable paper to avoid spilling and scattering the toner.

#### WARNING

Just after you have used the MFC, some internal parts of the machine will be extremely **HOT!** So, never touch the shaded parts shown in the left illustration.




3) Gently turn the lever on the toner cartridge forward until it stops. The toner cartridge cannot be removed unless the shutter is completely closed, by turning the lever fully to the front.



 Remove the old toner cartridge from the drum unit by gently pulling it out.

#### **WARNING** -


Handle the toner cartridge carefully. If toner scatters on your hands or clothes, immediately wipe it off or wash it with cold water.




5) Unpack the new toner cartridge. Place the used toner cartridge into the aluminum bag and discard it according to local regulations.

#### **WARNING** -


- Wait to unpack the toner cartridge until immediately before you install it into the MFC. If a toner cartridge is left unpacked for a long period of time, the toner life is shortened.
- You can use only a genuine Brother toner cartridge (TN-5000PF series), which is specially formulated to ensure top print quality. Using another brand of toner cartridge may void your MFC's warranty.




6) Gently rock the toner cartridge from side to side five or six times.



7) Slide the new toner cartridge into the opening on the right hand side of the drum unit. To ensure that the toner cartridge and the drum unit fit together correctly, make sure that the toner cartridge guide bar is exactly aligned with the guide slot in the drum unit.



8) Gently turn the lever on the toner cartridge backward until it stops.



9) Reinstall the drum unit into the MFC and close the top cover. Then, turn on the power switch or plug in the power cord.

#### Replacing the Drum Unit

The MFC uses a drum unit to create the print images on paper. If the display shows CHANGE DRUM, it indicates the drum unit is nearly at the end of its life. We recommend that you prepare a new drum unit to replace the current one. Even if the display shows CHANGE DRUM, you may be able to continue to print without replacing the drum unit for a while. If there is a noticeable deterioration in the output print quality even before CHANGE DRUM is shown, then the drum unit should be replaced.

#### WARNING


- When removing the drum unit, handle carefully because it contains toner.
- You should clean the MFC when you replace the drum unit. See pages 141–143.

NOTE: The drum unit is a consumable, and it is necessary to replace it periodically. The drum unit is rated at approximately 20,000 pages. There are many factors that determine the actual drum life, such as temperature, humidity, type of paper and toner that you use and the number of pages per print job, etc. The drum life is estimated at approximately 20,000 pages at 20 page per job and 8,000 pages at one page per job. The actual number of pages your drum will print may be significantly less than these estimates. Because we have no control over the many factors that determine the actual drum life, we cannot guarantee a minimum number of pages that will be printed by your drum.

For best performance, use only genuine Brother toner, and the product should be used only in a clean, dust-free environment with adequate ventilation.

Follow these steps to replace the drum unit:


- 1) Turn off the power switch or unplug the power cord.
- 2) Open the top cover.



3) Remove the old drum unit. (See page 134.)

#### WARNING


Just after you have used the MFC, some internal parts of the machine are extremely **HOT!** So please be careful. (See page 142.)




 Remove the toner cartridge from the drum unit and keep it in a safe place. For more information, see "Replacing the Toner Cartridge" on pages 133-136.

NOTE: • Discard the used drum unit according to local regulations. If you are not sure of them, consult with Brother Customer Service. Be sure to seal the drum unit tightly so toner powder does not spill out of the unit. When discarding used drum units, keep them separated from domestic garbage.

 We recommend you place the drum unit on a drop cloth or large piece of disposable paper to avoid spilling and scattering the toner.




5) Wait to unpack the new drum unit until immediately before installing it. Place the old drum unit into the aluminum bag and discard it according to local regulations.




6) Gently rock the new drum unit side to side five or six times.

#### - WARNING -

- Do not remove the starter sheet.
- Wait to unpack the drum unit immediately before installing it into the MFC. If an unpacked drum unit is subjected to excessive direct sunlight or room light, the unit may be damaged.
- Handle the toner cartridge and the drum unit carefully because it contains toner. If toner scatters and your hands or clothes get dirty, immediately wipe or wash it off with cold water.
- 7) Reinstall the toner cartridge into the new drum unit. For more information, see "Replacing the Toner Cartridge" on pages 133–136.



8) Holding the new drum unit by its handles, install it. Close the top cover.



9) Turn on the power switch or plug in the power cord. The MFC automatically will eject the starter sheet.


# Regular Maintenance

You can keep your MFC in optimum condition by cleaning it on a regular basis. It is a good idea to replace the toner cartridge and the drum unit during this routine. Avoid using thinners or other organic solvents to clean the MFC and do not use water.

#### Follow the steps below:


- 1. Unplug the telephone line and then the power cord.


  When you reconnect these lines later, make sure to connect the power cord first, then the telephone line.
- 2. Wipe dirt off the MFC using a slightly damp clean cloth.
- Clean the white bar and the glass cover.
   Moisten a small piece of clean soft, lint-free cloth with isopropyl alcohol and carefully remove dirt from the glass cover and the white bar of the scanner.
- \* Do not use isopropyl alcohol to remove dirt from the control panel. It may cause a crack on the panel.
- 4. Wipe the gears and electric terminals with isopropyl alcohol on a cotton swab. Gently wipe the scanner window and the toner sensor with a clean soft dry cloth.



# WARNING

- Do not use isopropyl alcohol to clean the scanner window or the toner sensor.
- Do not touch the scanner window with your finger.
- Handle the drum unit carefully as it contains toner. If toner scatters and your hands or clothes get dirty, immediately wipe or wash it off with cold water.





#### WARNING-


Just after you have used the MFC, some internal parts of the MFC are extremely **Hot!** When you open the top cover of the MFC, never touch the shaded parts shown in the diagram to the left.

Shaded Parts are HOT!

#### Cleaning the Drum Unit

**NOTE:** We recommend that you place the drum unit on a drop cloth or large piece of disposable paper to avoid spilling and scattering the toner.

1. Turn the drum unit upside down carefully.



3. Return the tab to the home position (▲ mark position) before reinstalling the drum unit.

# CAUTION

If you do not position the tab at the home position, printed pages may have vertical stripes.


- 4. Install the drum unit into the MFC. See the section "Replacing the Drum Unit" on pages 137–139.
- 5. Close the top cover.
- 6. Plug in the power cord and turn on the power switch.

#### Packing and Shipping the MFC


Whenever you transport the MFC, use the packing materials that came with your MFC. Also, follow the steps below to pack the MFC or it may be damaged, which will void the MFC's warranty.

- 1. Turn off the power switch and unplug the MFC from the AC outlet.
- 2. Open the top cover.
- 3. Remove the drum unit assembly. To remove the drum unit, please refer to Step 2 on page 134.


NOTE: Remove the drum unit and toner cartridge. Leave the toner cartridge installed in the drum unit.




 ${\bf 4. \ \ Place \ the \ drum \ unit \ and \ toner \ cartridge \ assembly \ into \ the \ plastic \ bag \ and \ seal \ the \ bag \ completely.}$ 



- 5. Close the top cover. Remove the wire extension, document tray, dust cover, paper tray and handset and pack them.
- 6. Wrap the MFC in the plastic bag and place it in the original carton box with the original packing material.



7. Place any documents (manual and printed material) and the drum unit and toner cartridge assembly into the carton box as shown below.



8. Close the carton box and tape it shut.

#### Paper Jams


Your MFC will sound an alarm if the document jams while going through the feeder or if the paper becomes stuck. The display will show DOCUMENT JAM or PRINTER JAM.

# Fixing a Document Jam


- 1. Open the front control panel.
- 2. Remove the jammed documents.
- 3. Close the control panel.
- 4. Press Stop.

# Fixing a Paper Jam

Before you can clear a paper jam error, you must find out where the paper is stuck. Use the diagram below to help locate the position of the paper.




- Do not force the jammed paper from the paper tray because you may damage the MFC and cause toner to scatter on the next printed panels.
- After you have used the MFC, some internal parts of the MFC are extremely **HOT!** When you open the top cover of the MFC, never touch the shaded parts shown in the following diagram.




# 1. Clearing a paper jam in the multi-purpose sheet feeder.

If a paper is jammed inside the multi-purpose sheet feeder, open the multi-purpose sheet feeder to pull the jammed paper upward out of the feeder; then close the multi-purpose sheet feeder. Also, open the top cover and check that a torn piece of paper does not remain inside the MFC (see the next section.)




# 2. Clearing a paper jam near the drum unit.

If a paper is jammed near the drum unit, open the top cover and remove the drum unit. Then, pull the jammed paper upward and out of the MFC. Reinstall the drum unit and close the top cover.



# 3. Clearing a paper jam in the fuser unit.

If a paper is jammed in the fuser unit, open the top cover and remove the drum unit. Then, pull the jammed paper out of the fuser. Reinstall the drum unit and close the top cover.




# 14. OPTIONAL ACCESSORIES

# Connecting the Serial Interface Board (RS100M)

To connect your MFC to a DOS computer or to an Apple Macintosh computer, you must first install the optional serial interface board (RS100M). When you have installed a serial interface board, you can share the MFC with two computers, using both the parallel and the serial interface ports. Automatic interface selection is a standard feature when using the serial interface board.


# Installing the Serial Interface Board into Your MFC



1. Unplug the power cord from the AC outlet and disconnect the parallel interface cable.

#### WARNING


Be sure to unplug the power cord before installing or removing the serial interface board.




2. Unscrew the three screws securing the rear plate of the main controller board and pull out the main controller board.

#### WARNING

Do not touch the surface of the main controller board.




3. Unscrew the two screws and remove the option slot cover plate and keep it in a safe place.



- 4. To install the serial interface board onto the main controller board, plug the serial interface board into the upper left connectors on the main controller board.
- 5. Secure the serial interface board with the two screws.

#### WARNING -


- Hold the edge of the serial interface board. Do not touch the surface of the board.
- Make sure the serial interface board is securely seated on the main controller board.



- 6. Reinstall the main controller board in the MFC by sliding it into the guide rails.
- 7. Secure the main controller board with the three screws.

#### Selecting the RS-422A (Apple) or RS-232C (IBM) Serial Interface

- 1. Make sure the MFC is in the offline mode.
- 2. Select the serial interface port that matches your computer:
  - For Apple Macintosh computers, select the RS-422A (Apple) port by keeping the slide switch to the left (factory setting is RS-422A).
  - For IBM compatible computers with Windows® or PCs that operate with DOS, move the slide switch to the right (RS-232C).



### Setting the Serial Interface Parameters

Set the parameters to match your computer as follows:

- Never change the RS-422A parameters for Apple Macintosh computers. The RS-422A parameters have been set correctly at the factory for Apple Macintosh computers, so you do not have to change the setting. You may skip this section. If you change parameters for the RS-232C serial interface and then switch back to RS-422A for Apple Macintosh computers, be sure to restore the parameters to the factory setting.
- Set the RS-232C parameters to match your IBM compatible computer. You can set serial
  settings in several different places, within your DOS application, within the Windows®
  Printer Icon (for Windows® application software only), or within your AUTOEXEC.BAT
  file using MODE commands. For information on setting serial interface parameters, see
  the user's guide for your computer or software.

If necessary, set the serial interface parameters as follows:

1. Make sure the printer is in offline.




Table 1: Serial Interface Parameters Settings

Parameters On (up) Off (down) — See Table 2. – **Baud Rate** Baud Rate See Table 2. Data Length 7 bits 8 bits Stop Bit 2 bits 1 bit Parity - See Table 3. Parity See Table 3. Protocol Xon/Xoff + DTR DTR only Robust Xon On Off

Table 2: Baud Rate Settings

Selector 1	Selector 2	For RS-422A	For RS-232C
Off	Off	57600	9600
On	Off	9600	4800
Off	On	1200	1200
On	On	19200	19200

Table 3: Parity Settings

Selector 1	Selector 2	Parity
On	On	Odd
On	Off	Even
Off		None

- The factory settings are indicated in bold print.
- If the robust Xon setting is turned on with selector 8, the printer sends Xon signals at one second intervals to the connected computer until it receives data. It is effective only if selector 7 is set to the On position for the Xon/Xoff plus DTR setting.

# Main tenance

#### Connecting the Serial Interface Cable

To connect your MFC to your computer, you must use a serial interface cable with an 8-pin, DIN-type connector.

See your dealer to purchase a serial interface cable:

- If you are a Macintosh user, you can easily find the necessary cable at a local computer store. Look for Apple serial cables labeled "Macintosh to ImageWriter™ or "Macintosh to Personal LaserWriter™ 300." Do not purchase a serial cable labeled "Straight-thru" or "Local-Talk."
- If you are a PC user, you must purchase a special serial cable from your dealer. If you have
  a 9-pin connector on your computer, look for a cable labeled "IBM AT to ImageWriter II."
  If you have a 25-pin connector, look for a cable labeled "DB25 to ImageWriter II." These
  cables most likely can be found in the Apple Macintosh section of your computer dealer's
  store. For more information about the interface specification, consult with your dealer.

NOTE: The MFC can be connected to a parallel and a serial interface cable at the same time. The autointerface selection function allows you to share the MFC with two computers. To do this, first connect the parallel interface cable and then connect the serial interface cable.

Connect the serial interface cable as follows:

1. Make sure the power switch is turned off.

#### WARNING

Unplug the power cord before connecting or disconnecting the interface cables or you may damage the MFC.

- Insert and secure the serial interface connector into the serial interface port of your MFC.
- 3. Insert and secure the serial interface connector into the serial interface port of your computer.
- 4. Turn on the power switch.

#### **Memory Board**

The memory board is installed on the main controller board inside the MFC. When you add the optional memory board, it increases the performance modes for both fax and printer operations.

#### Optional Memory for the Printer & Fax Operations

The MFC can recognize 1MB (ME1000) or 2MB (ME2000) of Optional Memory. Be careful to purchase the appropriate memory board for your needs.

#### For the Printer

Additional memory is useful and may be necessary if you want to download many different fonts or want to print a very complex document.

#### For the Fax


Additional memory is available and will expand the memory used for sending and receiving faxes.

Model Name	Optional Memory	Total
MFC 4550 plus 300 KB (up to 30 Pages)	1 MB (0.4 MB for Fax)	0.7 MB (up to 70 Pages)
300 KB (up to 30 Pages)	2 MB (0.9 MB for Fax)	1.2 MB (up to 120 Pages)

<sup>\*</sup> Using Brother #1 chart with MMR coding and Standard Resolution.

#### For the Copier


Additional memory will allow you to sort multiple copies (max. 60 pages).



1. Unplug the power cord from the AC outlet and disconnect the interface cable.

#### WARNING


Unplug the power cord before installing (or removing) the memory board.



2. Unscrew the three screws securing the main controller board plate and pull out the board.

#### WARNING

Do not touch the surface of the main controller board.




3. To install the memory board onto the main controller board, use the attached spacer and plug it into the lower right connectors of the main controller board.



#### WARNING-

- Hold the edge of the memory board. Do not touch the surface of the board.
- Make sure the memory board is securely seated in the main controller board.



- 4. Reinstall the main controller board in the MFC by sliding it into guide rails.
- 5. Secure the main controller board with the three screws.
- 6. Reconnect the interface cable.
- 7. Plug the power cord into the AC outlet.

# 15. TROUBLESHOOTING PROCEDURES

#### Fax-Back System

Brother Customer Service has installed an easy-to-use Fax-Back System, so you can get instant answers to common technical questions and product information for all Brother products. This system is available 24 hours a day, 7 days a week. You can use the system to send faxes to any fax machine, not just the one from which you are calling.

If you can't resolve difficulty with your MFC using this manual, call our Fax-Back System, and follow the voice prompts to receive faxed instructions about using the system, and an index of Fax-Back subjects.

USA:

1-800-521-2846

From within Canada: 1-800-681-9838

The Brother Fax-Back System number (USA only) is preprogrammed on One Touch key 01.

#### Brother on the World Wide Web

You can find more information about Brother products, from product specification sheets to Frequently Asked Questions (FAQs), on the World Wide Web. Visit us at

http://www.brother.com

### Brother Bulletin Board

Brother's Bulletin Board Numbers are

1-714-859-2610

From within Canada: 1-514-685-2040

Occasionally, you may have a problem with your MFC or telephone line. If this happens, your MFC usually identifies the problem and displays an error message. Refer to the following list when you see an error message on the display.

Error messages are listed below in alphabetical order.



This means an overflow of the input data buffer. Press **FF/Cont**. Data that overflowed the buffer will not be printed.

Check the communication parameter settings such as handshake protocol on both your computer and MFC.

If the error occurs again, the interface hardware may be damaged, so consult with your dealer.

C CHANGE DRUM

You can clear a print quality problem by replacing the drum unit with a new one if the display shows CHANGE DRUM. The drum unit is at the end of its life.

CHANGE TONER

If the display shows CHANGE TONER and at the same time the Toner Empty LED on the control panel flashes on and off, you can still print. But the toner is depleted and it is telling you that the toner will soon run out. Order a new toner cartridge now.

CHANGE TONER
TONER EMPTY

The toner is used up and printing is not possible. Replace the toner cartridge with a new one. (See pages 133–136)

CHECK PAPER


The MFC is out of paper or the paper is not properly loaded in the multi-purpose sheet feeder. Refill the paper or remove the paper and load it again.

CHECK PAPER SIZE

Your Paper Size setting may not be set correctly for the paper you are using (see page 66). When you see this error, the reduction ratio automatically will be changed to AUTO if you have used a fixed reduction ratio (see pages 67–68).

A poor quality phone line caused a COMM. ERROR communications error. Try the call again. You requested the polling function even CONNECTION FAIL though the machine you called does not have the polling feature. When the temperature of the drum unit or COOLING DOWN toner cartridge becomes too hot, the MFC will pause its current print job and go into cooling PLEASE WAIT down mode. During the cooling down mode you will hear the cooling fan running while the display on the MFC shows COOLING DOWN and PLEASE WAIT. You must wait and allow the MFC to resume printing when it is ready. The top cover or multi-purpose sheet feeder COVER OPEN cover was not completely closed. Please check each of them. The telephone line was disconnected by the DISCONNECTED D other party during the communication. Try calling the other party to see what happened. Your documents were not inserted properly, DOCUMENT JAM or the documents were not fed properly, or the documents were too long. Open the control panel and remove the documents. (See page 146) Then close the control panel, press Stop and insert the documents again, adjusting the guides on either side of the document, and try sending the fax again. Original documents should be straight, nonwrinkled, to be correctly fed. Otherwise, the documents may occasionally jam. The download buffer is full. Press FF/Cont. Printing will resume (the downloading is DOWNLOAD FULL canceled). The command that caused this message will be ignored. There is a communications error. If you are using a serial interface, check baud LINE ERROR rate, parity, etc. If you are using a parallel

interface, check the cable connections.



Turn off the power. Then contact the Customer Service number listed on page 181.

MEMORY FULL

- Press the **FF/Cont** switch to print the data remaining in the MFC.
- If you have installed the Windows® driver, try again after setting the True Type mode to "Print as Graphics" in the PRINT menu of your application software.
- Expand the printer memory with the optional memory board. (ME1000 or ME2000)
- Reduce the print resolution or reduce the complexity of your document.

N NO RESPONSE/BUSY

The number you called does not answer or is busy. Or, you may have reached a number that is not connected to a fax machine. Check the number and try again.

NOT REGISTERED

The One Touch key or Speed Dial number you pressed has no number assigned to it. You will have to program a phone number. (See pages 24–26)

P PRINT OVERRUN

- Press the **FF/Cont** switch to print the data remaining in the printer memory.
- If you have installed the Windows® printer driver, try again after setting the TrueType mode to 'Print as Graphics' in the PRINT menu of your application software.
- If this does not clear the error, reduce the complexity of your document or reduce the print resolution.

PRINTER JAM

The recording paper is stuck in the printing area. Remove the jammed paper. (See pages 146–148.)

SET CARTRIDGE

 $\Lambda$  toner cartridge is not installed. Reinstall the toner cartridge.

# If You are Having Difficulty with Your MFC

# When the Receiving Party Says the Picture is Not Clear

Sometimes the resolution mode you chose when you sent your fax may not have been appropriate. Send the fax again, but try using the FINE or SUPERFINE mode. Also, your MFC's scanner may be dirty, so try cleaning it. (See pages 141–142.)

# When the Receiving Party Says Vertical Streaks Appear on the Faxes They Receive:

Your MFC's scanner may be dirty or the receiving party's print head may be dirty. Clean your scanner, (see pages 141–142) and make a copy to check if the problem was caused by your MFC.

#### Vertical Streaks Appear on the Faxes You Receive


Sometimes you may see vertical streaks on the faxes you receive. Either your MFC's primary corona wire for printing may be dirty, or the sending party's fax scanner may be dirty. Clean your primary corona wire. (See pages 142–143.) Make a copy to see if the vertical streaks are still there.

#### Vertical Streaks Appear in Copies

Sometimes you may see vertical streaks on your copies. Either the scanner or the primary corona wire for printing is dirty. Clean them both. (See pages 141–143.)

# If the Printed Pages are Still Blurred at the Center or Either Edge as Below First, make sure that the printer is placed on a flat, horizontal surface.

If the problem still occurs, remove the drum unit with the toner cartridge installed. Hold the unit horizontally with both hands and tap it firmly against a flat surface 3 or 4 times. Reinstall the drum unit with the toner cartridge and try printing again. If the print quality is acceptable, you may continue using this drum unit. If the print quality is not acceptable replace the drum unit. If streaks still occur, please contact Brother Customer Service or your local Authorized Service Center for further assistance.



#### **Horizontal Streaks**

You may get a fax with horizontal streaks or with missing lines. Usually this is caused by a poor telephone connection. Ask the other party to send the fax again.


#### **Poor Printing Quality**

If the printing quality is not at an acceptable level, please replace your drum unit with a new one.

The Print is too Light or too Dark

The print density dial is located in the corner under the top cover. (Remove the drum unit assembly.) You can use it to adjust print density by increasing or decreasing the Print Density function setting you chose.

The print may become darker or lighter as conditions change (such as changing the toner cartridge and drum unit or if the MFC has become overheated from heavy use).



Use a straight blade screwdriver to turn the print density dial clockwise for darker print and counterclockwise for lighter print. The dial has been set to the middle position.

Make five or six copies to bring the toner up to the level of the new setting.

If the print is still too light, check to see if the Toner Save feature is ON (see page 70).

#### Received Faxes Appear as Split or Blank Pages:

If the received data is divided and printed on two pages or if you get an additional blank page, your Paper Size setting may not be correct for the paper you are using (see page 66). If you are using the fixed reduction feature, check to see if the reduction ratio is suitable for the real paper (see pages 67–68).

#### When Dialing Doesn't Work...

You may have the wrong dialing mode. Change the TONE/PULSE setting. (See page 19.) You should check all the telephone line connections (such as to the handset and to the wall jack). Check also that the power cord is connected and the power switch is turned on. (See page 9 of Setup Manual for Fax, Printer, Copier.) Check by pressing **Hook** to see if you hear a dial tone. Also try dialing by first pressing **Hook** or lifting the handset. Wait until you hear the fax tones and then press **Start**.

#### MFC Does Not Answer When Called:

Make sure the MFC is in the correct receiving mode for your setup (either FAX, F/T or TAD). Check for dial tone. If possible, call your MFC to hear it answer. If there is still no answer, check the telephone line cord connection. Connect a standard telephone handset to the MFC telephone jack. If there is no ringing when you call your MFC, call your Telephone Company to check the line.

#### No Dial Tone on the Handset:

Press **Hook**. If you do not hear a dial tone, check telephone line cord connections at the MFC and the wall jack. Check that the handset is connected to the MFC's handset jack. Test the wall jack with another single line telephone. If there is no dial tone on the wall outlet, call your Telephone Company.

#### **Double Ring in F/T Mode:**

The MFC knows the incoming call is not a fax, so it is signaling you to answer the telephone call. Pick up the MFC's handset or answer from an extension phone and press your MFC's Remote Deactivation Code (the default setting is #51).

#### Problem using the HP Pavilion PC and the "HP DEMO" Screen Saver

If you select the "HP Demo" screen saver on your HP Pavilion PC after you have installed the Multi-Function Link Pro software, the System.ini file is overwritten and you cannot use the Brother MFC to print, scan or for Remote Setup.

If you have used the HP Demo screen saver already, you must edit the System.ini file as follows:

[boot] ;comm.drv=comm115.drv comm.drv=brmfcomm.drv

[386Enh]

DEVICE=C:\WINDOWS\SYSTEM\Bi-Di.386

If you do not want to edit the System.ini file, please change the screen saver to another one and Re-install Multi-Function Link Pro again.

#### Bi-Directional Parallel Ports (Nibble and Byte modes):

The MFC 4550 plus supports both nibble (AT) and byte (bi-directional) mode parallel ports. If your PC supports byte mode, scanning and fax reception will be at a faster speed. To verify or change the parallel port mode, please check your system BIOS in the CMOS Setup or contact your computer manufacturer for assistance.

**NOTE:** Some older PC models support only nibble mode. Generally, newer models support both nibble and byte modes.

### MFC Connect Failure or Bi-Directional Communication Error

Recently, some printers have included a function to show the printer status on the PC display. Such printers use the bi-directional communication parallel port between the printer and the PC. Our MFC 4550 plus also has a bi-directional parallel port function. Since Windows® 3.xx does not support bi-directional communication on the parallel port, each peripheral vendor has developed and supplies their own bi-directional device driver, which will be installed into Windows® 3.xx. If you install two or more different bi-directional device drivers into Windows®, they might conflict with each other and cause some problems.

Please make sure you have installed the MFC 4550 plus driver by executing SETUP.EXE from your CD-ROM drive, as instructed on the CD-ROM label. The bidirectional communication may be disabled when the driver is installed from Add menu in "Printers" of the Control Panel. Please restart Windows®.

Remove the conflicting situation caused by one of the following printer drivers. Review the following sections that apply to any additional printer drivers you may have installed into your Windows® software.

Brother HL-6/6V/10h/630series/660series/960/1260/WL-660 HP LaserJet series II, IID, IIP, IIP+, III, IIID,IIIP or IV Plus NEC SuperScript 610/660 EPSON ActionLaser 1100/1400 LexMark WinWriter 200

#### Brother HL-6/6V/10h/630series/660series/960/1260/WL-660:

The Resource Manager for MFC 4550 plus may not work if the printer driver for the above models are installed after the installation of the MFC 4550 plus printer driver.

In this case, please install the MFC 4550 *plus* printer driver again or copy BI-DI.386 from the Brother CD-ROM to the Windows®/System directory. (**NOTE:** BI-DI.386 on CD-ROM is not compressed.)

#### HP LaserJet series II, IID, IIP, IIP+, III, IIID or IIIP:

If Microsoft Windows® Printing System for above models are used, you have to modify the "win.ini" file which is in the Windows® directory to turn the printer's bi-directional function off.

We recommend that you perform a backup before you modify the WIN.INI or SYSTEM.INI, just in case.

Open the file "win.ini" by using the "Notepad" application. You can find the following statement in the [spooler] section.
[spooler]

QP.LPT1 = wpsljqp.dll

To disable this function, put a semicolon at the head of above sentence as follows; [spooler]

;QP.LPT1 = wpsligp.dll

Then, open the file "system.ini" by using the "Notepad" application. You can find the following statement in the [386Enh] section.

[386Enh] device=wpsljvpd.386 :

WPSLPT1=1

To disable this function, put a semicolon at the head of above sentences as follows;

You must restart Windows® to make these modification effective. The modification disables the printer status reporting on your PC, however, you will be able to use MFC  $4550 \ plus$  with no further problems.

#### **HP LaserJet 4 Plus:**

Please uninstall the Main Status windows by double clicking the Un-install Status windows in HP LaserJet group.

#### NEC SuperScript 610/660:

Please remove the NEC SuperScript driver by having NECDELET.EXE run in the Disk 1 coming with NEC printers.

#### EPSON ActionLaser 1100 / 1400:

Please remove the EPSON Action Laser 1100/1400 driver by having EPDELETE.EXE file in Windows® Printer Driver for these models run.

#### Lexmark WinWriter 200:

You have to modify the "win.ini" and "system.ini" files, which are in the Windows® directory to turn the printer's bi-directional function off.

We recommend you to back-up WIN.INI and SYSTEM,INI before you modify them.

Open the file "win.ini" by using the "notepad" application. You can find the following statement in the [windows] section.

[windows]

run=C:/WINDOWS/SYSTEM/WPSIOMON

To disable this function, put a semicolon at the head of above sentence as follows; [windows]

:run=C:/WINDOWS/SYSTEM/WPSIOMON

Also, You can find the following statement in the [spooler] section. [spooler]

QP.LPT1=wpslbq.dll

To disable this function, put a semicolon at the head of above sentence as follows; [spooler]

;QP.LPT1=wpslbq.dll

Then, Open the file "system.ini" by using the "Notepad" application. You can find the following statement in the [386Enh] section.



```
[386Enh]
device=wpscomd.386
device=wpsljvpd.386
:
:
WPSLPT1=1
```

To disable the function, put a semicolon at the head of above sentences as follows;

```
[386Enh]
;device=wpscomd.386
;device=wpsljvpd.386
:
:
;WPSLPT1=1
```

You must restart Windows® to make these modification effective.

The modification disables the printer status reporting on your PC, however, you will be able to use the MFC  $4550 \ plus$  with no further problems.

# Graphics or Text is Missing when the Document is Printed

This could be caused by your Display Driver software. Contact your reseller and inquire about the latest Display Driver software. Another solution is to change your Windows® Setup Display selection from the current selection to the standard VGA or SVGA selection; contact your reseller or Microsoft Support if you need help modifying your Windows® Display selection or installing new Display Driver software.

# $Trouble shooting\ Tips$

This section contains questions and answers for using your MFC, if you are having difficulty:

# **Setting Up the MFC**

Difficulty	Suggestions	
The MFC does not print.	Check the following:  • The MFC is turned on.	
*	The toner cartridge and drum unit are installed properly.	
	• The interface cable is securely connected between the MFC and computer.	
	• Check to see if the LCD is showing an error message. (See pages 158–160.)	

# Windows® Setup Printing Difficulties

Difficulty	Suggestions
I cannot print from my application software.	<ul> <li>Make sure the Windows<sup>®</sup> printer driver is installed and you selected it in your application software.</li> </ul>
	• If you use the optional serial interface, make sure the serial slide switch of the serial interface is in the correct position and the DIP switches interface settings are correctly set up.
Sometimes I get an error message, PRINT OVERRUN when printing certain documents from Windows <sup>®</sup> .	<ul> <li>If you are using the supplied Windows® driver, turn the error recovery operation on in the Setup dialog box and try again.</li> <li>Reduce the print resolution or reduce the complexity of your document and try again.</li> <li>Expand the printer memory by installing one of the optional memory boards.</li> </ul>

# **DOS Setup Printing Difficulties**

Difficulty	Suggestions
	puggestions
I cannot print from my application software.	<ul> <li>Check that the DOS application software interface settings match those of your printer: for example, if you are using a parallel printer cable, you would probably set your DOS software printer port to LPT1.</li> </ul>
	• Check for an error message on the LCD.
	If you are using the RS100M serial interface board, make sure the RS-232C serial interface is selected with the slide switch. Make sure the interface settings are correctly set up with the proper DIP switches. Make sure the serial parameters for baudrates, parity and stop bits match those in your application software and the MFC.
The MFC prints, but it prints incorrect information. Sometimes it prints a couple of characters and then ejects the page, etc.	This is an indication that your application printer emulation setting and the MFC's printer emulation do not match. Check your application software to make sure you selected the correct printer driver. The MFC emulates HP LaserJet IIP. Try setting the MFC to HP emulation in Remote Printer Console and then select the HP LaserJet IIP printer in your application software.
The MFC prints the first part of my document but does not print the last page. (The LCD shows REMAINED DATA.)	This is a common problem with database software and spreadsheet software when they are not correctly set up. The data has been sent to the printer but the printer did not receive the Page Eject command. Press the FF/Cont Key to eject the page. Then ask your software supplier how to add a Page Eject (or Form Feed) command to the end of your print job.
How can I change the User settings or default settings on the MFC?	Use the Remote Printer Console (RPC) program.

# Optional Apple Macintosh Serial Interface Board (RS100M) Setup Printing Difficulties

Difficulty	Suggestions
I cannot print from my application software.	Make sure you installed the Macintosh printer driver in the System Folder and selected it with Chooser.
	<ul> <li>Check the PORT selection within the Chooser: it should match the port to which you physically attached the printer cable.</li> </ul>
	• The serial slide switch on the optional interface board should be in the Apple (RS-422A) position.
,	<ul> <li>Check the printer cable type: you cannot use a LocalTalk or straight-through cable. See Chapter 14 for details on different types of printer cables.</li> </ul>

# **Paper Handling Difficulties**

Difficulty	Suggestions
The MFC does not load paper. The LCD shows CHECK PAPER or PRINTER JAM.	<ul> <li>Check to see if the CHECK PAPER or PRINTER JAM message appears on the LCD. If so, the multi-purpose sheet feeder may be out of paper or not properly installed. If it is empty, load a new stack of paper into the feeder.</li> <li>If there is paper in the multi-purpose sheet feeder, make sure it is straight. If the paper is curled, you should straighten it. Sometimes it is helpful to remove the paper, turn the stack over and put it back into the paper tray.</li> <li>Reduce the amount of paper in the multi-purpose sheet feeder, then try again.</li> </ul>
The MFC does not load paper from the manual feed stop.	Reinsert the paper firmly, one sheet at a time.
How can I load envelopes?	You can load envelopes from either the multi-purpose sheet feeder or the manual feed slot. Your application software must be set up to print the envelope size you are using. This is usually done in the Page Setup or Document Setup menu of your software. Refer to your application manual.
What paper can I use?	You can use plain paper, envelopes, transparencies, labels, and organizer paper. For information on loading paper. See "Acceptable Paper" in Chapter 9.
How can I clear paper jams?	See "Paper Jams" on pages 146–148.

# **General Printing Difficulties**

Difficulty	Suggestions
The MFC prints unexpectedly or it prints garbage.	<ul> <li>Turn the MFC off and on or reset it.</li> <li>Make sure your application software is correctly set up to use the MFC by checking the printer settings in your application software.</li> <li>Make sure that the correct interface type and settings are set up to match your computer. Be sure to use the RS-422A serial interface for Macintosh computers and the RS-232C serial interface for PCs. Refer to "Connecting the Serial Interface Board (RS100M)" in Chapter 14.</li> </ul>
The MFC cannot print full pages of a document. An error message PRINT OVERRUN occurs.	The MFC received a very complex printjob and could not process part of the page. This may be solved by the following ways.  If you are using Windows® 3.1, 3.11, Windows® 95 or Windows NT® Workstation Version 4.0 with the supplied printer driver, see the "Windows® Setup Printing Problems" section.  Try to reduce the complexity of your document or reduce the print resolution.
The MFC prints the first couple of pages correctly, then some pages have text missing.	This is a problem usually relating to serial interface settings. Your computer is not recognizing the printer's input buffer full signal. Causes could be the wrong type of serial cable (incorrectly wired or too long) or incorrect setting of your computer serial interface.
The MFC cannot print full pages of a document. AMEMORY FULL error message occurs.	<ul> <li>Expand the printer memory by installing one of the optional memory boards (ME1000 or ME2000).</li> <li>Reduce the printer resolution.</li> <li>Reduce the complexity of your document and try again.</li> <li>Reduce the graphic quality or the number of font sizes within your application software.</li> </ul>
My headers or footers appear when I view my document on the screen but do not show up when I print them.	Most laser printers have a restricted area that will not accept print. Usually these are the first two lines and last two lines, leaving 62 printable lines. Adjust the top and bottom margins in your document to allow for this.

## **Print Quality Difficulties**

## NOTICE

If the display shows CHANGE DRUM, you can clear a print quality problem by replacing the drum unit with a new one. The old drum unit is at the end of its life.

Difficulty	Suggestions
Printouts are too dark or light.	Adjust the print conditions by setting the Print Density function, or turn the print density dial counterclockwise for lighter images and clockwise for darker images. It has been factory set to the middle position. See "The Print is too Light or too Dark" on page 162.
Printed pages contain white stripes.  White Stripes or Faint Images	You may fix this by wiping the scanner windows with a clean soft cloth. (See "Regular Maintenance" and "Cleaning the Drum Unit" on pages 141–143.)  If you still see white stripes or faint images and the display shows CHANGE DRUM, replace the drum unit with a new one.
Printed pages are stained with toner or have vertical stripes.  Dark Stripes or Toner Stains	<ul> <li>Clean the MFC's interior and the primary corona wire of the toner cartridge. See "Regular Maintenance" and "Cleaning the Drum Unit" on pages 141–143.</li> <li>Make sure that the tab of the corona wire is at the home position.</li> <li>If you still see dark stripes or toner stains and the display shows CHANGE DRUM after cleaning, replace the drum unit with a new one.</li> </ul>
Printed pages have white spots in black text and graphics area.	Make sure that you use paper that meets the specifications. Rough surface or thick media can cause the problem.  If you still see white spots and the display shows CHANGE DRUM, replace the drum unit with a new one.
White Spots	

Difficulty	Suggestions
Toner scatters and stains the printed page.	If toner scattered over the whole printing surface, adjust the print density dial inside the printer counterclockwise. See "The Print is too Light or too Dark" on page 162.
New Constitution of the Co	Clean the MFC's interior. See "Regular Maintenance" and "Cleaning the Drum Unit" on pages 141-143.
	Make sure that you use paper that meets specifications. See page 107.
Scattering Toner	If you still have scattered toner and the display shows CHANGE DRUM, replace the drum unit with a new one.
The whole page is printed in black.	Wipe the electric terminals referring to page 142. Also, do not use heat-sensitive paper as it will cause this problem.
	After cleaning, if the printed pages are still black and the display shows CHANGE DRUM, replace the drum unit with a new one.
Black Page	<u> </u>
Nothing is printed on the	Make sure that the toner cartridge is not empty.
page.	<ul> <li>Wipe the electric terminals referring to "Regular Maintenance" and "Cleaning the Drum Unit" on pages 141-143.</li> </ul>
	Make sure that a torn piece of paper does not remain on the scanner window.
White page	
Printed pages are marked at regular intervals.	The markings may disappear by themselves. Try copying multiple pages to clear this problem. Markings may occur if the MFC has not been used for a long time.
	A possible cause is that the surface of the drum is scratched. You must then replace the drum unit with a new one.
Everyla of Pagula-	If the markings do not disappear, it may be that the drum was marked or damaged by excessive exposure to light. In this case, replace the drum unit with a new one.
Example of Regular Marking	

NOTE: The drum unit is a consumable item, and it is necessary to replace it periodically.

### 16. SPECIFICATIONS

**Product Description** Five

Five performance modes are available for the MFC: Fax, Printer, Copier, Scanner and PC Fax in the MFC 4550 plus.

**Printer Specifications** 

Emulation Brother Printing System for Windows®, emulation mode of

HP LaserJet IIP (PCL level 4).

Printer Driver Windows® 3.1/3.11, Windows® 95 and Windows NT®

Workstation Version 4.0 driver supporting Brother Native

Compression mode and bi-directional capability

Optional Macintosh driver available for System 6.0.7 or

higher

Interface Bi-directional parallel

RS-422A/RS-232C serial interface (RS100M) is available as

an option.

Memory 512 KB

Expandable: 1 MB or 2 MB optional memory board

Printer Method Electrophotography by semiconductor laser beam scanning

Resolution 600 dots/inch

Print Quality Normal printing mode

Economy printing mode (saves up to 50% of the normal

toner usage)

Print Speed Six pages/minute (when loading A4 or letter size paper from

the multi-purpose sheet feeder)

Print Media Toner cartridge:

Life Expectancy: 2,200 pages/new toner cartridge

1,000 pages/starter toner cartridge

(USA, Canada and some other areas only)

(when printing on letter or A4 size paper at 5% print

coverage)

NOTE: Toner life expectancy will vary depending on the

type of average print job printed.

Drum Unit:

Life Expectancy: 20,000 pages at 20 pages per job

8,000 pages at 1 page per job

NOTE: There are many factors that determine the actual

drum life, such as temperature, humidity, type of paper and toner that you use, the number of pages

per joint job, etc.

TrueType Fonts on Disks TrueType-compatible soft-fonts for Windows® on the

supplied disk

### **Fax Specifications**

Compatibility **Coding System**  ITU-TS Group 3 MH/MR/MMR

**Modem Speed** 

14400/12000/9600/7200/4800/2400; Automatic Fallback

**Document Input Width** 

148 mm to 216 mm (5.8 inches to 8.5 inches)

Scanning/Printing Width

Paper Size

208 mm (8.2 inches) Letter/Legal/A4

Multi-Purpose Sheet Feeder

200 sheets (20 lbs)

**Gray Scale** 

64 levels

**Polling Types** 

Standard, Delay, Sequential

**Contrast Control** 

Automatic/Super Light/Super Dark (manual setting)

Resolution

• Horizontal 8 dot/mm (203 dot/inch)

• Vertical Standard 3.85 line/mm (98 line/inch) Fine, Photo 7.7 line/mm (196 line/inch)

Superfine, Photo (copy) 15.4 line/mm (392 line/inch)

One Touch Dial

24 stations

Speed Dial

36 stations

**Automatic Redial** 

Three times at five minute intervals

Speaker Type

Monitor

**Auto Answer** 

0, 1, 2, 3 or 4 rings

**Communication Source** 

Public switched telephone network

#### **Electrical and Environment**

Temperature

(Allowable) 50 - 90.5° F (10 - 32.5° C)

(Storage)

38 - 104° F (3.3 - 40° C)

Warm-up

Max. 1 minute at 23° C (73.4° F)

First Print

20 seconds (when loading the Letter size paper from the

multi-purpose sheet feeder)

**Power Source** 

120V AC 50/60Hz (U.S.A., Canadian Version Only)

**Power Consumption** 

Operating (Copying): 160 W or less (25° C)

Sleep Mode: 9 W or less

Stand by: 30 W or less (25° C)

Noise

Operating: 50 dB A or less

Stand-by:

39 dB A or less

**Humidity** 

Operating: 35 to 80% (without condensation)

Storage:

20 to 80% (without condensation)

**Dimensions** 

383 x 452 x 251 (mm)/15.1 x 17.8 x 9.9 (inches)

Weight

8.5 kg/18.8 lbs

Interface Connector

Printer Side: Amphenol FCN-685J036-L/X or equivalent A shielded cable should be used.

Pin Assignment

Pin No.	Signal	Direction	Pin No.	Signal	Direction
1	DATA STROBE	Input	19	0V(S.G.)	
2	DATA 1	Input	20	0V(S.G.)	
3	DTAT 2	Input	21	0V(S.G.)	-
4	DATA 3	Input	22	0V(S.G.)	_ =
5	DATA 4	Input	23	0V(S.G.)	_
6	DATA 5	Input	24	0V(S.G.)	-
7	DATA 6	Input	25	0V(S.G.)	- *
8	DATA 7	Input	26	0V(S.G.)	-
9	DATA 8	Input	27	0V(S.G.)	- 3
10	ACKNLG	Output	28	0V(S.G.)	-
11	BUSY	Output	29	0V(S.G.)	-
12	PE	Output	30	0V(S.G.)	-
13	SLCT	Output	31	IMPUT PRIME	Input
14	AUTO FEED	Input	32	FAULT	Output
15	N.C.	-	33	N.C.	-
16	0V (S.G.)	-	34	N.C.	-
17	0V (S.G.)	-	35	_ N.C	-
18	+5V	-	36	SLCT IN	Input

#### **Resident Fonts**

The following bitmapped fonts are resident in the MFC.

Brougham 10 (12 point)

Brougham 12 (10 point)

Letter Gothic 16.66 (8.5 point)

upright/normal upright/bold

italic/normal

italic/bold

upright/normal

upright/bold italic/norml

italic/bold

upright/normal

upright/bold

italic/normal

italic/bold

(Portrait and Landscape are available for the above.)

## Symbol Sets/Character Sets

## \*HP mode

- ISO14 JIS ASCII
- ISO57 Chinese
- ISO11 Swedish
- HP Spanish
- ISO17 Spanish ISO10 Swedish
- ISO16 Portuguese
- ISO84 Portuguese
- ISO85 Spanish
- PC-8
- PC-8 D/N
- PC-8 Turkish
- PC-850
- PC-852
- PC-860
- PC-863
- PC-865

- Roman 8
- ISO Latin 1 (ECMA-94)
- ISO60 Norwegian 1
- ISO61 Norwegian 2
- ISO4 UK
- ISO25 French
- ISO69 French
- HP German
- ISO21 German
- ISO15 Italian
- ISO6 ASCII
- Legal ISO2 IRV

NOTE: If you want to know which characters are in each symbol/character set, print the CHARSETS.PRN file from "The Print form" option in the Direct Access Menu of the Remote Printer Console Program.

☐ HP LaserJet IIP

	R	on	nan	8														IS	Ю	La	tir	ıl											
	0	1	2	3	4	5	6	7	8	9	A	B	c	Đ	E	F		٥	1	2	3	4	5	6	7	8	9	A	B	¢	_	E	_
0				0	e	P	٠	p				_	â	Â	Á	Þ	0				0	0	P	٠	p				•		Ð		
1			1	1	A	Q	-	4			À	Ý	s	۶	ī	Þ	1			1	1	A	Q	a	q			1	±		Ñ		
2			14	2	В	R	Þ	r			Â	Ý	â	Ø	ā	٠	Z			**	2	В	R	ь	r			¢	3	Â		â	à
3			#	3	c	s	¢	s			È	٠	û	E	Đ	μ	3			#	3	C	S	c	5			£	3	Ã	Õ	ã	ó
4			\$	4	D	T	đ	t			Ê	Ç	á	å	ð	N	4			\$	4	0	Ţ	d	t			4	-	Ä	Ô	ä	ô
5			ŧ	5	Ë	U	е	u			Ë	¢	é	í	Í	ş	5			ŧ	5	Ε	U	8	u			Ŧ	ц	Å		å	õ
6			8	6	F	٧	£	٧			Î	Ñ	ó	ø	Ì	-	6			&	6	F	V	£	v			1	П	£	Ö	æ	ö
7			,	7	G	W	g	¥			Ϊ	ñ		20		1	7			٠	7	G	W	g	w			5	•	Ç	×	ç	٠
8			(	8	Ħ	X	h	x			-	î	à	Ã	õ	1/2	8			(	8	H	X	h	×			••		È	Ø	è	ø
9			)	9	I	Y	i	y			-	ž	ě	ī	Ō	4	9			)	9	1	Y	i	Y			¢	٠,	É	Ū	é	ù
Α				ž	J	Z	j	z			-	Ħ	ŏ	Ö	ō	2	A			*	:	J	2	j	z			4	8	Ê	Ű	ê	ű
В			+	;	K	ι	k	(			••	E				*	В			+	7	K	Ţ	k	{			45	33	Ē	Û	ē	û
c			,	<	L	١	1	ı			-	¥	ä	É	š	×	c			,	<	Ĺ	١	1	1			7	ŧ	Ĭ	Ü	ì	ü
D			-	=	М	1	m	}			ù	5	ë	ï	Ű	*	D			-	*	M	1	Œ	)			-	1	Í	Ý	í	Ý
Е				>	N	٨	n	-			Û	f	ö	В	Ÿ	±	E				>	N	^	n	-			•	₹	Î	Þ	î	Þ
F			1	?	0		٥	沒			£	¢	ü	ô	ÿ		F			1	?	٥	_	o	ÿ,			•	š	Ϊ	В	ï	Ÿ

The following table shows characters available only in the corresponding character set. The numbers at the top of the table are code values with which characters are to be replaced in the Roman 8 character set. For other characters, see character set of Roman 8.

SYMBOL SET	23	24	40	5B	5C	SD	5E	60	7В	7C	7D	7E
ISO2 IRV	*	耳		E	١	1	•	•	-{		}	_
ISO4 UK	£	\$	6	Ę	١.	J	-		ŧ	1	1	_
ISO6 ASCII	#	\$		ſ	١.	]	^	*	{	-	}	-
ISO10 Swedish	#	ш	8	Ä	õ	Ä	-	-	ä	ő	å	_
ISO11 Swedish	#	п	É	Ä	ö	Å	ő	é	ä	ō	å	ū
ISO14 JIS ASCII	#	\$	6	Ţ	¥	1	^	•	(	1	}	_
ISO15 Italian	£	Ş	5	•	ç	é	•	ũ	à	ò	è	ì
ISO16 Portuguese	#	\$	5	Ā	Ç	Õ	•	•	ã	ç	ō	•
ISO17 Spanish	£	\$	5	ī	Ñ	ž	-	٠	•	ñ	ç	•
ISO21 German	#	\$	ş	Ä	ö	Ü	•	•	ä	ö	ü	8
ISO25 French	£	s	ä	•	ç	5	^	٠	é	ù	è	••
ISO57 Chinese	#	¥	9	ſ	١	1	•	٠	•	1	}	_
ISO60 Norwegian1	#	\$	æ	Æ	ø	Á	•	•	æ	8	å	_
ISO61 Norwegian2	5	•		R	Ø	å	•	•	20	a	å	1
ISO69 French	£	\$	à	•	ç	§ Ö	-	μ	é	ŭ	è	••
ISO84 Portuguese	#	\$	•	Â	Ç	ô	^	•	ã	Ç	ō	-
ISO85 Spanish	Ħ	5		ī	Ñ	Ç	z	. `	•	ñ	ç	-
HP German	E	\$	Ş	Ä	õ	Ü	-	•	ä	ö	ü	8
HP Spanish	#	S	e	ī	Ñ	Ł	•	•	-{	ñ	}	-

## 17. IMPORTANT INFORMATION

### Standard Telephone and FCC Notices (Applies only to 120V model)

These notices are in effect on models sold and used in the U.S.A.

This equipment is hearing aid compatible.

### When programming emergency numbers and/or making test calls to emergency numbers:

- Remain on the line and briefly explain to the dispatcher the reason for the call before hanging up.
- Perform such activities in the off-peak hours, such as early morning or late evening.

This equipment complies with Part 68 of FCC Rules. On the rear panel of this equipment is a label that contains, among other information, the FCC Registration Number and Ringer equivalence Number (REN) for this equipment. You must, upon request, provide this information to your telephone company.

You may safely connect this equipment to the telephone line by means of a standard modular jack, USOC RJ11C.

An FCC compliant telephone cord and modular plug is provided with this equipment. This equipment is designed to be connected to the telephone line or premises wiring using a compatible modular jack which is Part 68 compliant.

The REN is useful to determine the quantity of devices you may connect to your telephone line and still have those devices ring when your telephone number is called. In most, but not all areas, the sum of the RENs of all devices connected to one line should not exceed five (5). To be certain of the number of devices you may connect to your line, as determined by the REN, you should contact your local telephone company to determine the maximum REN for your calling area.

If your MFC 4550 plus damages the telephone line, the telephone company may discontinue your service temporarily. If possible, they will notify you in advance. But if advanced notice is not practical, you will be notified as soon as possible. You will be informed of your right to file a complaint with the FCC.

Your telephone company may make changes to its facilities, equipment, operations or procedures that could affect the proper functioning of your equipment. If they do, you will be notified in advance to give you an opportunity to maintain uninterrupted telephone service.

If you experience trouble with this MFC 4550 plus, please contact a Brother Authorized Service Center for information on obtaining service or repair. The telephone company may ask that you disconnect this equipment from the line until the problem has been corrected or until you are sure that the equipment is not malfunctioning.

If you are not able to solve a problem with your MFC, contact Brother Customer Service at:

**USA:** 1-800-284-4329 (voice)

1-908-271-1937 (fax)

From within Canada: 1-800-853-6660 (voice)

1-514-685-4898 (fax)

From within Montreal: 1-514-685-6464 (voice)

#### Warning

For protection against the risk of electrical shock, always disconnect all cables from the wall outlet before servicing, modifying or installing the equipment.

Paragraphics

This equipment may not be used on coin service lines provided by the telephone company or connected to party lines.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the fax equipment and the receiver.
- · Connect the fax equipment on a separate circuit.
- Consult with the dealer or an experienced radio/TV technician for help.

#### Laser Safety (For 110-120 V Model Only)

This equipment-is certified as a Class I laser product under the U.S. Department of Health and Human Services (DHHS) Radiation Performance Standard according to the Radiation Control for Health and Safety Act of 1968. This means that the equipment does not produce hazardous laser radiation.

Since radiation emitted inside the equipment is completely confined within protective housings and external covers, the laser beam cannot escape from the MFC during any phase of user operation.

#### **FDA Regulations**

U.S. Food and Drug Administration (FDA) has implemented regulations for laser products manufactured on and after August 2, 1976. Compliance is mandatory for products marketed in the United States. One of the following labels on the back of the printer indicates compliance with the FDA regulations and must be attached to laser products marketed in the United States.

#### MANUFACTURED:

#### BROTHER INDUSTRIES, LTD.

15-1 Nacshiro-cho Mizuho-ku Nagoya, 467 Japan

This product complies with FDA radiation performance standards, 21 CFR Subchapter J.

#### Caution

Use of controls, adjustments or performance of procedures other than those specified in this manual may result in hazardous invisible radiation exposure.

#### International Energy Star Compliance Statement

The purpose of the International Energy Star Program is to promote the development and popularization of energy-efficient office equipments, which includes computers, monitors, printers, facsimile receivers and copy machines world-wide. As an International Energy Star partner, Brother Industries, Ltd. has decided that this product meets the guideline of the program.



Brother cannot accept any financial or other responsibilities that may be the result of your use of this information, including direct, special or consequential damages. There are no warranties extended or granted by this document.

The serial number may be found on the label affixed to the back of the unit. For your convenience, note the number below and retain this Operations Manual to serve as a permanent record of your purchase, in the event of a theft or fire, or for future reference.

MODEL NO. MFC 4550 plu	s SERIAL NO		
NAME OF DEALER			
DATE OF PURCHASE	-	 	
		•	

#### Important Safety Instructions

- 1. Read all of these instructions
- 2. Save them for later reference.
- 3. Follow all warnings and instructions marked on the product.
- Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
- 5. Do not use this product near water.
- 6. Do not place this product on an unstable cart, stand, or table. The product may fall, causing serious damage to the product.
- 7. Slots and openings in the cabinet and the back or bottom are provided for ventilation; to ensure reliable operation of the product and to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heater. This product should not be placed in a built-in installation unless proper ventilation is provided.

- This product should be operated from the type of power source indicated on the label. If
  you are not sure of the type of power available, consult with your dealer or local power
  company.
- 9. This product is equipped with a 3-wire grounding type plug, a plug having a third (grounding) pin. This plug will fit only into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the purpose of the grounding-type plug.
- 10. Do not allow anything to rest on the power cord. Do not locate this product where people can walk on the cord.
- 11. If an extension cord is used (see pages 8–9 of Setup Manual) with this product, make sure that the total ampere ratings on the products plugged into the extension cord do not exceed the extension cord ampere rating. Also, make sure that the total of all products plugged into the wall outlet does not exceed 15 amperes (USA only).
- 12. Never push objects of any kind into this product through cabinet slots since they may touch dangerous voltage points or short out parts resulting in a risk of fire or electric shock. Never spill liquid of any kind on the product.
- 13. Do not attempt to service this product yourself because opening or removing covers may expose you to dangerous voltage points and/or other risks and may void your warranty. Refer all servicing to an Authorized Service Personnel. A list of Brother Authorized Service Centers has been included for your convenience, or you may contact the following Customer Service Numbers for your nearest Brother Authorized Service Center:

USA: 1-800-284-4329 (voice)

1-908-271-1937 (fax)

1-800-521-2846 (Fax-Back System)

From within Canada: 1-800-853-6660 (voice)

1-514-685-4898 (fax)

1-800-681-9838 (Fax-Back System)

From within Montreal: 1-514-685-6464 (voice)

- 14. Unplug this product from the wall outlet and refer servicing to Authorized Service Personnel under the following conditions:
  - A. When the power cord or plug is damaged or frayed.
  - B. If liquid has been spilled into the product.
  - C. If the product has been exposed to rain or water.
  - D. If the product does not operate normally when the operating instructions are followed. Adjust only those controls that are covered by the operating instructions since improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
  - E. If the product has been dropped or the cabinet has been damaged.
  - F. If the product exhibits a distinct change in performance, indicating a need for service.
- 15. To protect your product against power surges, we recommend the use of a power protection device (Surge Protector).

#### Important - About the Interface Cable

This MFC has been certified to comply with FCC standards, which are applied to the USA only. A shielded interface cable should be used according to FCC 15.27 (C). In addition, a grounded plug should be plugged into a grounded AC outlet after checking the rating of the local power supply for the printer to operate properly and safely.

### CAUTION-

 $Changes\ or\ modifications\ not\ expressly\ approved\ by\ Brother\ Industries, Ltd.\ may\ void\ the\ user's\ authority\ to\ operate\ the\ equipment.$ 

#### **Notice**

BROTHER'S LICENSOR(S) MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, REGARDING THE SOFTWARE. BROTHER'S LICENSOR(S) DOES NOT WARRANT, GUARANTEE OR MAKE ANY REPRESENTATIONS REGARDING THE USE OR THE RESULTS OF THE USE OF THE SOFTWARE IN TERMS OF ITS CORRECTNESS, ACCURACY, RELIABILITY, CURRENTNESSOROTHERWISE. THE ENTIRE RISK AS TO THE RESULTS AND PERFORMANCE OF THE SOFTWARE IS ASSUMEND BY YOU. THE EXCLUSION OF IMPLIED WARRANTIES IS NOT PERMITTED BY SOME STATES. THE ABOVE EXCLUSION MAY NOT APPLY TO YOU.

IN NO EVENT WILL BROTHER'S LICENSOR(S), AND THEIR DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS (COLLECTIVELY BROTHER'S LICENSOR) BE LIABLE TO YOU FOR ANY CONSEQUENTIAL, INCIDENTAL OR INDIRECT DAMAGES (INCLUDING DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION LOSS OF BUSINESS INFORMATION, AND THE LIKE) ARISING OUT OF THE USE OR INABILITY TO USE THE SOFTWARE EVEN IF BROTHER'S LICENSOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BECAUSE SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. IN ANY EVENT BROTHER'S LICENSOR'S LIABILITY TO YOU FOR ACTUAL DAMAGES FROM ANY CAUSE WHATSOEVER, AND REGARDLESS OF THE FORM OF THE ACTION (WHETHER IN CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY OR OTHERWISE), WILL BE LIMITED TU \$50.

COPYRIGHT © 1994 APPLE COMPUTER, INC. ALL RIGHTS RESERVED.

#### **Trademarks**

The brother logo is a registered trademark of Brother Industries, Ltd.

© Copyright 1997 Brother Industries, Ltd. All rights reserved.

© Copyright 1997 Smith Micro Software, Inc. All rights reserved.

© Copyright 1997 Visioneer, Inc. All rights reserved.

Brother is a registered trademark of Brother Industries, Ltd.

Visioneer PaperPort is a registered trademark of Visioneer, Inc.

Windows is a registered trademark of Microsoft in the U.S. and other countries.

Excel and Word are trademarks of Microsoft Corp.

TextBridge is a trademark of Xerox Imaging Systems, Inc.

TrueType is a trademark of Apple Computer, Inc.

Centronics is a trademark of Genicom Corporation.

Epson is a registered trademark and FX-80 FX-850 are trademarks of Seiko Epson Corporation.

Hewlett Packard is a registered trademark and HP LaserJet II, IIP, and IID are trademarks of Hewlett-Packard Company.

IBM, IBM PC, and Proprinter are registered trademarks of International Business Machines Corporation.

Microsoft and MS-DOS are registered trademarks of Microsoft Corporation.

Hammermill copyplus white is a registered trademark of International Paper.

All other terms and brand and product names mentioned in this manual are registered trademarks of their respective companies.

#### **Compilation and Publication Notice**

Under the supervision of Brother Industries Ltd., this manual has been compiled and published, covering the latest product's descriptions and specifications.

The contents of this manual and the specifications of this product are subject to change without notice.

Brother reserves the right to make changes without notice in the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical and other errors relating to the publication.

INDEX	
A	Daily Timer 4
Accessory Orders 192	Date and Time
Activity Report 121, 123, 124	Delayed Polling 92~93
ADF 34	Delayed Transmission 42~43
All Dial List 121, 125	Difficulties 167~17
Answer Mode 6, 61	DIP Switch 152
Automatic Transmission 37~38	Distinctive Ringing 79~84
	Document 33~34
В	Drum Unit 137~139
Beeper 23	Duplex 114
Broadcasting 43~44	
Brother Bulletin Board 157	E
Brother Customer Service 191	ECM 58
Brother Fax-Back System 157	Emulation 11:
Brother on The World	Enlarging Copies13
Wide Web 157	Envelopes 107, 109
	Environment176
С	Error Message/Codes 158~166
Call Back Message 56~58, 121	Error Retransmission59
Call Reservation 56~57	Extension Telephone 75
Canceling 47	External Telephone
Chain Dialing 29	
Character Sets 178	F
Cleaning 141~143	F/T Mode 61, 63~6
Clearing Errors 111	Factory Reset 119
Connecting 8~10 of Setup	Fax Forwarding 97, 10
Manual, 73, 77	Fax Storage9
Contrast 36	Fax-Back System 15
Control Panel Keys 1~6	FCC Notices 181~18
Copy 3, 129~132	FF/CONT Key11
Cover Open 159	Fine 3
Cover Page 50~55, 121	Font 17
Customer Service 191	Font List Print11
_	Form Feed 11
D	Function 5, 7~
D/D SET MODE 83-84	

G	Multiple Resolution
Groups for Broadcasting 27~29	Transmission 49~50
н	N
HELP 6, 14	Next-FAX Reservation 59
Hex Dump Mode 120	
Hold 2, 31	0
Hook 2, 31~32	OffLine 110
	On Hook Dial 32
. I	On-Screen Programming 7~8
Interrupting 46	One Touch Dial 3, 10, 24~25,
	27, 31, 37
j	OnLine 110
Jack 73, 78	Organizer Sheet 107
Jam 146~148	Overseas Mode 48
L	P
Label 107	Packing List 2 of Setup
Line Error 159	Manual
Loading Paper 4~6 of Setup	Paging 97~99
Manual, 114~116	Paper 107~109
	Paper Jam 146~148
M	Paper Size 67~68
Manual Dial31	Paper Specifications 107
Manual Duplex 114	Parallel Interface177
Manual Feed 115~116	Pause 2, 25, 31
Memory 27, 69	PBX 14 of Setup Manual, 26
Memory Board 154	Photo 35, 129, 132
Memory Full 40, 130, 160	Polling 89~94
Memory Full Error170	Power 8~9 of Setup Manual, 176
Memory Status List 104, 121, 127	Print Configuration118
Memory Transmission 40, 42~45	Print Overrun 160
Mode 6, 61	Print Quality161
Multi-Purpose Sheet	Printable Area 109
Feeder 113114	

R	Smoothing 65
Redial 2, 39	Speaker Volume71
Reduction 66~68, 131	Specifications 175~179
Remote Access/	Speed Dial 10, 25~27, 31, 37
Retrieval 100~104	Standard Mode 35, 49
Remote Activation 74~76	Station ID21~22
Remote Code 74~76	Super Dark Mode 36
Remote Control Commands . 103	Super Fine Mode 35, 49
Remote Deactivation 74~76	Super Light Mode 36
Remote Printer Console	Super Quick-Scan 40
Program112	Supplies 192
Reports 121~127	Symbol Sets 178
Reset 111	•
Resident Fonts177	T
Resolution 6, 10, 35, 49~50	TAD Hookup 78
Ring Delay 62	TAD Mode 61, 76~79
Ring Time 64	Telephone Index 32
Ring Volume 72	Test Sample Page 111
RS-232C 151	Tone/Pulse19
RS-422A 151	Toner Cartridge133
	Toner Empty 133, 158
S	Toner Save 70
Safety Instructions 183~185	Transmission Verification
Sequential Polling 93~94	Report 121, 126~127
Setting Up 3~14 of Setup	Transparency 107
Manual	Troubleshooting 157~174
Shift3, 24, 116, 120	*
Shortcut 8	W
Simultaneous 110	World Wide Web157
Sleep Mode 17~18	

# FOR CUSTOMER SERVICE

**USA:** 1-800-284-4329 (voice)

1-908-271-1937 (fax)

From within Canada: 1-800-853-6660 (voice)

1-514-685-4898 (fax)

From within Montreal: 1-514-685-6464 (voice)

# ORDERING ACCESSORIES AND SUPPLIES

For the best quality results use only genuine Brother accessories, available at most Brother retailers. If you cannot find the accessory you need and you have a Visa, MasterCard, Discover, or American Express credit card, you can order accessories directly from Brother.

**USA:** 1-888-879-3232 (voice)

1-800-947-1445 (fax)

From within Canada: 1-800-668-2768 (voice)

Description	ltem
Laser Fax Toner	TN5000PF
Laser Fax Drum	DR200
1 MB Expandable Memory Board	ME1000
2 MB Expandable Memory Board	ME2000
Telephone Line Cord	UG1570001
Telephone Handset	UF6400003
Handset Curled Cord	UF7204009
Dust Cover	UL6955001
Wire Extension	UF7201001
IEEE-1284 Bi-directional Cable	UG4166001
Paper Tray	UF7209001
Document Tray with Wire Extension	UF7206001
Setup Manual	UF7828001
Quick Reference Card	UF7696001
Remote Control Card	UF8297001



Brother International Corporation 200 Cottontail Lane, Somerset, NJ 08875-6714, U.S.A.

Brother International Corporation (Canada) Ltd.
1 rue Hôtel de Ville,
Dollard-des-Ormeaux, QC, CANADA H9B 3H6

These machines are made for use in the USA or CANADA only. We can not recommend using them overseas because it may violate the Telecommunications Regulations of that country and the power requirements of your Multi-Function Center may not be compatible with the power available in foreign countries. Using USA or CANADA models overseas is at your own risk and will void your warranty.

\* Manufactured by Brother Industries Ltd. whose quality system is registered by BSI and JQA.

BSI Certificate of registration No. FM27391 JQA Certificate of registration No. JQA-0340 UF7825001 Printed in Japan